

IsoUs – Ultimate Step  
G Code User Manual

[www.promax.it](http://www.promax.it)



**PROMAX**

Motion  
&  
Control

The contained information in this handbook are only informative and they can being change without warning and they must not being understandings with some engagement from Promax srl. Promax srl does not assume responsibility or obligates for errors or inaccuracies that can be found in this handbook. Except how much granted from the license, no part of this publication can be reproduced, saved in a recording system or transmitted in whatever form or with any means, electronic, mechanical or recording system or otherwise without Promax srl authorization. Any reference to names of society or products have only demonstrative scope and it does not allude to some real organization.

Rev. 4.8.6 © Promax srl

## 1 INTRODUCTION

This manual explains ISO programming and all relative functions. The method of programming can change with the used PC model (keyboard, touch-screen), however main concept remains unchanged. To manage ISO programs refer to USER INTERFACE manual.

## 2 ISOUS RULES

### 2.1 BLOCK

A block is formed by one or more ISO function ended with CR/LF character. The sequence of more blocks composes a program (defined PartProgram) that it is managed by user interface.

**All characters forming the block must be UPPER-CASE.**

Isous editor makes an automatic conversion of lower-case characters.

**G1X100Y100Z10**

### 2.2 LINE NUMBER OR BLOCK NUMBER

Line number or block number defines block position inside the PROGRAM.

Such position is useful in some features (block restart, retrace, etc.).

Isous ignores line marks Nxx before block, therefore the real line number is the number showed on ISO editor window.

ISO CODE	
1	N10 G1X100Y100
2	N30 G4F2

Isous ignores **N10** and **N30** characters, therefore the real line is showed on the left bar. 1 and 2 in this example.

### 2.3 PROGRAM RUNNING

Program running is made by Isous user interface. When in run, program can be PAUSED or STOPPED.

### 2.4 AXIS NAME

Isous don't use any particular convention to define axis type (linear or rotative) by name (X,Y, etc.). Definition must be setted only in configuration. Isous manages up to 9 axis with the following names:

**X,Y,Z,A,B,C,U,V,W**

### 2.5 HOMING

All axis refer to an HOME POSITION made after switch on. Home position follows an HOMING procedure selected by relative machine parameters.

### 2.6 WORK ORIGIN

Isous manages up to 256 different WORK ORIGINS. Each origin defines a reference point of zero, all following positions refers to this point. Origins can be set both manually by interface and with dedicated instructions inserted in PartProgram. Furthermore they can be SUSPENDED, RESTORED or DISABLED.

## 2.7 WORK OFFSET

As well origin, Isous can manage up to 256 WORK OFFSET. An OFFSET works as a new origin manageable only with PartProgram. Also OFFSETS can be SUSPENDED, RESTORED or DISABLED.

## 2.8 HEADS

Isous manages 256 working HEADS for a single machine.

Each head refers to machine origin and it is automatically pre-setted (do not need to use WORK ORIGIN e WORK OFFSET). Used head can be recall by PartProgram with Hn instruction. It programs automatically head offset of all axis (referred to machine origin).

## 2.9 MODAL FUNCTIONS

MODAL functions remains active for all current PartProgram and also the subsequent ones until a (or more) particular function disables it. G0,G1,G2,G3 etc. are modal functions and therefore it doesn't need repeat them until another function exclude it. G1 excludes G0,G2 e G3, G2 excludes G0,G1 e G3 etc.

**G1X100Y100**

**X300Y120Z10**

**X450**

In this example it is used modal G1 function. In block 2 and 3 it isn't necessary to insert G1 because it remains active.

## 2.10 RECOGNIZED CODES

Almost all recognized codes are highlighted with a colour. However, in the few cases when it doesn't happen, it doesn't mean instruction isn't recognized.

When Isous editor doesn't recognize an instruction it is underlined with RED and it shows error window.

## 2.11 NUMERIC VALUES SETTING

Isous works with two numeric values types:

### INTEGER

### FLOATING

Integer values are used for all defined quantities (Loop numbers, etc.). When it is insert a floating value instead of integer one, Isous generate an error warning the user.

Floating values are used for all REAL quantities (axis position, radius, etc.).

Isous uses as decimal separator character "." (DOT).

## 2.12 PROGRAM REMARKS

Isous don't use CNC classic convention for program remarks.

Remarks starts with "//" characters and terminates with end line. Isous editor highlights it with GREEN colour.

Remarks can be insert also on the right of block.

Remarks are ignored by PartProgram and all its content are discarded.

// This is a remark

**G1X100Y100** // This is a remark too

### 3 ISO NS INSTRUCTIONS

#### 3.1 RECOGNIZED G CODES

Code G	Description	TASK1	TASK2
<a href="#">G0</a>	RAPID positioning	NO	NO
<a href="#">G0.1</a>	RAPID positioning single Axis with private Acceleration	NO	NO
<a href="#">G0.2</a>	RAPID positioning for "TRANSPORTED AXIS"	NO	NO
<a href="#">G1</a>	Linear Interpolation at F programmed speed	NO	NO
<a href="#">G1.1</a>	G1-G2-G3 Suspension and set G0	NO	NO
<a href="#">G1.2</a>	G1 Resume	NO	NO
<a href="#">G2</a>	CW circular interpolation	NO	NO
<a href="#">G3</a>	CCW circular interpolation	NO	NO
<a href="#">G4</a>	Timed pause	YES	YES
<a href="#">G4.1</a>	Time Add on Calc Time	NO	NO
<a href="#">G10</a>	Enable external axis OVERRIDE ASSI on potentiometer	YES	YES
<a href="#">G11</a>	Disable external axis OVERRIDE ASSI on potentiometer	YES	YES
<a href="#">G17</a>	Set work plane on X-Y	NO	NO
<a href="#">G18</a>	Set work plane on Z-X	NO	NO
<a href="#">G18.1</a>	Set work plane on Z-X but not in PREVIEW	NO	NO
<a href="#">G19</a>	Set work plane on Y-Z	NO	NO
<a href="#">G19.1</a>	Set work plane on Y-Z but not in PREVIEW	NO	NO
<a href="#">G20</a>	Axes in Inch	NO	NO
<a href="#">G21</a>	Axes in millimeters	NO	NO
<a href="#">G22</a>	Change axis of the work plane	NO	NO
<a href="#">G23</a>	Restore axis of the work plane (disable G22)	NO	NO
<a href="#">G24</a>	Enable horizontal mirror	NO	NO
<a href="#">G25</a>	Disable horizontal mirror G24	NO	NO
<a href="#">G26</a>	Change a couple of axis	NO	NO
<a href="#">G27</a>	Suspend G26	NO	NO
<a href="#">G28</a>	Resume G26	NO	NO
<a href="#">G30</a>	Enable automatic insert of fillet on edges	NO	NO
<a href="#">G31</a>	Suspend G30	NO	NO
<a href="#">G32</a>	Resume G30	NO	NO
<a href="#">G33</a>	Enable automatic insert of bevel on edges	NO	NO
<a href="#">G34</a>	Suspend G33	NO	NO
<a href="#">G35</a>	Resume G33	NO	NO
<a href="#">G36</a>	Gestione assi rotativi	NO	NO
<a href="#">G40</a>	Disable TOOL RADIUS compensation	NO	NO

<a href="#">G41</a>	Enable TOOL RADIUS compensation LEFT	NO	NO
<a href="#">G42</a>	Enable TOOL RADIUS compensation RIGHT	NO	NO
<a href="#">G43</a>	Enable TOOL LENGTH compensation	NO	NO
<a href="#">G44</a>	Disable TOOL LENGTH compensation	NO	NO
<a href="#">G44.1</a> <a href="#">G44.2</a>	Suspend G43 Resume G43	NO	NO
<a href="#">G45</a>	Enable TOOL LENGTH compensation, parameter from TOOL TABLE	NO	NO
<a href="#">G46</a>	Disable G45	NO	NO
<a href="#">G47</a>	Set mode of start/stop TOOL compensation G41 G42	NO	NO
<a href="#">G48</a>	Define Depth Axis	NO	NO
<a href="#">G49</a>	MILD MODE – Edge Smoothing	NO	NO
<a href="#">G50</a>	Working plane rotation	NO	NO
<a href="#">G51</a>	Suspend plane rotation G50	NO	NO
<a href="#">G52</a>	Restore plane rotation G50	NO	NO
<a href="#">G53</a>	As G98 (for compatibility to other cn)	NO	NO
<a href="#">G54</a> <a href="#">G54.n</a>	Work origin from memory, AXIS X (or axis selected by following parameters XYZ etc	NO	NO
<a href="#">G55</a>	Work origin from memory, AXIS Y	NO	NO
<a href="#">G56</a>	Work origin from memory, AXIS Z	NO	NO
<a href="#">G57</a>	Work origin from memory, AXIS XY	NO	NO
<a href="#">G58</a>	Work origin from memory, AXIS YZ	NO	NO
<a href="#">G59</a>	Work origin from memory, AXIS XZ	NO	NO
<a href="#">G60</a>	Enable FAST interpolation without stop on segments	NO	NO
<a href="#">G61</a>	Enable interpolation with stop on segments	NO	NO
<a href="#">G62</a>	Wait stop axis	NO	NO
<a href="#">G63</a>	G1 Enable PX_MOVETO (3D interpolation outside selected plane) without stop	NO	NO
<a href="#">G64</a>	G1 Enable interpolation on selected plane PX_LINETO (2D plane interpolation	NO	NO
<a href="#">G65</a>	Enable 3D interpolation PX_MOVETO with calculated stop on edge by parameters	NO	NO
<a href="#">G66</a>	AFC – Adaptive Feed Control	NO	NO
<a href="#">G66 X-100</a>	NEW AFC – Adaptive Feed Control	NO	NO
<a href="#">G67</a>	PX_MOVETO for movement outside plane and PX_LINETO for inside ones	NO	NO
<a href="#">G68</a>	Always using of PX_LINETO in G1 “TRANSPORTED AXIS”	NO	NO
<a href="#">G69</a>	LHK – Depth of buffer Look Ahead on virtual CN	NO	NO
<a href="#">G70</a>	Set work plane on a generic couple of axis	NO	NO
<a href="#">G71</a> <a href="#">G71.1</a> <a href="#">G71.2</a>	Start axis home searching Enable Axis Disable Axis	NO	NO
<a href="#">G72</a>	Enable N.U.R.B.S (Not Uniform Rational BSpline) filter	NO	NO
<a href="#">G73</a>	Enable Noise filter	NO	NO

<a href="#">G74</a>	Enable RLS (Remove Len Segment) filter	NO	NO
<a href="#">G75</a>	Use G64 for movement inside work plane and G65 for movement outside work plane	NO	NO
<a href="#">G80 (G1080)</a>	Forced pause by code	YES	YES
<a href="#">G81 (G1081)</a>	Management secondary axes LIMITS	YES	YES
<a href="#">G82 (G1082)</a>	Work ORIGIN at current position with sensor offset	NO	NO
<a href="#">G83 (G1083)</a>	Update CPU1 counter	NO	NO
<a href="#">G84 (G1084)</a>	Preset CPU axis	NO	NO
<a href="#">G85</a>	Work OFFSET at current position with sensor offset	NO	NO
<a href="#">G86</a>	Hardware preset axis on module 360 degrees	NO	NO
<a href="#">G87</a>	Suspend head offset selected with Hn	NO	NO
<a href="#">G88</a>	Resume head offset selected with Hn	NO	NO
<a href="#">G89</a>	HardWare Preset of axis position	NO	NO
<a href="#">G90</a>	Values with ABSOLUTE position	NO	NO
<a href="#">G91</a> <a href="#">G91.1</a> <a href="#">G91.2</a>	Values with INCREMENTAL position Force the values in ABSOLUTE (G90) and store the current state (G90-G91) Resume the state stored with G91.1 (G90 if was G90 or G91 if was G91)	NO	NO
<a href="#">G92</a>	Work ORIGIN at current position	NO	NO
<a href="#">G93</a>	Work OFFSET at selected position	NO	NO
<a href="#">G94</a> <a href="#">G94.n</a>	Work ORIGIN at selected position Save work origins	NO	NO
<a href="#">G95</a>	Work OFFSET at current position	NO	NO
<a href="#">G96</a>	Suspend work offset G93-G95	NO	NO
<a href="#">G97</a>	Resume work offset G92-G94	NO	NO
<a href="#">G98</a>	Suspend work origin G92-G94	NO	NO
<a href="#">G99</a>	Resume work origin G92-G94	NO	NO
<a href="#">G100</a>	Synchronous comand for VIRTUAL axis	NO	NO
<a href="#">G101</a>	AXIS STOP comand	YES	YES
<a href="#">G102</a>	Start sensor acquisition	NO	NO
<a href="#">G102.1</a>	Acquisition from PxVision System	NO	NO
<a href="#">G102.2</a>	Start sensor acquisition without Alarm	NO	NO
<a href="#">G103</a>	Set RTCP parameters	NO	NO
<a href="#">G104</a> <a href="#">G104.1</a>	Enable RTCP	NO	NO
<a href="#">G105</a>	Suspend RTCP	NO	NO
<a href="#">G106</a>	Smoothing Filter	NO	NO
<a href="#">G107</a>	Management Interrupt Macro	NO	NO
<a href="#">G108</a>	Management Special Axes	NO	NO
<a href="#">G120</a>	Enable vertical mirror	NO	NO
<a href="#">G121</a>	Disable vertical mirror G20	NO	NO

<a href="#">G940</a>	MOVE axes excluding WORK ORIGIN only in the actual block	NO	NO
<a href="#">G1028 (G28)</a>	Return to Home	NO	NO
<a href="#">G1050</a>	Disable Scaling	NO	NO
<a href="#">G1051</a>	Enable Scaling	NO	NO
<a href="#">G1080 (G80)</a>	Drilling	NO	NO
<a href="#">G1081 (G81)</a>	Drilling	NO	NO
<a href="#">G1082 (G82)</a>	Drilling	NO	NO
<a href="#">G1083 (G83)</a>	DRILLING	NO	NO
<a href="#">G1084 (G84)</a>	TAPPING	NO	NO

#### 4 OTHERS RECOGNIZED CODES

Code	Description	TASK1	TASK2
<a href="#">X</a>	Axis X position	NO	NO
<a href="#">Y</a>	Axis Y position	NO	NO
<a href="#">Z</a>	Axis Z position	NO	NO
<a href="#">A</a>	Axis A position	NO	NO
<a href="#">B</a>	Axis B position	NO	NO
<a href="#">C</a>	Axis C position	NO	NO
<a href="#">U</a>	Axis U position	NO	NO
<a href="#">V</a>	Axis V position	NO	NO
<a href="#">W</a>	Axis W position	NO	NO
<a href="#">QX</a>	Channel 0 position	NO	NO
<a href="#">QY</a>	Channel 1 position	NO	NO
<a href="#">QZ</a>	Channel 2 position	NO	NO
<a href="#">QA</a>	Channel 3 position	NO	NO
<a href="#">QB</a>	Channel 4 position	NO	NO
<a href="#">QC</a>	Channel 5 position	NO	NO
<a href="#">QU</a>	Channel 6 position	NO	NO
<a href="#">QV</a>	Channel 7 position	NO	NO
<a href="#">QW</a>	Channel 8 position	NO	NO
<a href="#">DX</a>	Axis X relative position	NO	NO
<a href="#">DY</a>	Axis Y relative position	NO	NO
<a href="#">DZ</a>	Axis Z relative position	NO	NO
<a href="#">DA</a>	Axis A relative position	NO	NO
<a href="#">DB</a>	Axis B relative position	NO	NO
<a href="#">DC</a>	Axis C relative position	NO	NO
<a href="#">DU</a>	Axis U relative position	NO	NO



<a href="#"><u>DV</u></a>	Axis W relative position	NO	NO
<a href="#"><u>DW</u></a>	Axis W relative position	NO	NO
<a href="#"><u>OX</u></a>	Set Origin number for axis X	NO	NO
<a href="#"><u>OY</u></a>	Set Origin number for axis Y	NO	NO
<a href="#"><u>OZ</u></a>	Set Origin number for axis Z	NO	NO
<a href="#"><u>OA</u></a>	Set Origin number for axis A	NO	NO
<a href="#"><u>OB</u></a>	Set Origin number for axis B	NO	NO
<a href="#"><u>OC</u></a>	Set Origin number for axis C	NO	NO
<a href="#"><u>OU</u></a>	Set Origin number for axis U	NO	NO
<a href="#"><u>OV</u></a>	Set Origin number for axis V	NO	NO
<a href="#"><u>OW</u></a>	Set Origin number for axis W	NO	NO
<a href="#"><u>DOX</u></a>	Origin Offset fo axis X	NO	NO
<a href="#"><u>DOY</u></a>	Origin Offset fo axis Y	NO	NO
<a href="#"><u>DOZ</u></a>	Origin Offset fo axis Z	NO	NO
<a href="#"><u>DOA</u></a>	Origin Offset fo axis A	NO	NO
<a href="#"><u>DOB</u></a>	Origin Offset fo axis B	NO	NO
<a href="#"><u>DOC</u></a>	Origin Offset fo axis C	NO	NO
<a href="#"><u>DOU</u></a>	Origin Offset fo axis U	NO	NO
<a href="#"><u>DOV</u></a>	Origin Offset fo axis V	NO	NO
<a href="#"><u>DOW</u></a>	Origin Offset fo axis W	NO	NO
<a href="#"><u>F</u></a>	Axis FEED	NO	NO
<a href="#"><u>S</u></a>	Spinale speed	YES	YES
<a href="#"><u>N</u></a>	Line number (optional)	NO	NO
<a href="#"><u>D</u></a>	Tool diameter	NO	NO
<a href="#"><u>M</u></a>	M function	YES	YES
<a href="#"><u>HM</u></a>	HM function	YES	YES
<a href="#"><u>H</u></a>	Select head	NO	NO
<a href="#"><u>T</u></a>	Select tool	NO	NO
<a href="#"><u>I</u></a>	CENTER X coordinate for G2 G3	NO	NO
<a href="#"><u>J</u></a>	CENTER Y coordinate for G2 G3	NO	NO
<a href="#"><u>K</u></a>	CENTER Z coordinate for G2 G3 (optional)	NO	NO
<a href="#"><u>R</u></a>	Radius for G2 G3	NO	NO
<a href="#"><u>USER_ZERO</u></a>	Index of WORK ORIGIN LIST	NO	NO
<a href="#"><u>USER_OFFSET</u></a>	Index of WORK OFFSET LIST	NO	NO
<a href="#"><u>STOP_MODE</u></a>	Defines the STOP Button function mode	NO	NO
<a href="#"><u>PAUSE_MODE</u></a>	Defines the Pause function mode	NO	NO
<a href="#"><u>FILTER_MODE</u></a>	Defines the Filter function mode	NO	NO

## 4.1 PROGRAM FLOW INSTRUCTIONS

Code	Description	TASK1	TASK2
<a href="#"><u>IF</u></a>	Start IF cycle	YES	YES
<a href="#"><u>ELSE</u></a>	Relative to IF cycle	YES	YES
<a href="#"><u>END_IF</u></a>	End IF cycle	YES	YES
<a href="#"><u>SELECT-CASE</u></a>	Select – Case cycle	YES	YES
<a href="#"><u>LOOP</u></a>	Start LOOP cycle	YES	YES
<a href="#"><u>END_LOOP</u></a>	End LOOP cycle	YES	YES
<a href="#"><u>FOR</u></a>	Start For Cycle	YES	YES
<a href="#"><u>NEXT</u></a>	End For Cycle	YES	YES
<a href="#"><u>BREAK</u></a>	Break FOR or WHILE	YES	YES
<a href="#"><u>CONTINUE</u></a>	Continue FOR or WHILE	YES	YES
<a href="#"><u>WHILE</u></a>	Start WHILE Cycle	YES	YES
<a href="#"><u>END_WHILE</u></a>	End WHILE	YES	YES
<a href="#"><u>GOTO</u></a>	Jump to LABEL or line number	YES	YES
<a href="#"><u>GOSUB</u></a>	Call of Soubrutine	YES	YES
<a href="#"><u>RETURN</u></a>	Retrun from Soubrutine	YES	YES
<a href="#"><u>@</u></a>	LABEL definition	YES	YES
<a href="#"><u>//</u></a>	Start remarks	YES	YES
<a href="#"><u>END_PROGRAM</u></a>	End of program	YES	YES
<a href="#"><u>WAIT_INPUT</u></a>	Wait of digital input with Time Out	YES	YES
<a href="#"><u>TWAIT_INPUT</u></a>	Wait of digital input with Time Out and with state time	YES	YES
<a href="#"><u>ERROR</u></a>	Force stop program with error	YES	YES

## 4.2 MULTI TASK INSTRUCTIONS

Code	Description	TASK1	TASK2
<a href="#"><u>TASK.RUN</u></a>	Run TASK	YES	YES
<a href="#"><u>TASK.STOP</u></a>	Stop TASK	YES	YES
<a href="#"><u>TASK.PAUSE</u></a>	Pause TASK	YES	YES
<a href="#"><u>TASK.READVAR</u></a>	Read Variable from TASK	YES	YES
<a href="#"><u>TASK.WRITEVAR</u></a>	Write variable to TASK	YES	YES
<a href="#"><u>TASK.STATUS</u></a>	Read status TASK	YES	YES
<a href="#"><u>TASK.LOADCMD</u></a>	Load CMD in the TASK	YES	YES
<a href="#"><u>TASK.PRIORITY</u></a>	Set priority TASK	YES	YES
<a href="#"><u>USTASK</u></a>	Start Gcode Section for TASK1	NO	NO
<a href="#"><u>ENDUSTASK</u></a>	End Gcode section for TASK1	NO	NO

## 4.3 GENERIC INSTRUCTIONS

Code	Description	TASK1	TASK2
<a href="#"><u>SDO_DL</u></a>	Sdo download (can open)	YES	YES
<a href="#"><u>SDO_UL</u></a>	Sdo upload (can open)	YES	YES
<a href="#"><u>GET</u></a>	Read parameter of HM function	YES	YES
<a href="#"><u>READ_PARMAC</u></a>	Read machine parameter	YES	YES
<a href="#"><u>WRITE_PARMAC</u></a>	Write machine parameter	YES	YES
<a href="#"><u>LOAD_VAR</u></a>	Load a file of variable	YES	YES
<a href="#"><u>GET_VAR</u></a>	Read a variable from loaded file	YES	YES
<a href="#"><u>WRITE_VAR</u></a>	Write a variable in memory list	YES	YES
<a href="#"><u>SAVE_VAR</u></a>	Save a file of variable on harddisk	YES	YES
<a href="#"><u>DIM_VAR</u></a>	Set dimension of memory list	YES	YES
<a href="#"><u>FILE_EXISTS</u></a>	Check if file exists	YES	YES
<a href="#"><u>REMOVE_VAR</u></a>	Remove a value from current list	YES	YES
<a href="#"><u>CLEAR_VAR</u></a>	Remove ALL values from current list	YES	YES
<a href="#"><u>OPT</u></a>	Compiler option	YES	YES
<a href="#"><u>IMPORT</u></a>	Import external file	NO	NO
<a href="#"><u>END_IMPORT</u></a>	End of Import program	NO	NO
<a href="#"><u>PA(n,par)</u></a>	Set ABSOLUTE target positioner	YES	YES
<a href="#"><u>PD(n,par)</u></a>	Set REALTIVE target positioner	YES	YES
<a href="#"><u>PF(n)</u></a>	Set FEED positioner	YES	YES
<a href="#"><u>PS(n)</u></a>	STOP positioner	YES	YES
<a href="#"><u>PM(n,par)</u></a>	STATUS positioner	YES	YES
<a href="#"><u>RESUME_T</u></a>	Resume the PartProgram from last instruction Tn used	NO	NO
<a href="#"><u>DIM</u></a>	ARRAY management	YES	YES
<a href="#"><u>DEBUG_INFO</u></a>	Write informations in Log file	YES	YES
<a href="#"><u>SET_TABPAR</u></a>	Set a Parameters Table	YES	YES
<a href="#"><u>SAVE_T</u></a>	Save the tools table in the Isous cfg	YES	YES
<a href="#"><u>IF_RUN</u></a>	Check NORMAL Run Type (\$[X7]=0)	YES	YES
<a href="#"><u>IF_NOTRUN</u></a>	Check SIMULATED Run Type (\$[X7]<>0)	YES	YES
<a href="#"><u>USEFORM</u></a>	Open a Form compiled by UsFormManager	YES	YES

#### 4.4 MATH AND LOGICAL OPERATORS

Code	Description	TASK1	TASK2
+	Addiction	YES	YES
-	Subtraction	YES	YES
*	Multiplication	YES	YES
/	Division	YES	YES
(	Open bracket	YES	YES
)	Cosed bracket	YES	YES
[	Start expresion for axis count ex: G1X[\$var+\$var1]	YES	YES
]	End expresion for axis count ex: G1X[\$var+\$var1]	YES	YES
^	POW	YES	YES
%	XOR	YES	YES
>	Greater	YES	YES
<	Less	YES	YES
>=	Greater or equal	YES	YES
<=	Less or equal	YES	YES
<>	Not equal	YES	YES
=	Equal	YES	YES
	Logic Or	YES	YES
&&	Logic And	YES	YES
	Or Bit	YES	YES
&	And Bit	YES	YES
!	Negate	YES	YES
~	Not Bit	YES	YES
>>	Shift bit right	YES	YES
<<	Shift bit left	YES	YES
<b>\$VAR++</b> <b>:xxx++</b>	\$VAR=\$VAR+1 :1000=:1000+1	SI	SI
<b>\$VAR--</b> <b>:xxx--</b>	\$VAR=\$VAR-1 :1000=:1000-1	SI	SI
<b>\$VAR+=</b> <b>:xxx+=</b>	\$VAR=\$VAR+exp :1000=:1000+exp	SI	SI
<b>\$VAR-=</b> <b>:xxx-=</b>	\$VAR=\$VAR-exp :1000=:1000-exp	SI	SI
<b>\$VAR*= :xxx*=</b>	\$VAR=\$VAR*exp :1000=:1000*exp	SI	SI
<b>\$VAR/=</b> <b>:xxx/=</b>	\$VAR=\$VAR/exp :1000=:1000/exp	SI	SI

## 4.5 MATH FUNCTIONS

Code	Description	TASK1	TASK2
<a href="#"><u>SIN</u></a>	Sinus	YES	YES
<a href="#"><u>COS</u></a>	Cosinus	YES	YES
<a href="#"><u>LOG</u></a>	Logarithm	YES	YES
<a href="#"><u>EXP</u></a>	Exponetial	YES	YES
<a href="#"><u>SQR</u></a>	Square root	YES	YES
<a href="#"><u>TAN</u></a>	Tangent	YES	YES
<a href="#"><u>ATAN</u></a>	Arctangent	YES	YES
<a href="#"><u>ASIN</u></a>	Arcsinus	YES	YES
<a href="#"><u>ACOS</u></a>	Arccos	YES	YES
<a href="#"><u>INT</u></a>	Integer part of float rounded	YES	YES
<a href="#"><u>FIX</u></a>	Integer part of float whitout rounded	YES	YES
<a href="#"><u>ABS</u></a>	Absolute value	YES	YES
<a href="#"><u>DRG</u></a>	Set degrees for COS,SIN,TAN,ACOS,ASIN,ATAN	YES	YES
<a href="#"><u>RAD</u></a>	Set radiants for COS,SIN,TAN,ACOS,ASIN,ATAN	YES	YES

## 4.6 VARIABLES and CONSTANTS

Code	Description	TASK1	TASK2
<a href="#"><u>NUMBER</u></a>	Numeric constant ex: 432.12	YES	YES
<a href="#"><u>\$VARNAME</u></a>	Generic double value ex: \$VAR1	YES	YES
<a href="#"><u>\$STRUCT.VAR</u></a>	Data Structures	YES	YES
<a href="#"><u>:Addr</u></a>	Variable for Address	YES	YES
<a href="#"><u>:\$VAR</u></a>	Variable for pointer	YES	YES
<a href="#"><u>\$(Qn)</u></a>	Demand axis position ex: \$(Q0) - \$(Q100)	YES	YES
<a href="#"><u>\$(Rn)</u></a>	Actual axis position ex: \$(R0) - \$(R100)	YES	YES
<a href="#"><u>\$(In)</u></a>	Digital input ex: \$(I10)	YES	YES
<a href="#"><u>\$(On)</u></a>	Digital output ex: \$(O10)	YES	YES
<a href="#"><u>\$(Tn)</u></a>	TIMER ex: \$(T3)	YES	YES
<a href="#"><u>\$(Un)</u></a>	Tool parameter ex: \$(U12)	YES	YES
<a href="#"><u>\$(Cn)</u></a>	Axis counter ex: \$(C0)	YES	YES
<a href="#"><u>\$(Hn)</u></a>	Head parameter ex: \$(H1)	YES	YES
<a href="#"><u>\$(Xn)</u></a>	Special parameters Variables ex: \$(X1)	YES	YES
<a href="#"><u>\$(Yn)</u></a>	Work origin position ex: \$(Y0)	YES	YES
<a href="#"><u>\$(Wn)</u></a>	Work offset position ex: \$(W0)	YES	YES
<a href="#"><u>\$(Kn)</u></a>	User generic on CN	YES	YES
<a href="#"><u>\$(En)</u></a>	Positive Software limit axis set	YES	YES
<a href="#"><u>\$(Pn)</u></a>	Preview Parameters	YES	YES
<a href="#"><u>\$(Sn)</u></a>	Negative Software limit axis set	YES	YES
<a href="#"><u>\$(A0)</u></a>	Write Analog Out for SPINDLE	YES	YES
<a href="#"><u>\$(Jn)</u></a>	Macro and Gcode parameters Management	YES	YES

## 4.7 PREDEFINED VARIABLES

Code	Description	TASK1	TASK2
<a href="#"><u>\$ PARM 1</u></a>	Parameter 1 for M function	YES	YES
<a href="#"><u>\$ PARM 2</u></a>	Parameter 2 for M function	YES	YES
<a href="#"><u>\$ PARM 3</u></a>	Parameter 3 for M function	YES	YES
<a href="#"><u>\$ PARM 4</u></a>	Parameter 4 for M function	YES	YES
<a href="#"><u>\$ PARM 5</u></a>	Parameter 5 for M function	YES	YES

## 4.8 UsForms INSTRUCTIONS

Code	Description	TASK1	TASK2
<a href="#"><u>LIB.MESSAGE</u></a>	Show Message Box	NO	NO
<a href="#"><u>LIB.SHOWFORM</u></a>	Show NsForm	NO	NO
<a href="#"><u>LIB.CLOSEFORM</u></a>	Close NsForm	NO	NO
<a href="#"><u>LIB.FORMPROP</u></a>	Set Property NsForm	NO	NO
<a href="#"><u>LIB.FORMTEXT</u></a>	Set Caption NsForm	NO	NO
<a href="#"><u>LIB.ADDLABEL</u></a>	Add a NsLabel to NsForm	NO	NO
<a href="#"><u>LIB.LABELPROP</u></a>	Set NsLabel Property	NO	NO
<a href="#"><u>LIB.LABELTEXT</u></a>	Set Text NsLabel	NO	NO
<a href="#"><u>LIB.LABELPRINT</u></a>	Print Isous Variable to NsLabel	NO	NO
<a href="#"><u>LIB.LABELF</u></a>	Set Format for print from TIMER	NO	NO
<a href="#"><u>LIB.ADDBUTTON</u></a>	Add a NsButton to NsForm	NO	NO
<a href="#"><u>LIB.BUTTONPROP</u></a>	Set NsButton Property	NO	NO
<a href="#"><u>LIB.BUTTONTEXT</u></a>	Set Text NsButton	NO	NO
<a href="#"><u>LIB.BUTTONPRINT</u></a>	Print Isous Variable to NsButton	NO	NO
<a href="#"><u>LIB.BUTTONF</u></a>	Set Format for print from TIMER	NO	NO
<a href="#"><u>LIB.ADDINPUT</u></a>	Add a NsInput Object to NsForm	NO	NO
<a href="#"><u>LIB.INPUTPROP</u></a>	Set NsInput Property	NO	NO
<a href="#"><u>LIB.INPUTSETVALUE</u></a>	Set NsInput init value	NO	NO
<a href="#"><u>LIB.ADDITEXT</u></a>	Add ITEXT Object to NsForm	NO	NO
<a href="#"><u>LIB.ITEXTPROP</u></a>	Set ITEXT Property	NO	NO
<a href="#"><u>LIB.ITEXTSETVALUE</u></a>	Set ITEXT init value	NO	NO
<a href="#"><u>LIB.ADDCHECK</u></a>	Add CHECK Object to NsForm	NO	NO
<a href="#"><u>LIB.CHECKPROP</u></a>	Set CHECK Property	NO	NO
<a href="#"><u>LIB.CHECKSETVALUE</u></a>	Set CHECK init value	NO	NO
<a href="#"><u>LIB.CHECKTEXT</u></a>	Set caption of CHECK	NO	NO
<a href="#"><u>LIB.ADDCOMBO</u></a>	Add COMBO Object to NsForm	NO	NO
<a href="#"><u>LIB.COMBOPROP</u></a>	Set COMBO Property	NO	NO
<a href="#"><u>LIB.COMBOSETVALUE</u></a>	Set COMBO init value	NO	NO
<a href="#"><u>LIB.COMBOITEM</u></a>	Add an ITEM to COMBO	NO	NO
<a href="#"><u>LIB.ADDSLIDER</u></a>	Add SLIDER Object to NsForm	NO	NO
<a href="#"><u>LIB.SLIDERPROP</u></a>	Set SLIDER Property	NO	NO
<a href="#"><u>LIB.SLIDERSETVALUE</u></a>	Set SLIDER init value	NO	NO
<a href="#"><u>LIB.GETVAR</u></a>	Read a Form Variable	NO	NO
<a href="#"><u>LIB.SETVAR</u></a>	Write a Form Variable	NO	NO
<a href="#"><u>LIB.DEBUG</u></a>	Write a Debug Gcode informations	NO	NO

## 4.9 EXTENDED INSTRUCTIONS EXD

Code	Description	TASK1	TASK2
<a href="#">EXD.STL_LOAD</a>	Load STL file in Preview	YES	YES
<a href="#">EXD.READ_TOOLPAR</a>	Read Tool Table Parameter	YES	YES
<a href="#">EXD.READ_HEADPAR</a>	Read Head Table Parameter	YES	YES
<a href="#">EXD.WRITE_TOOLPAR</a>	Write Tool Table Parameter	YES	YES
<a href="#">EXD.WRITE_HEADPAR</a>	Write Head Table Parameter	YES	YES
<a href="#">EXD.LOAD_LAST</a>	Load the Last Tool Used	YES	YES
<a href="#">EXD.SAVE_LAST</a>	Save the current use as Last Tool used	YES	YES
<a href="#">EXD.RESET_LAST</a>	Reset the Last Tool used file	YES	YES
<a href="#">EXD.SET_OUT</a>	Set/Reset digital output by address - $\$(On)$	YES	YES
<a href="#">EXD.READ_OUT</a>	Read digital output by address - $\$(On)$	YES	YES
<a href="#">EXD.READ_INP</a>	Read digital input by address - $\$(In)$	YES	YES
<a href="#">EXD.WRITE_USER</a>	Write User Generic by address - $\$(Kn)$	YES	YES
<a href="#">EXD.READ_USER</a>	Read User Generic by address - $\$(Kn)$	YES	YES
<a href="#">EXD.READ_DEMAND</a>	Read Axis Demand Position by address - $\$(Qn)$	YES	YES
<a href="#">EXD.READ_REAL</a>	Read Axis Real Position by address - $\$(Rn)$	YES	YES
<a href="#">EXD.MASK</a>	Set Digital Output MASK	YES	YES
<a href="#">EXD.WRITE_BIT</a>	Set/Reset Bit of Variable	YES	YES
<a href="#">EXD.READ_BIT</a>	Read Bit of Variable	YES	YES
<a href="#">EXD.PXV_ALL_DETECTORS</a>	Read all detectors of PXV System	YES	YES
<a href="#">EXD.PXV_SINGLE_DETECTOR</a>	Read a single detector of PXV System	YES	YES
<a href="#">EXD.PXV_READ_PROBE</a>	Read a PROBE of PXV System	YES	YES
<a href="#">EXD.PXV_RESET_PROBE</a>	Reset a PROBE of PXV System	YES	YES
<a href="#">EXD.PXV_SET_DETECTOR</a>	Set Detector Type of PXV System	YES	YES
<a href="#">EXD.PXV_SAVE_IMAGE</a>	Save the current image acquired in PXV	YES	YES
<a href="#">EXD.PXV_GET_IMAGE</a>	Capture an Image from PXV	YES	YES
<a href="#">EXD.PXV_SET_JOB</a>	Set PXV Job configuration File	YES	YES
<a href="#">EXD.RUN_SCRIPT</a>	Execute a C# SCRIPT	YES	YES
<a href="#">EXD.OPEN_DLL</a>	Open UsDLL .NET	YES	YES
<a href="#">EXD.CALL_DLL</a>	Call UsDLL .NET	YES	YES
<a href="#">EXD.CLOSE_DLL</a>	Close UsDLL .NET	YES	YES
<a href="#">EXD.SYNK_DLL</a>	Synk UsDLL .NET	YES	YES
<a href="#">EXD.STL_SETVIS</a>	Show or Hide STL by Name	YES	YES
<a href="#">EXD.STL_READVIS</a>	Read the STL Visibility by Name	YES	YES
<a href="#">EXD.STL_SETVISIDX</a>	Show or Hide STL by Address	YES	YES
<a href="#">EXD.STL_READVISIDX</a>	Read the STL Visibility by Address	YES	YES



#### 4.10 Compiler Switch and Directive

Code	Description	TASK1	TASK2
<a href="#"><u>IFDEF</u></a>	Compiler Switch IF	YES	YES
<a href="#"><u>ELSEDEF</u></a>	Compiler Switch ELSE	YES	YES
<a href="#"><u>ENDIFDEF</u></a>	Compiler Switch ENDIF	YES	YES
<a href="#"><u>NOAXESREADY</u></a>	Compiler directive Axes not Ready	YES	YES
<a href="#"><u>ONERROR</u></a>	Compiler directive On Error	YES	YES
<a href="#"><u>ONSTOP</u></a>	Compiler directive On Stop	YES	YES
<a href="#"><u>ENDON</u></a>	Compiler directive End On	YES	YES
<a href="#"><u>USET</u></a>	Compiler directive Use T	YES	YES
<a href="#"><u>USEH</u></a>	Compiler directive Use H	YES	YES

## 4.11 INSTRUCTIONS for remote controls

Code	Description	TASK1	TASK2
<a href="#"><u>REMOTE.LOAD</u></a>	Load Gcode in Remote CN	YES	YES
<a href="#"><u>REMOTE.RUN</u></a>	Run Gcode in Remote CN	YES	YES
<a href="#"><u>REMOTE.STOP</u></a>	Stop Gcode in Remote CN	YES	YES
<a href="#"><u>REMOTE.PAUSE</u></a>	Pausa Gcode in Remote CN	YES	YES
<a href="#"><u>REMOTE.STATUS</u></a>	Read Status Gcode in Remote CN	YES	YES
<a href="#"><u>REMOTE.MOVE</u></a>	Read Axes Mov in Remote CN	YES	YES
<a href="#"><u>REMOTE.INFO</u></a>	Read Info in Remote CN	YES	YES
<a href="#"><u>REMOTE.AXIS</u></a>	Read Axis value in Remote CN	YES	YES
<a href="#"><u>REMOTE.GROUP</u></a>	Read Axes Values in Remote CN	YES	YES
<a href="#"><u>REMOTE.READISOVAR</u></a> <a href="#"><u>REMOTE.READVARNAME</u></a>	Read Gcode Variable in Remote CN	YES	YES
<a href="#"><u>REMOTE.WRITEISOVAR</u></a> <a href="#"><u>REMOTE.WRITEVARNAME</u></a>	Write Gcode Variable in Remote CN	YES	YES
<a href="#"><u>REMOTE.READCNVAR</u></a>	Read User Generic variable in Remote CN	YES	YES
<a href="#"><u>REMOTE.WRITECNVAR</u></a>	Write User Generic variable in Remote CN	YES	YES
<a href="#"><u>REMOTE.READINPUT</u></a>	Read Digital Input in Remote CN	YES	YES
<a href="#"><u>REMOTE.READOUT</u></a>	Load Gcode in Remote CN	YES	YES
<a href="#"><u>REMOTE.WRITEOUT</u></a>	Run Gcode in Remote CN	YES	YES

## 4.12 INSTRUCTIONS for Multi Process Control

Code	Description	TASK1	TASK2
<a href="#"><u>CNC.LOAD</u></a>	Load Part Program On CN Process	YES	YES
<a href="#"><u>CNC.RUN</u></a>	Run Part Program On CN Process	YES	YES
<a href="#"><u>CNC.PREVIEW</u></a>	Preview Part Program On CN Process	YES	YES
<a href="#"><u>CNC.STOP</u></a>	Stop Part Program On CN Process	YES	YES
<a href="#"><u>CNC.PAUSE</u></a>	Pause Part Program On CN Process	YES	YES
<a href="#"><u>CNC.STATUS</u></a>	Read Status On CN Process	YES	YES
<a href="#"><u>CNC.STATUSBIT</u></a>	Read Status bit On CN Process	YES	YES
<a href="#"><u>CNC.INFO</u></a>	Read Informations On CN Process	YES	YES
<a href="#"><u>CNC.AXIS</u></a>	Read Axes Values On CN Process	YES	YES
<a href="#"><u>CNC.GROUP</u></a>	Read Group Axes Values On CN Process	YES	YES
<a href="#"><u>CNC.READVARADDR</u></a> <a href="#"><u>CNC.READVARNAME</u></a>	Read Gcode Variable On CN Process	YES	YES
<a href="#"><u>CNC.WRITEVARADDR</u></a> <a href="#"><u>CNC.WRITEVARNAME</u></a>	Write Read Gcode Variable On CN Process	YES	YES
<a href="#"><u>CNC.READPARAMAC</u></a>	Read Machine Parameter On CN Process	YES	YES
<a href="#"><u>CNC.WRITEPARAMAC</u></a>	Write Machine Parameter On CN Process	YES	YES
<a href="#"><u>CNC.ENABLEAXIS</u></a>	Enable Axis On CN Process	YES	YES
<a href="#"><u>CNC.HOMEAXIS</u></a>	Homing Axis On CN Process	YES	YES
<a href="#"><u>CNC.READGENERIC</u></a>	Read Generic Variable On CN Process	YES	YES
<a href="#"><u>CNC.WRITEGENERIC</u></a>	Write Generic Variable On CN Process	YES	YES

## 5 PROGRAM FLOW

Isous allows programming with an extension of standard ISO code. The adding instruction to control the program flow are BASIC style increasing programming performance. Therefore it's possible to manage conditional cycles, iterative cycles, jumps to labels, etc.

### 5.1 IF-ELSE-END\_IF

It allows conditional execution of an instructions block depending of the result of expression. IF cycles can be nested without limits.

#### Syntax

```
IF condition
    [instr. true]
ELSE
    [instr. false]
END_IF
```

**condition** Mandatory. Any numeric expression with a result of True or False.

**Instr. true** Instructions block executed if condition is TRUE

**Instr. false** Optional. Instructions block executed if condition is FALSE

**END\_IF** End of **IF ELSE** cycle

Ex:

```
IF $VAR=$VAR2*15+($VAR4+18)
    $VAR1=10
    G1X10Y20
ELSE
    $VAR1=0
    G1X0Y0
END_IF
```

### 5.2 LOOP - END\_LOOP

Iterative cycle of the program. Instructions inside LOOP END\_LOOP cycle are executed a number of time depended of expression result. LOOP cycles can be nested without limits.

#### Syntax

```
LOOP variable K
    [instructions]
END_LOOP
```

**variable** Mandatory. Any variable type \$name or numeric value

**K** Optional – If it is insert, in preview only one time (LOOP 100 K)

**Instructions** Instructions block executed in each cycle

**END\_LOOP** End of **LOOP** cycle

Ex:

```
G91
$VAR=20+($VAR1*5)
LOOP $VAR
    G1X1.3Y1.2
    IF $VAR1=20
        GOTO EXIT_LOOP // FORCED EXIT FROM LOOP
    END_IF
END_LOOP
@EXIT_LOOP
```

## FOR – NEXT – BREAK - CONTINUE

Cycle FOR-NEXT

Iterative cycle of the program. Instructions inside FOR NEXT cycle are executed a number of time depended of expression result.

### Syntax

**FOR** InitFor;CondFor;IterFor

[instructions]

BREAK

CONTINUE

### NEXT

<b>InitFor</b>	Mandatory .Initialization Variable of For cycle
<b>CondFor</b>	Mandatory – Condition FOR cycle – Continue If condition is TRUE
<b>IterFor</b>	Mandatory – Values of increase/decrease Condition Variable
<b>Instructions</b>	Instructions block executed in each cycle
<b>BREAK</b>	Break For cycle
<b>CONTINUE</b>	Jump to next iteration
<b>NEXT</b>	End <b>FOR</b>

Ex:

```
G0X0Y0
$VAR1=0
$VAR2=0
$VAR3=0
$VAR4=0
FOR $V=0;$V<20;$V+=2
  G0X[$VAR1]Y[$VAR2]
  G4F0.5
  $VAR1+=10
  $VAR2+=20
  $VAR+=4
  IF$VAR<20
    CONTINUE
  END_IF
  IF$VAR4=200
    BREAK
  END_IF
  FOR $V1=0;$V1<100;$V1++
    $VAR3+=1
  NEXT
NEXT
```

## WHILE – END\_WHILE – BREAK - CONTINUE

Cycle WHILE-END\_WHILE

Iterative cycle of the program. Instructions inside WHILE END\_WHILE cycle are executed a number of time depended of expression result.

### Syntax

#### WHILE CondWhile

[instructions]

BREAK

CONTINUE

#### END\_WHILE

**CondWhile** Mandatory – Condition WHILE cycle – Continue If condition is TRUE

**Instructions** Instructions block executed in each cycle

**BREAK** Break While cycle

**CONTINUE** Jump to next iteration

**END\_WHILE** End **WHILE**

Es:

```

GOX100
$VAR1=10
$VAR=0
$VAR3=0
$VAR4=5
WHILE $VAR<$VAR1
  $VAR++
  WHILE $VAR3<200
    IF $VAR3=204
      BREAK
    END_IF
    $VAR3++
  END_WHILE
  IF $VAR4=10
    CONTINUE
  END_IF
END_WHILE
GOX200

```

### 5.3 GOTO

Unconditional jump to a label or line number identified by Nxx

#### Syntax

**GOTO** labelname

**GOTO** @linenumber

**labelname** Mandatory. A label of program defined with @labelname

**@linenumber** Line number identified by Nxx. **if LineNumber = -1 restart the Partprogram**

Ex:

```

IF $VAR1=0
    GOTO CYCLE_A
END_IF
IF $VAR1=1
    GOTO @100 // GOTO @-1 JUMP TO BEGIN
END_IF
// EXECUTE CYCLE A
@ CYCLE_A
G1X100Y100
.....
.....
// EXECUTE CYCLE B
N100G1X10Y10

```

### 5.4 GOSUB – RETURN

Jump to and return from a subroutine defined by a label.

#### Syntax

**GOSUB** labelname

**GOSUB** @linenumber

**labelname** Mandatory. A label of program defined with @labelname

**@linenumber** Line number identified by Nxx

**it is mandatory that an instructions block which start with label, must to end with a RETURN**

Ex:

```

IF $VAR1=0
    GOSUB CYCLE_A
END_IF
IF $VAR1=1
    GOSUB @100
END_IF
// EXECUTE CYCLE A
@ CYCLE_A
G1X100Y100
RETURN
// EXECUTE CYCLE B
N100G1X10Y10
RETURN

```

## 5.5 LABEL

A LABEL defines a jump point that can be use with GOTO e GOSUB. It isn't possible to have two or more LABEL with the same name, because it can cause a system conflict.

LABELS are exclusive for every PART PROGRAM, therefore ISOUS defines as private the LABELS that will be found in M or HM functions, so they don't have any effect in the PART PROGRAM.

It's a good thing to have LABEL with relevant names.

### Syntax

@labelname

**@** Mandatory. Identifier of LABEL  
**labelname** Mandatory. Unique name of the label  
 All characters excluded math and logic operator are allowed

### Ex:

```
@ CYCLE_A
G1X100Y100
.....
.....
@ CYCLE_B
G1X10Y10
```

## 5.6 END\_PROGRAM

It forces an end of program. Isous inserts automatically this instruction at end of program list (end of file). However in some cases it can be necessary to end program in a particular point other than end of file.

### Syntax

END\_PROGRAM

### Ex:

```
IF $VAR1=0
    END_PROGRAM // END PROGRAM IN PREMATURE MODE
END_IF
```

## 5.7 WAIT\_INPUT

It waits a digital input for a programmed time. If time elapses without input is active it is possible stop the program reporting an ALARM.

### Syntax

**WAIT\_INPUT** Input State Timeout Alarm

**Input** Mandatory. Digital input number from 0 to 255  
**State** Mandatory. Logic state of input to continue the program (0 = OFF state , 1 = ON state)  
**Timeout** Time in sec. (0.1 resolution). If time elapses it's possible to signal an alarm stopping the PartProgram  
**TIME=0 infinite wait**  
**Alarm** Generated alarm code (refer to configuration file)  
 0 = No allarm generated

### Ex:

```
WAIT_INPUT 2 1 5.3 12 // Wait input 2 at logic state ON for 5.3 sec. and
// signal alarm 12 if condition is not happen
```



## 5.8 TWAIT\_INPUT

It waits a digital input for a programmed time Out and for a state time valid. If time elapses without input is active for a time valid it is possible stop the program reporting an ALARM.

### Syntax

**TWAIT\_INPUT** Input State TimeState Timeout Alarm

**Input** Mandatory. Digital input number from 0 to 255

**State** Mandatory. Logic state of input to continue the program (0 = OFF state , 1 = ON state)

**TimeState** TimeState in sec. (0.1 resolution). The input must be in the programmed state for this time


**TIME=0 like to WAIT\_INPUT**

**Timeout** Time in sec. (0.1 resolution). If time elapses it's possible to signal an alarm stopping the PartProgram

**TIME=0 infinite wait**

**Alarm** Generated alarm code (refer to configuration file)

0 = No allarm generated



Ex:

```
TWAIT_INPUT 2 1 2 5.3 12 // Wait input 2 at logic state ON Tstate 2 sec for 5.3 sec. and
// signal alarm 12 if condition is not happen
```

## 5.9 ERROR

It cause an exit from PartProgram reporting an error. This instruction is useful to generate exceptions of PartProgram at events occurrences. Execution is stopped with an alarm.

### Syntax

**ERROR** err\_code

**err\_code** Mandatory. Error code (refer to configuration file).

Ex:

```
IF $VAR1=0
  ERROR 10      // STOP PARTPROGRAM WITH ALLARM 10
END_IF
```

## 5.10 RESUME\_T

Resumes the part program from the last statement used Tn.

It is used for tool management Damaged. In practice, when the measurement tool detects that the tool is damaged, through **RESUME\_T** you can redo the work from last tool change made.

The parameter that follows **RESUME\_T** is the tool alternative to that Damaged. This parameter is taken from the table tools.

### Syntax

**RESUME\_T** Tool\_nr

**Tool\_nr** Alternative Tool Number

## 5.11 SAVE\_T

Saves the tools table in Isous cfg file.

With PartProgram is possible modify the tools table value. **SAVE\_T** saves in permanent mode the modify.

### Syntax

**SAVE\_T**

```
T1 // SELECTED T1
${U0}=10 // WRITE TOOL DIAMETER INDEX TABLE 0
${U1}=100.3 // WRITE TOOL LENGHT INDEX TABLE 1
SAVE_T // SAVE THE TOOLS TABLE
```

## 5.12 SET\_TABPAR

Set a Parameter Table and activates the parameters values of the table.

The parameters Tables are generated by IsoUs configurator, and these contain a copy of original machine parameters, but with different values. That allows a dynamic parametrization by Gcode.

**The TABLE 0 contains a copy of DEFAULT PARAMETERS.**

### Syntax

**SET\_PARTAB** Tab\_nr

**Tab\_nr** is the TABLE number to activate. Table 0 original parameters

### 5.13 SELECT – CASE - END\_SELECT

Executes one of different groups of instructions conditioned by value of expression.

#### *Syntax*

#### **SELECT Test Variable**

##### **CASE Exp1**

[Instructions]

##### **CASE Exp2**

[Instructions]

.

.

##### **CASE ELSE**

[Instructions]

#### **END\_SELECT**

<b>SELECT Test Variable</b>	Mandatory must be a variable \$ - Start cycle
<b>CASE Num</b>	Condition True– Value=Num
<b>CASE Exp</b>	Condition True – Value =Exp
<b>CASE Exp1 TO Exp2</b>	Condition True - Values between Exp1 1 and Exp2
<b>CASE Exp1,Exp2,Exp3..</b>	Condition True – Values equal to Exp1, or Exp2,or Exp3, etc.
<b>CASE IF..</b>	Condition True – is evaluated the IF expression
<b>CASE ELSE</b>	Optional. List of Instructions executed if not any Case cycle was True (must be as last condition, before the END_SELECT)
<b>END_SELECT</b>	End Select Cycle

Ex:

```

SELECT $VAR
  CASE 10
  .
  .
  CASE $VAR1
  .
  .
  CASE $VAR2,15,$VAR3
  .
  .
  CASE 20 TO $VAR4
  .
  .
  CASE IF>=$VAR5
  .
  .
  CASE ELSE
  .
  .
END_SELECT

```

### 5.14 IF RUN

Check type of Gcode execution. Condition True **NORMAL** execution.  
Like to **IF \$[X7]=0**

#### *Syntax*

**IF RUN**

..  
..  
..

**END\_IF**

### 5.15 IF NOTRUN

Check type of Gcode execution. Condition True **SIMULATED** execution.  
Like to **IF \$[X7]<>0**

#### *Syntax*

**IF NOTRUN**

..  
..  
..

**END\_IF**

### 5.16 USEFORM

Open a FORM compiled by PlugIn **UsFormManager**

#### *Syntax*

**USEFORM "FORMNAME"**

**FORMNAME** Form Name without extension compiled (folder \Data\_Form)

XS:

**USEFORM "FORM1"**

## 6 GENERIC INSTRUCTIONS

### 6.1 SDO\_DL

CanOpen SDO Down-Load function (refer to CanOpen documentation).  
Write data in a CanOpen node.

#### Syntax

**SDO\_DL** node index subindex len\_data \$var

<b>node</b>	Mandatory. CanOpen node
<b>index</b>	Mandatory. Object index
<b>subindex</b>	Mandatory. Object sub-index
<b>len_data</b>	Mandatory. Length of datas inside \$Var (1 char – 2 int – 4 long)
<b>\$Var</b>	Mandatory. Variable containing data.

#### Ex:

```
// SEND TO NODE 2 AT INDEX 24596 AND SUBIND. 0
// 4 BYTE FROM VARIABLE $VAR1
SDO_DL 2 24596 0 4 $VAR1
```

### 6.2 SDO\_UL

CanOpen SDO Up-Load function (refer to CanOpen documentation).  
Read data in a CanOpen node.

#### Syntax

**SDO\_UL** node index subindex len\_data \$var

<b>node</b>	Mandatory. CanOpen node
<b>index</b>	Mandatory. Object index
<b>subindex</b>	Mandatory. Object sub-index
<b>len_data</b>	Mandatory. Length of datas inside \$Var (1 char – 2 int – 4 long)
<b>\$Var</b>	Mandatory. Variable where data will be write

#### Ex:

```
// READ FROM NODE 2 AT INDEX 24596 AND SUBIND. 0
// 4 BYTE WRITED IN VARAIBLE $VAR1
SDO_UL 2 24596 0 4 $VAR1
```

### 6.3 GET

Read parameter for HM function

**ATTENTION: PARAMETERS ARE IN REVERSE ORDER COMPARED TO HOW THEY WERE WRITED**

#### Ex:

```
HM 10 20 30 40
..
GET $PAR1 $PAR2 $PAR3 $PAR4 // READ PARAMETERS
then
$PAR1=40 $PAR2=30 $PAR3=20 $PAR4=10
```

## 6.4 READ\_PARMAC

Read a machine parameter with name indication.

### Syntax

**READ\_PARMAC** ParName \$var

**ParName** Mandatory. Parameter name to read (ex: VJOG\_X)  
**\$Var** Mandatory. Variable where parameter value will be write

**A runtime error will be generated if “parname” doesn’t exist**

Ex:

**READ\_PARMAC** VJOG\_X \$VAR1

## 6.5 WRITE\_PARMAC

Write a machine parameter with name indication.

### Syntax

**WRITE\_PARMAC** ParName \$var

**ParName** Mandatory. Parameter name to read (ex: VJOG\_X)  
**\$Var** Mandatory. Variable containing value to be write

**A runtime error will be generated if “parname” doesn’t exist**

**ATTENTION: write of parameters can be cause system errors if execute inappropriately**

Ex:

\$VAR1=100

**WRITE\_PARMAC** “VJOG\_X” \$VAR1

## 6.6 OPT

Set the option of compiler for M functions.  
 Change the function M for actual PartProgram

### Syntax

**OPT** Options Value

**Options** Options:

**MSTOP,MSTART,MEND,MGOBLOCK,MGORETRACE,MERROR,MPAUSE,MGOPAUSE**

**Value** New value for M functions

EX:

**OPT MSTOP 10 //M STOP = 10 for actual PartProgram**

**OPT MERROR -1 //Disable M error for actual PartProgram**

## 6.7 PAUSE\_MODE

Defines the way in which CNC must act PAUSE.

The modes are as follows:

<b>0</b>	Normal Mode(Pause Enabled,M Pause Enabled,M Resume Pause Enabled)
<b>1</b>	Pause Enabled, M Pause Enabled, <b><u>M Resume Pause Disabled</u></b>
<b>2</b>	Pause Enabled, <b><u>M pause Disabled</u></b> , M Resume Pause Enabled
<b>3</b>	Pause Enabled, <b><u>M pause Disabled</u></b> , <b><u>M Resume Pause Disabled</u></b>
<b>4</b>	<b><u>PAUSE DISABLED ON CNC</u></b>

### Syntax

**PAUSE\_MODE val**

**Val** Value or expression

Pause\_Mode used to disable or limit the functionality of the PAUSE cycles during some special work: Ex: TOOL CHANGE etc..

## 6.8 FILTER\_MODE

Defines the Filters function G69,G66 and other

The modes are as follows:

<b>0</b>	<b>LOOK AHEAD</b> disabled on IsoUs
<b>1</b>	<b>LOOK AHEAD</b> enabled with last value setted
<b>2</b>	Disabled <b>PAUSE and STOP</b>
<b>3</b>	Enabled <b>PAUSA and STOP</b>
<b>4</b>	Disabled <b>SAVE_T</b> function
<b>5</b>	Enabled <b>SAVE_T</b> function

### Sintassi

**FILTER\_MODE val**

**Val** Valore o espressione

## 6.9 IMPORT

Import an external file with various formats.

The predefined format is ISOUS. If present **NsImportFile.dll** file, this defines the import format.

### Syntax

**IMPORT "filename.ext"**

**filename** It contains the absolute or relative file path.  
 If **FileName** initiates with \$APPPATH,, the file is searched in the folder ISOUS  
 Import generates the events StartImport and EndImport when the file terminated execution  
 The MAIN part program resume execution when Import File is terminated.  
 import multiple files can be nested .

**Ex:**

**IMPORT "\$APPPATH\PROJECT\IMPORT\TESTIMPORT.ISO" // Import from Isous folder**

**IMPORT "C:\FILEIMPORT\TESTIMPORT.ISO" // import from absolute path**

## 6.10 END\_IMPORT

Terminate in anticipated mode a program called from function IMPORT and return to back program calling

### *Syntax*

**END\_IMPORT**

*Ex:*

**IF \$VAR=0**

**END\_IMPORT**

**END\_IF**



## 6.11 STOP\_MODE

Defines the buttons STOP function

The modes are as follows:

- 0** Normal Mode
- 1** The STOP is disabled when the MACRO STOP is in EXECUTION  
This allows to don't INTERRUPT NEVER the MACRO STOP
- 2** Interrupt the MACRO STOP with TWO PRESSIONS of BUTTON STOP  
This allows to INTERRUPT the MACRO STOP, but must be press 2 times the button STOP

### Syntax

**STOP\_MODE** val

Val Value or expression

## 6.12 DEBUG\_INFO

Write informations in the IsoUs\_x.log file for Debug

### Syntax

**DEBUG\_INFO** "TextInfo" \$var

**TextInfo** Mandatory. Text of Informations

**TextInfo** controls some special chars for define the **DEBUG\_INFO** action.

**@** If inserted as **FIRST** char\_of **TextInfo**, the message is inserted in the **Log** file and send also to **Notify** panel.

Ex: **DEBUG\_INFO "@TextInfo" \$var**

**&** If inserted as **FIRST** char\_of **TextInfo** the message is write in the file **\_Us\_DebugInfo.txt**. this file is located in the same folder of IsoUs

Ex: **DEBUG\_INFO "&TextInfo" \$var**

**\$** If inserted as **LAST** char\_of **TextInfo** is generated the event **UsDebugInfo**

Ex: **DEBUG\_INFO "TextInfo\$" \$var**

**\$Var** Mandatory. Variable of Debug can contain more informations.

The variable is printed after the TextInfo

UsDebug --> TextInfo : \$Var

**ATTENTION: TextInfo must be inside "..."**

**\$VAR1=1**

**DEBUG\_INFO "TEST DEBUG INFO" \$VAR1**

## 7 INSTRUCTIONS FOR MANAGEMENT DISPLAY REMOTE HANDWHEEL WHC

### 7.1 LIB.HMESSAGE

Show text on display Remote HandWheel Promax WHC.  
The WHC display has 4 ROW x 20 COL

#### *Syntax*

**LIB.HMESSAGE** "TEXT" DURATION\_TIME

**TEXT** → Text of message

Special characters:

@RCC

WHERE R=Row Number (from 0 to 3)

CC=Col Number (from 0 to 19) the Col Number must have always 2 characters )

Ex: LIB.HMESSAGE "@105TEEXT" 5 Write on Row 1 Col 5

**DURATION\_TIME** → Duration in Sec. of permanency (after this time the text will be deleted)

**LIB.HMESSAGE** "@100TEST TEXT" 5

write "TEST TEX" T Row 1 Col 0 for 5 seconds

## 8 EXTENDED INSTRUCTIONS

### 8.1 EXD.STL\_LOAD

Allows to load a 3D model file STL in the preview. Valid only for **RealMachine** simulation.

**Syntax**

**EXD.STL\_LOAD** "STLNAME" Xval Yval Zval Aval

**STLNAME** STL name (without extension) the file must be saved in the folder \UsMachines\DynamicStl

**X** Optional Center X (if not inserted is used position in MachineSettings )


**Y** Optional Center Y (if not inserted is used position in MachineSettings )

**Z** Optional Center Z (if not inserted is used position in MachineSettings )


**A** Optional Aligement STL: (if not inserted is used position in MachineSettings )

**VALUES FOR A PARAMETER**


**SIDE DOWN**




**SIDE UP**




**SIDE FRONT**





**SIDE BACK**



**SIDE LEFT**



**SIDE RIGHT**




**31) Default defined in XML**

**32) Model Origin – Origin get for STL file**

Ex:

EXD.STL\_LOAD "TEST"



## 8.2 EXD.READ\_TOOLPAR

Allows to read a Tool Table parameter. Like to  $\$(Un)$  but allows to set the Tool Table Index

### Syntax

**EXD.READ\_TOOLPAR** *TabIndex* *ParIndex*  $\$DEST$

*TabIndex*        Table Index (Numeric or Variable)  
*ParIndex*        Parameter Index (Numeric or Variable)  
 $\$DEST$             Destination Variable

Ex:

$\$TABINDEX=2$

$\$PARINDEX=1$

**EXD.READ\_TOOLPAR 2 1  $\$Dest$  //READ THE PARAMETER 1 TOOL DIAMATER FROM TABLE 2**

**EXD.READ\_TOOLPAR  $\$TABINDEX$   $\$PARINDEX$   $\$Dest$  //READ THE PARAMETER 1 TOOL DIAMATER FROM TABLE 2**

## 8.3 EXD.READ\_HEADPAR

Allows to read a Head Table parameter. Like to  $\$(Hn)$  but allows to set the Head Table Index

### Syntax

**EXD.READ\_HEADPAR** *TabIndex* *ParIndex*  $\$DEST$

*TabIndex*        Table Index (Numeric or Variable)  
*ParIndex*        Parameter Index (Numeric or Variable)  
 $\$DEST$             Destination Variable

Ex:

$\$TABINDEX=2$

$\$PARINDEX=1$

**EXD.READ\_HEADPAR 2 1  $\$Dest$  //READ THE PARAMETER 1 FROM TABLE 2**

**EXD.READ\_HEADPAR  $\$TABINDEX$   $\$PARINDEX$   $\$Dest$**

## 8.4 EXD.WRITE\_TOOLPAR

Allows to write a Tool Table parameter. Like to  $\$(Un)$  but allows to set the Tool Table Index

### Syntax

**EXD.WRITE\_TOOLPAR** *TabIndex* *ParIndex*  $\$SOURCE$

*TabIndex*        Table Index (Numeric or Variable)  
*ParIndex*        Parameter Index (Numeric or Variable)  
 $\$SOURCE$         Source Variable

Ex:

$\$TABINDEX=2$

$\$PARINDEX=1$

$\$SOURCE=10$

**EXD.WRITE\_TOOLPAR 2 1  $\$SOURCE$  //WRITE THE PARAMETER 1 TOOL DIAMATER IN TABLE 2 AT VALUE 10**

**EXD.WRITE\_TOOLPAR  $\$TABINDEX$   $\$PARINDEX$   $\$SOURCE$**

## 8.5 EXD.WRITE\_HEADPAR

Allows to write a Head Table parameter. Like to  $\$(Hn)$  but allows to set the Head Table Index

### Syntax

**EXD.WRITE\_HEADPAR** *TabIndex* *ParIndex* **\$SOURCE**

**TabIndex**        Table Index (Numeric or Variable)  
**ParIndex**        Parameter Index (Numeric or Variable)  
**\$SOURCE**         Source Variable

Ex:

**\$TABINDEX=2**

**\$PARINDEX=1**

**\$SOURCE=10**

**EXD.READ\_HEADPAR 2 1 \$SOURCE** //WRITE THE PARAMETER 1 IN TABLE 2 AT VALUE 10

**EXD.WRITE\_HEADPAR \$TABINDEX \$PARINDEX \$SOURCE**

## 8.6 EXD.LOAD\_LAST

Load in a variable the last Tool Table used by **Tn from file** ("UTENSILE.INF")

### Syntax

**EXD.LOAD\_LAST** **\$DEST**

**\$DEST**    Destination Variable

Ex:

**EXD.LOAD\_LAST \$DEST**

## 8.7 EXD.SAVE\_LAST

Save in the file ("UTENSILE.INF") the current Tool Table set by **Tn**

### Syntax

**EXD.SAVE\_LAST**

Es:

**EXD.SAVE\_LAST**

## 8.8 EXD.RESET\_LAST

Reset the file ("UTENSILE.INF") No Last Tool Used

### Syntax

**EXD.RESET\_LAST**

Es:

**EXD.RESET\_LAST**



## 8.9 EXD.SET\_OUT

Set/Reset of Digital Outputs by Index like to **\$(On)** but is used the variables for output index and output state.

### *Syntax*

**EXD.SET\_OUT \$OutIndex \$State**

Ex:

**\$INDEX=10**

**\$STATE=1**

**EXD.SET\_OUT \$INDEX \$STATE //SET OUT 10**

## 8.10 EXD.READ\_OUT

Read of Digital Outputs by Index like to **\$(On)** but is used the variable for output index.

### *Syntax*

**EXD.READ\_OUT \$OutIndex \$Dest**

Ex:

**\$INDEX=10**

**EXD.READ\_OUT \$INDEX \$DEST //READ OUT 10 IN \$DEST**

## 8.11 EXD.READ\_INP

Read of Digital Inputs by Index like to **\$(In)** but is used the variable for input index.

### *Syntax*

**EXD.READ\_INP \$InptIndex \$Dest**

Ex:

**\$INDEX=10**

**EXD.READ\_INP \$INDEX \$DEST //READ INP 10 IN \$DEST**

## 8.12 EXD.WRITE\_USER

Write an User generic variable in the CN by Index. Like to **\$(Kn)** but is used the variable for index.

### *Syntax*

**EXD.WRITE\_USER \$Index \$Value**

Ex:

**\$INDEX=10**

**\$VALUE=100**

**EXD.WRITE\_USER \$INDEX \$VALUE //WRITE USER 10 VALUE 100**

### 8.13 EXD.READ\_USER

Read an User generic variable in the CN by Index. Like to  $\$(Kn)$  but is used the variable for index.

#### *Syntax*

**EXD.READ\_USER \$Index \$Dest**

Ex:

**\$INDEX=10**

**EXD.READ\_USER \$INDEX \$DEST //RED USER 10 IN \$DEST**

### 8.14 EXD.READ\_DEMAND

Read demand position of Axis. Like to  $\$(Qn)$  but is used the variable for axis index.

Value <100 from 0 to 8 read position with OFFSET (Work Origins etc.)

Value >= 100 from 100 to 108 read position without OFFSET

#### *Syntax*

**EXD.READ\_DEMAND \$Axis \$Dest**

Ex:

**\$Axis=1**

**EXD.READ\_DEMAND \$AXIS \$DEST //READ DEMAND AXIS 1 WITH OFFSET IN \$DEST**

**\$Axis=101**

**EXD.READ\_DEMAND \$AXIS \$DEST // READ DEMAND AXIS 1 WITHOUT OFFSET IN \$DEST**

### 8.15 EXD.READ\_REAL

Read Real position of Axis. Like to  $\$(Rn)$  but is used the variable for axis index.

Value <100 from 0 to 8 read position with OFFSET (Work Origins etc.)

Value >= 100 from 100 to 108 read position without OFFSET

#### *Syntax*

**EXD.READ\_REAL \$Axis \$Dest**

Ex:

**\$Axis=1**

**EXD.READ\_REAL \$AXIS \$DEST //READ REAL AXIS 1 WITH OFFSET IN \$DEST**

**\$Axis=101**

**EXD.READ\_REAL \$AXIS \$DEST // READ REAL AXIS 1 WITHOUT OFFSET IN \$DEST**

## 8.16 EXD.MASK

Set A **MASK** for force a state of Digital Output.

### Syntax

#### EXD.MASK Type OutIndex

**Type** Variable or numeric value that defines the MASK type

**Type=0** Force the output **OFF**

**Type=1** Force the output **ON**

**Type=2** Invert the state of Output

**Type=3** Reset MASK of output

**OutIndex** Digital Output Index

Ex:

`$TYPE=0`

`$OUTINDEX=10`

`EXD.MASK $TYPE $OUTINDEX //FORCE OUT 10 OFF`

`EXD.MASK 3 10 //RESET MASK OUT 10`

## 8.17 EXD.WRITE\_BIT

Set/Reset Variable bit

### Syntax

#### EXD.WRITE\_BIT \$BIT \$VAR \$VAL

**BIT** Variable or Value Nr. Bit to Set/Res (from 0 to 31)

**VAR** Destination Variable

**VAL** Variable or Value state of Bit (0 Reset 1 Set)

Ex:

`$BIT=5`

`$VAL=1`

`EXD.WRITE_BIT $BIT $VARDEST $VAL //SET BIT 5 OF VARDEST`

`EXD.WRITE_BIT 5 $VARDEST 0 //RESET BIT 5 OF VARDEST`

## 8.18 EXD.READ\_BIT

Read bit state of variable

### Syntax

#### EXD.READ\_BIT \$BIT \$VAR \$DEST

**BIT** Variable or Value Nr. Bit to Set/Res (from 0 to 31)

**VAR** Source Var

**VAL** Destination Var state of bit (0 or 1)

Ex:

`$BIT=5`

`EXD.READ_BIT $BIT $VARSOURCE $VARDEST //READ BIT 5 OF VARSOURCE`

`EXD.READ_BIT 5 $VARSOURCE $VARDEST // READ BIT 5 OF VARSOURCE`

## 8.19 EXD.PXV\_ALL\_DETECTORS

Read ALL detectors of PXV Sytem

Ex. For control the tools presence in the charger

### Syntax

**EXD.PXV\_ALL\_DETECTORS \$SHOWMODE \$TOOLS \$ISOK**

**SHOWMODE** Allows to show an image in the PXV Simulation. Variable or Value (for debug)

**SHOWMODE=0** NONE

**SHOWMODE=1** Show image **FILTERED**

**SHOWMODE=2** Show **ORIGINAL** Image

**TOOLS** Return state of detectors read – Bit Mapped (max 32 detectors from 0 to 31)

**Bit=0** Detector ON

**Bit=1** Detector OFF

**ISOK** If =-1 **ERROR READ DETECTORS** . Else Nr. Detectors read

Ex:

```
EXD.PXV_ALL_DETECTORS 0 $TOOLS $ISOK //READ DETECTORS
IF $ISOK<>-1 //IF OK
    EXD.READ_BIT 0 $TOOLS $VARDEST //READ DETECTOR 0
    IF $VARDEST=1 //ON
        ....
    ELSE //OFF
        ....
    END_IF
END_IF
```

## 8.20 EXD.PXV\_SINGLE\_DETECTOR

Read state of detector in PXV system

### Syntax

**EXD.PXV\_SINGLE\_DETECTOR \$NRDET \$SHOWMODE \$VAR**

**NRDET** Detector number to read (from 0 to 31) Variable or Value

**SHOWMODE** See **EXD.PXV\_ALL\_DETECTORS**

**\$VAR** Value Read

**-1 ERROR**

**0 OFF**

**1 ON**

Ex:

```
EXD.PXV_SINGLE_DETECTOR 0 0 $RET //READ DETECTOR 0
IF $RET<>-1 // OK
    IF $RET=1 //ON
        ....
    ELSE //OFF
        ....
    END_IF
END_IF
```

## 8.21 EXD.PXV\_READ\_PROBE

Read state of Probe in PXV system

Return the X,Y position Set

### Syntax

**EXD.PXV\_READ\_PROBE \$PROBE \$XVAL \$YVAL \$ISOK**

**PROBE** Probe Number Variable or Value  
**XVAL** IF ISOK=1 X Position of Probe  
**YVAL** IF ISOK=1 Y Position of Probe  
**ISOK** =-1 PROBE READ ERROR

Ex:

```
EXD.PXV_READ_PROBE 0 $VX $VY $ISOK //READ PROBE 0
IF $ISOK=1 // OK
    GO X[$VX] Y[$VY] //MOVE X,Y TO PROBE 0 POSITION
END_IF
```

## 8.22 EXD.PXV\_RESET\_PROBE

Reset a Probe in PXV system

This Probe will be deactivated and if is read a ERROR will Return

### Syntax

**EXD.PXV\_RESET\_PROBE \$PROBE**

**PROBE** Probe Number Variable or Value

Ex:

```
EXD.PXV_RESET_PROBE 0 //RESET PROBE 0
```

## EXD.PXV\_SET\_DETECTOR

Set the type of Detector (used in system PXV)

### Syntax

**EXD.PXV\_SET\_DETECTOR \$MODE**

**MODE** Type of Detector Variable or Value  
**MODE=0** Contrast Detector  
**MODE=1** Brightness Detector  
**MODE=2** Area Detector  
**MODE=3** Color Detector

Ex:

```
EXD.PXV_SET_DETECTOR 0 //SET MODE TO CONTRAST DETECTOR
```

### 8.23 EXD.PXV\_SAVE\_IMAGE

Save current image acquired in PXV in file jpg  
 Used for capture machine state (ex. After an ERROR)  
 Used in combination to **EXD.PXV\_GET\_IMAGE**  
 Will be saved TWO Images FILTERED and ORIGINAL:

<b>_PxvImgFiltered.jpg</b>	<b>FILTERED</b>
<b>_PxvImgNoFiltered.jpg</b>	<b>ORIGINAL</b>
<b>_PxvImgNoFiltered1.jpg</b>	<b>ORIGINAL ALTERNATIVELY TO _PxvImgNoFiltered.jpg</b>

#### *Syntax*

**EXD.PXV\_SAVE\_IMAGE**

### 8.24 EXD.PXV\_GET\_IMAGE

Image Capture for PXV  
 The captured Image can be save by **EXD.PXV\_SAVE\_IMAGE**

#### *Syntax*

**EXD.PXV\_GET\_IMAGE \$ISOK**

<b>ISOK</b>	<b>0</b>	<b>ERRORE CAPTURE</b>
	<b>1</b>	<b>OK</b>

```
EXD.PXV_GET_IMAG $ISOK //CAPTURE
IF $ISOK=1 // OK
    EXD.PXV_SAVE_IMAGE //SAVE THE IMAGE CAPTURED
END_IF
```

### 8.25 EXD.PXV\_SET\_JOB

Set a **JOB PXV** Configuration File  
 The **JOB** must be created by **PxVisionBrowser**

#### *Sintassi*

**EXD.PXV\_SET\_JOB «JOBNAME» \$ISOK**

<b>JOBNAME</b>	<b>JOB File Name del file JOB (in quote)</b>	
<b>ISOK</b>	<b>0</b>	<b>ERROR SET JOB</b>
	<b>1</b>	<b>OK</b>

Ex:

**EXD.PXV\_SET\_JOB "MYJOB" \$ISOK**

## 8.26 EXD.RUN\_SCRIPT

This function allows to execute a **SCRIPT** code in **C#**. The **SCRIPT** is compiled in **RUN.-TIME** and isn't necessary any external development software

The **SCRIPT** has access to all resources of current process **ISO US**, ex. Read or Write Gcode **VARIABLES**.

This allows to use a **STANDARD PROGRAMMING LANGUAGE** with high performances.

All parameters of **EXD.RUN\_SCRIPT** are separated by **COMMA “,”** and they have an identifier (**\*,&,@,X**) that define the parameter type.

The **SCRIPT** must be found in the **FOLDER ISO US->Us\_Script** and **MUST HAVE AN EXTENSION .USS**.

There are no limit to **SCRIPT** number.

**The SCRIPT code will finish when the RETURN is performed from MAIN function.**

### IDENTIFIERS :

- \*)** Script Name (without extension) **MANDATORY**  
*Only ONE parameter of this type is admitted*
- &)** Input parameter for script **Main function NOT MANDATORY**  
*No limit for this parameter*  
*Can be:*  
*Variable \$*  
*Variable:*  
*DIRECT Values*
- @)** Output parameter to script **Main function NOT MANDATORY**  
*No limit for this parameter*  
*Can be:*  
*Variable \$*
- X)** Mode of Script execution **NOT MANDATORY**  
*Only ONE parameter of this type is admitted*  
*Can be:*  
*DIRECT VALUE 0 or 1*  
*X0, The Script isn't executed in DEMO MODE (Preview) DEFAULT*  
*X1, The Script is executed in DEMO MODE (Preview)*

### Syntax

**EXD.RUN\_SCRIPT \*SCRIPT\_NAME, &\$VAL,&:ADDR,&100,@\$RET,@\$RET1**

**SCRIPT\_NAME** Script name WITHOUT EXTENSION

**&** INPUT Parameters

**@** OUPUT Parameters

Es:

**\$VAR=127.14**

**:5000=37.18**

**EXD.RUN\_SCRIPT \*TESTSCRIPT,&\$VAR,&:5000,&500.14,@\$RET,@\$RET1,@\$RET2**

*//\$VAR FIRST INPUT VALUE (127.14)*

*//:5000 SECOND INPUT VALUE (37.18)*

*//500.14 THIRD INPUT VALUE*

*//\$RET FIRST OUTPUT VALUE*

*//\$RET1 SECOND OUTPUT VALUE*

*//\$RET2 THIRD OUTPUT VALUE*

**RULES OF SCRIPT CODE**

The **SCRIPT** must follow some **RULES** for a correct **COMPILATION** and **EXECUTION**.

**ISO US** generate an example in the folder **Us\_Script-> UsExample.uss**

**BASE RULES:**

**namespace**

Must be **UsFunctions**

**Class**

Must be **UsFunctions type PUBLIC**

**Entry Point**

Must be:

**public static bool Main(UsWork.IsoUs MyIsoUs,double[] Par,out double[] ValOut)**

**where:**

**MyIsoUs** (type UsWork.IsoUs) current instance of **FRAMEWORK** running this allows to access at all resources of **IsoUS**

**See**

[https://www.promax.it/file\\_download/ENG/IsoUs%20Framework\\_eng.pdf](https://www.promax.it/file_download/ENG/IsoUs%20Framework_eng.pdf)

**Par** Array of double that contains **INPUT** values (if presents ) in the sorted of defined in the function **EXD.RUN\_SCRIPT**

If not **PRESENT** any **INPUT** parameter, **Par=null**

**ValOut** Array of double that contains **OUTPUT** values (if presents ) read in the sorted of defined in the function **EXD.RUN\_SCRIPT**

If not **PRESENT** any **OUTPUT** value, **ValOut =null**

Ex: **EXD.RUN\_SCRIPT \*XXX,&\$x,@\$VAL1,@\$VAL2,@\$\$VAL3**

**\$VAL1=ValOut[0]**

**\$VAL2=ValOut[1]**

**\$VAL3=ValOut[2]**

The function Main return a bool value:

**True     SCRIPT EXECUTION OK**

**False    EXECUTION ERROR**

**ERROR EXECUTION SCRIPT**

The script can generate **ERRORS** if **COMPILATION** or **EXECUTION** (exceptions)

From Gcode will be generate an **ALARM** "**ERROR EXECUTION SCRIPT**".

For understand better the **ERROR** type, IsoUs will write (in the same folder of IsoUs) a file "**\_UsScript.Err**"

This contains more informations about the errors.



**SCRIPT EXAMPLE**

```

@ASSEMBLY System.dll,Microsoft.CSharp.dll,System.Core.dll,System.Data.dll,ComSynk.dll,Compiler.dll,UsWork.dll
//@ASSEMBLY references - add new references if necessary
using System;
using System.Windows;
namespace UsFunctions
{
    public class UsFunctions
    {
        //Function Main 3 par input return 3 ValOut
        public static bool Main(UsWork.IsoUs MyIsoUs,double[] Par,out double[] ValOut)
        {
            ValOut=null;
            try
            {
                ValOut=new double[3]; // 3 ValOut
                ValOut[0]=Par[0]*2; // Par input 0*2
                ValOut[1]=Par[1]*2; // Par input 1*2
                ValOut[2]=Par[2]*2; // Par input 2*2
                for(int n=0;n<300;n++) //Write IsoUs Var From 1000 to 1300
                    MyIsoUs.MyMaster.GetLink.MyCpu.VarCpu[0].VarIsoNs[1000+n]=n*10;
                TestCall(); //Test function call
                return true; // return OK
            }
            Catch { return false; // Error Script}
        }
        //Test Function Call
        static void TestCall()
        {
            ...
        }
    }
}

```

**Call by Gcode:**

**\$VAR**=127.14

:5000=37.18

**EXD.RUN\_SCRIPT** \***TESTSCRIPT**,&**\$VAR**,&:5000,&500.14,@**\$RET**,@**\$RET1**,@**\$RET2**

**3 input parameters**

Par[0]=127.14 -> \$VAR

Par[1]=37.18 -> :5000

Par[2]=500.14

**3 Output values**

ValOut[0]=Par[0]\*2 -> 254.28

ValOut[1]=Par[1]\*2 -> 74.36

ValOut[2]=Par[2]\*2 -> 1000.28

*The example writes also the IsoUs variables from addr 1000 to addr 1300 with values from 0 to 300*

**SCRIPT LIMITS**

There are no limits for code of SCRIPT.

You need to be careful about the execution TIME of SCRIPT.

Time > 2-3 sec can block the IsoUs application whit a fatal error

## 1) EXD.OPEN\_DLL

Allows to execute a **DLL .NET** . The DLL must be write with Visual Studio in **C#** or **VbNet**.

The **DLL** has access to all resources of current process **ISO US** , ex . Read or Write Gcode **VARIABLES**.

All parameters of **EXD.OPEN\_DLL** are separated by **COMMA “,”** and they have an identifier (**\*,&,@,X**) that define the parameter type.

The **DLL** must be found in the **FOLDER ISO US->Us\_Dll** and **MUST HAVE AN EXTENSION .dll**.

There are no limit to **DLL** number.

**The DLL code will finish when the EXD.CLOSE DLL will be invoke or when the Gcode is ended.**

Is invoked the function `public bool Load(UsWork.IsoUs IsoUs, double[] ParInput, out double[] ValOut)`

### IDENTIFIERS :

- \*)** Dll Name (without extension) **MANDATORY**  
*Only ONE parameter of this type is admitted*
- &)** Input parameter for script **Load** function **NOT MANDATORY**  
*No limit for this parameter*  
*Can be:*  
*Variable \$*  
*Variable:*  
*DIRECT Values*
- @)** Output parameter to script **Load** function **NOT MANDATORY**  
*No limit for this parameter*  
*Can be:*  
*Variable \$*
- X)** Mode of Dll execution **NOT MANDATORY**  
*Only ONE parameter of this type is admitted*  
*Can be:*  
*DIRECT VALUE 0 or 1*  
*X0, The Dll isn't executed in DEMO MODE (Preview) DEFAULT*  
*X1, The Dll is executed in DEMO MODE (Preview)*

**The DLL MUST IMPORT THE INTERFACE UsWork.IsoUs.IUsDll.**

This force the following Methods and Property:

`public bool Load(UsWork.IsoUs IsoUs, double[] ParInput, out double[] ValOut)`

Must be call for **FIRST ONLY ONE TIME**

**IsoUs** Current process of IsoUs  
**ParInput** Array of double **INPUT** parameters if presents, **null if not presents**  
**ValOut** Array of **OUTPUT** parameters if presents, **null if not presents**  
**Ritorna** **True** Load **DLL OK**  
**False** Load **DLL ERROR**

`public bool CallFunc(double[] ParInput, out double[] ValOut)`

Can be called during the Gcode cycle

The DLL must be open by Load

**ParInput** Array of double **INPUT** parameters if presents, **null if not presents**  
**ValOut** Array of **OUTPUT** parameters if presents, **null if not presents**  
**Ritorna** **True** Call **DLL OK**  
**False** Call **DLL ERROR**

`public void Close()`

Close DLL.

During the Closing all **DLL** resources will be disposed programmatically

The Close is always called in **AUTOMATIC MODE** at Gcode **END** or Gcode **ALARM**

```
public int Synk { get; set; }
```

It is used for DLL synchronization with Gcode without block the application.

The **SYNK** must be set during the Load DLL at value -1 programmatically (synk not ready).

Values different to -1 **ENABLE THE SYNK AND RELEASE THE GCODE TO NEXT LINE.**

Generally is used to wait the **INPUT PARAMETERS** in a **FORM**.

The **RETURN VALUE** (different to -1) can be read by Gcode

### Syntax

```
EXD.OPEN_DLL *DLL_NAME, &$VAL,&:ADDR,&100,@$RET,@$RET1
```

**DLL\_NAME**        **DLL name without extension**

**&**                **INPUT parameters**

**@**                **OUTPUT parameters**

Ex:

```

//$VAR FIRST INPUT VALUE (127.14)
//:5000 SECOND INPUT VALUE (37.18)
//500.14 THIRD INPUT VALUE
//$RET FIRST OUTPUT VALUE
//$RET1 SECOND OUTPUT VALUE
//$RET2 THIRD OUTPUT VALUE
$VAR=127.14
:5000=37.18
EXD.OPEN_DLL *TESTUSDLL,&$VAR,&:5000,&500.14,@$RET,@$RET1,@$RET2 //OPEN
EXD.SYNK_DLL *TESTUSDLL,@$SYNCKRET //WAIT SYNK
IF $SYNCKRET=1 // IF SYNK = 1 END
  END_PROGRAM
END_IF
$_LOOP=:100
$COUNT=0
LOOP $_LOOP
  F[:101]
  G1X250Y250Z-50A150B50
  G62
  F[:101]
  X0Y0Z0A0B0
  G62
  $COUNT++
  EXD.CALL_DLL *TESTUSDLL,&$COUNT // CALL FOR UPDATE FORM VALUES
END_LOOP
EXD.SYNK_DLL *TESTUSDLL,@$SYNCKRET // SYNK WAIT END
EXD.CLOSE_DLL *TESTUSDLL // CLOSE

```

## 2) EXD.CALL\_DLL

Dll Call.

Generally used for update Dll parameters.

Is invoked the function `public bool CallFunc(double[] ParInput, out double[] ValOut)`

### *Syntax*

**EXD.CALL\_DLL \*DLL\_NAME, &\$VAL,&:ADDR,&100,@\$RET,@\$RET1**

**DLL\_NAME**        **DLL name without extension**

**&**                **INPUT parameters**

**@**                **OUPUT parameters**

**Ex:**

**EXD.CALL\_DLL \*TESTUSDLL,&\$COUNT // CALL FOR UPDATE FORM VALUES**

## 3) EXD.CLOSE\_DLL

Dll close.

Is invoked the function `public void Close()`

### *Syntax*

**EXD.CLOSE\_DLL \*DLL\_NAM**

**DLL\_NAME**        **DLL name without extension**

**Ex:**

**EXD.CLOSE\_DLL \*TESTUSDLL**

## 4) EXD.SYNK\_DLL

Gcode synchronization from Dll

Is used for wait some operations in the DLL , like to Data Input.

Is invoked the property `public int Synk { get; set; }`

For enable the **SYNK**, the **DLL** must write Synk property !=-1

### *Syntax*

**EXD.SYNK\_DLL \*DLL\_NAM,@SYNKRET**

**DLL\_NAME**        **DLL name without extension**

**SYNKRET**        **Return value from Synk (the value is always different to -1) NOT MANDATORY**

**Ex:**

**EXD.SYNK\_DLL \*TESTUSDLL,@\$SYNKRET // SYNK WAIT IN \$SYNKRET THE VALUE OF PROPERTY Synk**

## 5) EXD.STL\_SETVIS

Allow to set the visibility status of STL component in the **REALMACHINE** simulation.  
The component is called by **NAME** defined in the *MachineSettings.xml*

### Syntax

**EXD.STL\_SETVIS** "STLNAME" Xvis

**STLNAME** STL component NAME

**Xvis** State of visibility

**X0** Hidden

**X1** Visible

Ex:

**\$VIS=0**

**EXD.STL\_SETVIS** "STLPART1" \$VIS // HIDE COMPONENT STLPART1

## 6) EXD.STL\_READVIS

Allow to read the visibility of STL component in the **REALMACHINE** simulation.  
The component is called by **NAME** defined in the *MachineSettings.xml*

### Syntax

**EXD.STL\_READVIS** "STLNAME" \$STATE

**STLNAME** STL component NAME

**\$STATE** Return Variable of State visibility

**\$STATE =0** Hidden

**\$STATE =1** Visible

Ex:

**EXD.STL\_READVIS** "STLPART1" \$STATE // READ STATUS COMPONENT STLPART1

## 7) EXD.STL\_SETVISIDX

Allow to set the visibility status of STL component in the **REALMACHINE** simulation.  
The component is called by **ADDRESS** defined in the *MachineSettings.xml*

### Syntax

**EXD.STL\_SETVISIDX** ADDR VIS

**ADDR** Address of STL component VARIABLE or NUMERIC VALUE

**VIS** State of STL VARIABLE or NUMERIC VALUE

**0** Hidden

**1** Visible

Ex:

**\$VIS=0**

**\$ADDR=5**

**EXD.STL\_SETVISIDX** \$ADDR \$VIS // HIDE COMPONENT ADDR 5

**EXD.STL\_SETVISIDX** 7 0 // HIDE COMPONENT ADDR 7

## 8) EXD.STL\_READVISIDX

Allow to read the visibility of STL component in the **REALMACHINE** simulation.  
The component is called by **ADDRESS** defined in the *MachineSettings.xml*

### Syntax

**EXD.STL\_READVISIDX** ADDR \$STATE

**ADDR** Address of STL component **VARIABLE** or **NUMERIC VALUE**

**\$STATE** Return Variable of State visibility

**\$STATE =0** Hidden

**\$STATE =1** Visible

Ex:

```
EXD.STL_READVISIDX 5 $STATE // READ STATUS COMPONENT ADDR 5
```

### **RULES OF US DLL**

The Us DLL must follow some **RULES**.

**ISO US** generate a **EXAMPLE** in the folder **Us\_Dll-> ExampleLink.txt** this contains a LINK for download a complete C# project.

#### **RULES:**

**namespace**

Must be **UsDll**

**Class**

Must be **UsDll** and derivate the **INTERFACE UsWork.IsoUs.IUsDll**

**public class UsDll:UsWork.IsoUs.IUsDll**

**Methods and Proprties are described in [EXD.OPEN DLL](#)**

#### **DLL EXECUTION ERRORS**

From Gcode will be generate an **ALARM "ERROR EXECUTION DLL"**.

For understand better the **ERROR** type, IsoUs will write (in the same folder of IsoUs) a file "**\_UsDll.Err**"

This contains more informations about the errors.

Is possible to use the Visual Studio Debug

**USDLL EXAMPLE IN VISUAL STUDIO C#**

Complete project [https://www.promax.it/file\\_download/ZIP/TestUsDll.zip](https://www.promax.it/file_download/ZIP/TestUsDll.zip)

**UsDll Class**

```
using System.Windows;
using TestUsDll;
```

```
namespace UsDll
{
    public class UsDll:UsWork.IsoUs.IUsDll
    {
        //Gcode IsoUs for Test
        /*
            $VAR=127.14
            :5000=37.18
            EXD.OPEN_DLL *TESTUSDLL,&$VAR,&:5000,&500.14,@$RET,@$RET1,@$RET2
            EXD.SYNK_DLL *TESTUSDLL,@$SYNCKRET
            IF $SYNCKRET=1
                END_PROGRAM
            END_IF
            $_LOOP=:100
            $COUNT=0
            LOOP $_LOOP
                F[:101]
                G1X250Y250Z-50A150B50
                G62
                F[:101]
                X0Y0Z0A0B0
                G62
                $COUNT++
                EXD.CALL_DLL *TESTUSDLL,&$COUNT
            END_LOOP
            EXD.SYNK_DLL *TESTUSDLL,@$SYNCKRET
            EXD.CLOSE_DLL *TESTUSDLL
        */
        internal UsWork.IsoUs _MyIsoUs; // instance of UsWork
        TestW _TestW; //Test Window
        internal int Loop; //Loop Number
        #region Events
        /// <summary>
        /// Values changed
        /// Update form labels
        /// </summary>
        /// <param name="sender"></param>
        /// <param name="e"></param>
        void _MyIsoUs_AxesDemandValueChanged(object sender, UsWork.AxesValueArg e)
        {
            _TestW.LblValX.Content = e.Format[0];
            _TestW.LblValY.Content = e.Format[1];
            _TestW.LblValZ.Content = e.Format[2];
            _TestW.LblValA.Content = e.Format[3];
            _TestW.LblValB.Content = e.Format[4];
        }
    }
}
```



## #endregion Events

## #region IUsDll

```

/// <summary>
/// IsoUs Instance of current Framework running
/// Load Dll
/// ParInput Input parameters
/// ValOut Output values
/// </summary>
/// <param name="IsoUs"></param>
/// <param name="ParInput"></param>
/// <param name="ValOut"></param>
/// <returns></returns>
public bool Load(UsWork.IsoUs IsoUs, double[] ParInput, out double[] ValOut)
{
    Synk = -1;
    ValOut = new double[ParInput.Length]; // ValOut the same length of ParInput
    for (int n = 0; n < ParInput.Length; n++)
        ValOut[n] = ParInput[n] * 2; // Copy values * 2
    _MyIsoUs = IsoUs; // save IsoUs instance
    _SetEvents(); // Set IsoUs events
    _TestW = new TestW(this); // test Window
    _TestW.Owner = (Window)_MyIsoUs.Tag; // Owner
    _TestW.Show(); // Show
    return true; // return OK
}
/// <summary>
/// Call Function
/// ParInput Input parameters
/// ValOut Output values
/// </summary>
/// <param name="ParInput"></param>
/// <param name="ValOut"></param>
/// <returns></returns>
public bool CallFunc(double[] ParInput, out double[] ValOut)
{
    ValOut = null; // no ValOut
    int _Val = (int)ParInput[0]; // Get ParInput[0]
    if (_Val == Loop) // if cycle reached
    {
        _TestW.LblLoop.Content = "END PCS: " + _Val.ToString(); // update label END PCS
        _TestW.BtnExit.IsEnabled = true; // enable Exit button
    }
    else
        _TestW.LblLoop.Content = _Val.ToString(); //Update PCS Number
    return true;
}
/// <summary>
/// Close Dll
/// </summary>
public void Close()
{
    _TestW.Close(); // Close Window
}

```

```
/// <summary>
/// Synk Dll
/// return SYNK value if not -1
/// </summary>
public int Synk { get; set; }

#endregion IUsDll
/// <summary>
/// Stop the current Gcode execution
/// called by form button
/// </summary>
internal void Stop()
{
    _MyIsoUs.UsGcodeRun.StopGcode(); // Stop Gcode
}
/// <summary>
/// Set events
/// </summary>
void _SetEvents()
{
    _MyIsoUs.AxesDemandValueChanged += _MyIsoUs_AxesDemandValueChanged; // axes values changed
    _MyIsoUs.MyMaster.ResetEvent(); // reset events for update labels
}
}
```

**TestW.xaml**

```

<Window x:Name="TestW1" x:Class="TestUsDll.TestW"
  xmlns="http://schemas.microsoft.com/winfx/2006/xaml/presentation"
  xmlns:x="http://schemas.microsoft.com/winfx/2006/xaml"
  xmlns:d="http://schemas.microsoft.com/expression/blend/2008"
  xmlns:mc="http://schemas.openxmlformats.org/markup-compatibility/2006"
  xmlns:local="clr-namespace:TestUsDll"
  mc:Ignorable="d"
  Title="TestW" Height="400" Width="400" WindowStyle="None">
<Grid x:Name="MyGrid" >
  <Grid.RowDefinitions>
    <RowDefinition Height="*" />
    <RowDefinition Height="*" />
    <RowDefinition Height="*" />
    <RowDefinition Height="*" />
    <RowDefinition Height="*" />
    <RowDefinition Height="*" />
    <RowDefinition Height="*" />
    <RowDefinition Height="*" />
  </Grid.RowDefinitions>
  <Grid Grid.Row="0">
    <Grid.ColumnDefinitions>
      <ColumnDefinition Width="0.7*" />
      <ColumnDefinition Width="0.8*" />
      <ColumnDefinition Width="0.7*" />
      <ColumnDefinition Width="*" />
    </Grid.ColumnDefinitions>
    <Label x:Name="LblNrLoop" Tag="2" Grid.Column="0" Content="NrLoop" HorizontalAlignment="Center"
  Height="40" FontSize="18" VerticalAlignment="Center" />
    <TextBox x:Name="TxtLoop" Tag="0" Grid.Column="1" HorizontalAlignment="Center" Height="30" Text="50"
  FontSize="20" VerticalAlignment="Center" Width="90" TextAlignment="Center" PreviewTextInput="TxtLoop_Preview-
  TextInput" />
    <Label x:Name="LblCurrentLoop" Grid.Column="2" Tag="2" Content="Current" HorizontalAlignment="Center"
  Height="40" FontSize="18" VerticalAlignment="Center" />
    <Label x:Name="LblLoop" Tag="2" Grid.Column="3" FontSize="18" Content="0" HorizontalAlignment="Left"
  Height="40" HorizontalContentAlignment="Center" VerticalContentAlignment="Center" VerticalAlignment="Center"
  />
  </Grid>
  <Grid Grid.Row="1">
    <Grid.ColumnDefinitions>
      <ColumnDefinition Width="*" />
      <ColumnDefinition Width="*" />
      <ColumnDefinition Width="*" />
    </Grid.ColumnDefinitions>
    <Label x:Name="LblFeed" Tag="2" Grid.Column="0" Content="Feed" HorizontalAlignment="Center"
  Height="40" FontSize="18" VerticalAlignment="Center" Width="50" />
    <TextBox x:Name="TxtF" Tag="0" Grid.Column="1" HorizontalAlignment="Center" Height="30" FontSize="20"
  Text="1" VerticalAlignment="Center" Width="100" TextAlignment="Center" PreviewTextInput="TxtF_PreviewTextIn-
  put" />
    <Button x:Name="BtnSetF" Grid.Column="2" Tag="1" Content="Set Feed" ToolTip="Set Work Feed" Horizontal-
  Alignment="Center" FontSize="16" Height="30" VerticalAlignment="Center" Width="80" Click="BtnSetF_Click" />
  </Grid>
  <Grid Grid.Row="2">

```

```

<Grid.ColumnDefinitions>
  <ColumnDefinition Width="*" />
  <ColumnDefinition Width="5*" />
</Grid.ColumnDefinitions>
<Border x:Name="BLblX" Grid.Column="0" Tag="3" Height="40" Width="40" VerticalAlignment="Center"
HorizontalAlignment="Center" >
  <Label x:Name="LblX" Tag="2" Content="X" Height="40" FontSize="24" HorizontalContentAlignment="Center"
VerticalAlignment="Center" Width="40" />
</Border>
<Border x:Name="BLblValX" Grid.Column="1" Tag="4" Height="40" Width="200" VerticalAlignment="Center"
HorizontalAlignment="Center">
  <Label x:Name="LblValX" Tag="2" Content="..." Height="40" FontSize="24" HorizontalContentAlign-
ment="Center" VerticalAlignment="Center" />
</Border>
</Grid>
<Grid Grid.Row="3">
  <Grid.ColumnDefinitions>
    <ColumnDefinition Width="*" />
    <ColumnDefinition Width="5*" />
  </Grid.ColumnDefinitions>
  <Border x:Name="BLblY" Grid.Column="0" Tag="3" Height="40" Width="40" VerticalAlignment="Center"
HorizontalAlignment="Center" >
    <Label x:Name="LblY" Tag="2" Content="Y" Height="40" FontSize="24" HorizontalContentAlignment="Center"
VerticalAlignment="Center" Width="40" />
  </Border>
  <Border x:Name="BLblValY" Grid.Column="1" Tag="4" Height="40" Width="200" VerticalAlignment="Center"
HorizontalAlignment="Center" >
    <Label x:Name="LblValY" Tag="2" Content="..." Height="40" FontSize="24" HorizontalContentAlign-
ment="Center" VerticalAlignment="Center" />
  </Border>
</Grid>

<Grid Grid.Row="4">
  <Grid.ColumnDefinitions>
    <ColumnDefinition Width="*" />
    <ColumnDefinition Width="5*" />
  </Grid.ColumnDefinitions>
  <Border x:Name="BLblZ" Tag="3" Grid.Column="0" Height="40" Width="40" VerticalAlignment="Center" Hor-
izontalAlignment="Center" >
    <Label x:Name="LblZ" Tag="2" Content="Z" Height="40" FontSize="24" HorizontalContentAlignment="Center"
VerticalAlignment="Center" Width="40" />
  </Border>
  <Border x:Name="BLblValZ" Grid.Column="1" Tag="4" Height="40" Width="200" VerticalAlignment="Center"
HorizontalAlignment="Center" >
    <Label x:Name="LblValZ" Tag="2" Content="..." Height="40" FontSize="24" HorizontalContentAlign-
ment="Center" VerticalAlignment="Center" />
  </Border>
</Grid>
<Grid Grid.Row="5">
  <Grid.ColumnDefinitions>
    <ColumnDefinition Width="*" />
    <ColumnDefinition Width="5*" />
  </Grid.ColumnDefinitions>

```

```

    <Border x:Name="BLbIA" Grid.Column="0" Tag="3" Height="40" Width="40" VerticalAlignment="Center" HorizontalAlignment="Center">
        <Label x:Name="LbIA" Tag="2" Content="A" Height="40" FontSize="24" HorizontalContentAlignment="Center" VerticalAlignment="Center" Width="40"/>
    </Border>
    <Border x:Name="BLbIValA" Grid.Column="1" Tag="4" Height="40" Width="200" VerticalAlignment="Center" HorizontalAlignment="Center" Grid.Row="1">
        <Label x:Name="LbIValA" Tag="2" Content="..." Height="40" FontSize="24" HorizontalContentAlignment="Center" VerticalAlignment="Center" />
    </Border>
</Grid>
<Grid Grid.Row="6">
    <Grid.ColumnDefinitions>
        <ColumnDefinition Width="*" />
        <ColumnDefinition Width="5*" />
    </Grid.ColumnDefinitions>
    <Border x:Name="BLbIB" Grid.Column="0" Tag="3" Height="40" Width="40" VerticalAlignment="Center" HorizontalAlignment="Center" >
        <Label x:Name="LbIB" Tag="2" Content="B" Height="40" FontSize="24" HorizontalContentAlignment="Center" VerticalAlignment="Center" Width="40"/>
    </Border>
    <Border x:Name="BLbIValB" Grid.Column="1" Tag="4" Height="40" Width="200" VerticalAlignment="Center" HorizontalAlignment="Center" >
        <Label x:Name="LbIValB" Tag="2" Content="..." Height="40" FontSize="24" HorizontalContentAlignment="Center" VerticalAlignment="Center" />
    </Border>
</Grid>
<Grid Grid.Row="7">
    <Grid.ColumnDefinitions>
        <ColumnDefinition Width="*" />
        <ColumnDefinition Width="*" />
        <ColumnDefinition Width="*" />
    </Grid.ColumnDefinitions>
    <Button x:Name="BtnStop" Grid.Column="0" Tag="1" IsEnabled="False" Content="STOP" ToolTip="Stop Gcode and Exit" HorizontalAlignment="Center" Height="30" VerticalAlignment="Center" Width="60" Click="BtnStop_Click"/>
    <Button x:Name="BtnRun" Grid.Column="1" Tag="1" Content="Run" ToolTip="Run Gcode" HorizontalAlignment="Center" Height="30" VerticalAlignment="Center" Width="60" Click="BtnRun_Click"/>
    <Button x:Name="BtnExit" Grid.Column="2" Tag="1" ToolTip="Exit" Content="Exit" HorizontalAlignment="Center" Height="30" VerticalAlignment="Center" Width="60" Click="BtnExit_Click" />
</Grid>
</Grid>
</Window>

```

**TestW.xaml.cs**

```

using System;
using System.Collections.Generic;
using System.Linq;
using System.Text;
using System.Threading.Tasks;
using System.Windows;
using System.Windows.Controls;
using System.Windows.Data;
using System.Windows.Documents;
using System.Windows.Input;
using System.Windows.Media;
using System.Windows.Media.Imaging;
using System.Windows.Shapes;

namespace TestUsDll
{
    public partial class TestW : Window
    {
        UsDll.UsDll _MyUsDll;
        //Style components
        /*
        MainGridStyle      -> Grid
        PluginButton       -> Button
        PluginButtonSelect -> Button
        BtnVisType         -> Button
        ButtonCommandsStyle -> Button
        TextBoxStyle       -> TextBox
        LabelStyle         -> Label
        LabelSelector      -> Label
        LabelSelector1     -> Label
        LabelAbsStyle      -> Label
        LabelMonitorStyle  -> Label
        LabelCommandsStyle -> Label
        LabelNameAxesStyle -> Label
        LabelFlashStyle    -> Label
        LabelHomeStyle     -> Label
        LabelInc           -> Label
        UsPreviewCheckBox  -> CheckBox
        CheckBoxStyle      -> CheckBox
        UsContextMenuStyle -> ContextMenu
        UsGridViewHeaderStyle -> DataGridColumnHeader
        UsDataGridCellStyle -> DataGridCell
        UsProgressBar      -> ProgressBar
        TabItemStyle       -> TabItem
        BorderSelector     -> Border
        BorderSelector1    -> Border
        BorderStyle        -> Border
        BorderAbsStyle     -> Border
        BorderMonitorStyle -> Border
        BorderNameAxesStyle -> Border
        BorderInc          -> Border
        */
    }
}

```

```

SliderThumbStyle    -> Thumb
NotifyListViewFont  -> ListViewItem
NotifyListViewStyle -> ListView
*/
public TestW(UsDII.UsDII MyUsDII)
{
    _MyUsDII = MyUsDII;
    InitializeComponent();
    _SetStyle(); // Set Style from IsoUs
}
#region Events
/// <summary>
/// Move Window
/// </summary>
/// <param name="e"></param>
protected override void OnMouseLeftButtonDown(MouseButtonEventArgs e)
{
    base.OnMouseLeftButtonDown(e);
    DragMove();
}
/// <summary>
/// Run Gcode SYNK OK
/// </summary>
/// <param name="sender"></param>
/// <param name="e"></param>
void BtnRun_Click(object sender, RoutedEventArgs e)
{
    _MyUsDII.Loop = int.Parse(TxtLoop.Text); // Loop Value
    _MyUsDII._MyIsoUs.MyMaster.GetLink.MyCpu.VarCpu[0].VarIsoNs[100] = _MyUsDII.Loop; // Write IsoUs Var
Loop
    _MyUsDII._MyIsoUs.MyMaster.GetLink.MyCpu.VarCpu[0].VarIsoNs[101] = double.Parse(TxtF.Text,
    _MyUsDII._MyIsoUs.NewProvider); // Write FEED Value
    _MyUsDII.Synk = 0; // Synk Ok
    BtnStop.IsEnabled = true;
    BtnExit.IsEnabled = false;
    BtnRun.IsEnabled = false;

}
/// <summary>
/// Exit
/// </summary>
/// <param name="sender"></param>
/// <param name="e"></param>
void BtnExit_Click(object sender, RoutedEventArgs e)
{
    _MyUsDII.Synk = 1; // SYNK EXIT
}
/// <summary>
/// Stop Gcode
/// </summary>
/// <param name="sender"></param>
/// <param name="e"></param>
void BtnStop_Click(object sender, RoutedEventArgs e)
{

```

```

    _MyUsDtl.Stop();
}
/// <summary>
/// Set Feed
/// </summary>
/// <param name="sender"></param>
/// <param name="e"></param>
void BtnSetF_Click(object sender, RoutedEventArgs e)
{
    _MyUsDtl._MyIsoUs.MyMaster.GetLink.MyCpu.VarCpu[0].VarIsoNs[101] = double.Parse(TxtF.Text,
    _MyUsDtl._MyIsoUs.NewProvider); // Set Gcode Feed
}
/// <summary>
/// Feed Preview Text Input
/// </summary>
/// <param name="sender"></param>
/// <param name="e"></param>
void TxtF_PreviewTextInput(object sender, TextCompositionEventArgs e)
{
    TextBox _Txt = (TextBox)sender;
    _ChecksNumeric(e, _Txt.Text, true, false);
}
/// <summary>
/// Loop Preview Text Input
/// </summary>
/// <param name="sender"></param>
/// <param name="e"></param>
void TxtLoop_PreviewTextInput(object sender, TextCompositionEventArgs e)
{
    TextBox _Txt = (TextBox)sender;
    _ChecksNumeric(e, _Txt.Text, false, false);
}
#endregion Events
/// <summary>
/// Check if string contains only numerical value
/// </summary>
/// <param name="e">TextCompositionEventArgs PreviewTextInput Argument</param>
/// <param name="_Text">String Text for check</param>
/// <param name="_DecimalPoint">True accept decimal point</param>
/// <param name="_NegativeValue">True accept negative value</param>
void _ChecksNumeric(TextCompositionEventArgs e, string _Text, bool _DecimalPoint, bool _NegativeValue)
{
    if (!_DecimalPoint)
        _ChecksNumeric(e, _Text, 0, _NegativeValue);
    else
        _ChecksNumeric(e, _Text, 20, _NegativeValue);
}
/// <summary>
/// Check if string contains only numerical value
/// </summary>
/// <param name="e">TextCompositionEventArgs PreviewTextInput Argument</param>
/// <param name="_Text">String Text for check</param>
/// <param name="_NrDecimal">Int32 Number of Decimal Digit</param>
/// <param name="_NegativeValue">True accept negative value</param>

```



```

void _ChecksNumeric(TextCompositionEventArgs e, string _Text, Int32 _NrDecimal, bool _NegativeValue)
{
    int result;
    if (e.Text == "-")
    {
        if (!_NegativeValue)
            e.Handled = true;
        if (_Text == "")
            return;
        if (_Text.Contains('-'))
        {
            e.Handled = true;
            return;
        }
        TextBox _Txt = (TextBox)e.OriginalSource;
        if (_Txt.CaretIndex == 0)
            return;
        e.Handled = true;
        return;
    }
    if (e.Text == ".")
    {
        if (_NrDecimal <= 0)
            e.Handled = true;
        if (_Text.Contains("."))
            e.Handled = true;
        return;
    }
    if (!(int.TryParse(e.Text, out result)))
        e.Handled = true;
    // Check Decimal after dot
    Int32 AfterDot;
    Int32 PosDot;
    PosDot = _Text.IndexOf('.');
    if (PosDot == -1)
        return;
    // get char after dot
    AfterDot = _Text.Length - PosDot - 1;
    TextBox _MText = (TextBox)e.Source;

    if (AfterDot >= _NrDecimal && _MText.CaretIndex > PosDot)
        e.Handled = true;
}
/// <summary>
/// Set SType
/// </summary>
void _SetStyle()
{
    _SetStyle(MyGrid);
}

```

```

/// <summary>
/// Set Styles
/// Set Components Styles like to IsoUs
/// </summary>
void _SetStyle(Grid _Grid)
{
    for(int n=0;n<_Grid.Children.Count;n++)
    {
        int _Tag = -1;
        object _Obj = _Grid.Children[n];
        if(_Obj is Grid)
        {
            Grid _Grd = (Grid)_Obj;
            _Grd.Style = _MyUsDll._MyIsoUs.UsStylesProvider.GetStyle("MainGridStyle");
            _SetStyle(_Grd);
        }
        Label _Lbl = null;
        Border _Brd = null;
        Button _Btn = null;
        TextBox _Txt = null;
        if (_Obj is Label)
        {
            _Lbl = (Label)_Obj;
            _Tag = int.Parse(_Lbl.Tag.ToString());
        }
        if (_Obj is Button)
        {
            _Btn = (Button)_Obj;
            _Tag = int.Parse(_Btn.Tag.ToString());
        }
        if (_Obj is TextBox)
        {
            _Txt = (TextBox)_Obj;
            _Tag = int.Parse(_Txt.Tag.ToString());
        }
        if (_Obj is Border)
        {
            _Brd = (Border)_Obj;
            object _Obj1 = _Brd.Child;
            _Lbl = (Label)_Obj1;
            _Tag = int.Parse(_Brd.Tag.ToString());
        }
        switch (_Tag)
        {
            case 0:
                _Txt.Style = _MyUsDll._MyIsoUs.UsStylesProvider.GetStyle("TextBoxStyle");
                break;
            case 1:
                _Btn.Style = BtnExit.Style = _MyUsDll._MyIsoUs.UsStylesProvider.GetStyle("PlugInButton");
                break;
            case 2:
                _Lbl.Style = _MyUsDll._MyIsoUs.UsStylesProvider.GetStyle("LabelNameAxesStyle");
                break;
            case 3:

```

```
_Brd.Style = _MyUsDll._MyIsoUs.UsStylesProvider.GetStyle("BorderNameAxesStyle");  
_Lbl.Style = _MyUsDll._MyIsoUs.UsStylesProvider.GetStyle("LabelNameAxesStyle");  
break;  
case 4:  
_Brd.Style = _MyUsDll._MyIsoUs.UsStylesProvider.GetStyle("BorderStyle");  
_Lbl.Style = _MyUsDll._MyIsoUs.UsStylesProvider.GetStyle("LabelAbsStyle");  
break;  
}  
}  
}  
}  
}
```

The screenshot displays a CNC control interface with a golden background. At the top, it shows 'NrLoop' with a value of 50 and 'Current' with a value of 4. Below this, there is a 'Feed' section with a value of 10 and a 'Set Feed' button. The main area contains five rows of axis data, each with a label in a rounded button and a corresponding numerical value in a rounded rectangle:

Axis	Value
X	69.540
Y	69.540
Z	-13.908
A	41.724
B	13.908

At the bottom of the interface, there are three buttons: 'STOP', 'Run', and 'Exit'.

## 9 NSFORMS INSTRUCTIONS

**LIB.** Instructions are used for open the dialog windows (FORM) by Gcode.

This allows to prepare or condition the Gcode from **OBJECTS** insert in the **FORM**:

**BUTTON**

**LABEL**

**CHECK BOX**

**INPUT**

**TEXT BOX**

**COMBO BOX**

**SLIDER**

All objects can **READ** or **WRITE** Gcode variables.

All text messages used by Objects, if begin by prefix “@\_” can be get from dictionary “*UsLanguages.lang*” in the folder *\Languages*.

For a easy and visual programming of the **FORM**, is possible use the PlugIn **UsFormManager**.

## 9.1 LIB.MESSAGE

Show a MessageBox with specified mode.

The program is suspended up to executed action in MessageBox

### Syntax

**LIB.MESSAGE** "TEXT" "CAPTION" BUTTON ICON

#### TEXT

Body Message Text \N line feed carriage return

#### CAPTION

Message Title

#### BUTTON (value or variable)

0 OK  
1 YES - NO

#### ICON (value or variable)

0 ERROR  
1 WARNING  
2 INFORMATION  
3 QUESTION  
4 NONE

Ex:

```
LIB.MESSAGE "CONTINUE\NPART PROGRAM EXECUTION???" "WARNING!!!" 1 1
```

```
$BTN=${X13} // READ THE BUTTON PRESSED
```


```
IF $BTN=2
```

```
    END_PROGRAM // END PROGRAM IF PRESSED NO
```

```
END_IF
```

The LIB.MESSAGE instruction returned the code button pressed in the variable **\$(X13)**.  
this contain

- 0 → Button **OK** pressed
- 1 → Button **SI** pressed
- 2 → Button **NO** pressed



## 9.2 LIB.SHOWFORM

Show a NsForm. The properties must be set by **LIB.FORMPROP** instruction. The NsForm is in any case closed when the actual Part Program is finished.

**Only one NsForm is displayed**

**Syntax**

**LIB.SHOWFORM**

## 9.3 LIB.CLOSEFORM

Close a NsForm previously opened .

**Syntax**

**LIB.CLOSEFORM**

## 9.4 LIB.FORMPROP

Set the NsForm properties. The properties can be setted before a **LIB.SHOWFORM**

**Syntax**

**LIB.FORMPROP "PROPNAME" PROPVALUE (value or variable)**

**PROPNAME** (Property Name TEXT) :

**VISIBLE**

**PropValue 0** (or < ZERO) NsForm Invisible

**PropValue 1** (or > ZERO) NsForm Visible

**WIDTH**

**PropValue** > zero set **WIDTH** NSFORM

**HEIGHT**

**PropValue** > zero set **HEIGHT** NSFORM

**LEFT**

**PropValue** > zero Set the **LEFT** position

**TOP**

**PropValue** > zero Set the **TOP** position

**BACKCLOR**

**PropValue** Value 0 to 140.Set BACKCOLOR (see color table)

**STARTPOSITION (must be set before SHOWFORM)**

**PropValue 0** (o r< di ZERO) Use the **LEFT** e **TOP** position

**PropValue 1** (or > di ZERO) NsForm is centered on screen

**WINDOWSTATE**

**PropValue 0** (or < di ZERO) Use **WIDTH** e **HEIGHT** dimensions

**PropValue 1** (or > di ZERO) Use a Max dimension

**USESTYLE**

**PropValue 0** Use BackColor and ForeColor for form and all objects


**PropValue 1** use IsoUs Style for form and all objects

Ex:

```

LIB.FORMPROP "WIDTH" 400
LIB.FORMPROP "HEIGHT" 450
LIB.FORMPROP "LEFT" 748
LIB.FORMPROP "TOP" 293
LIB.FORMPROP "STARTPOSITION" 1
LIB.FORMPROP "WINDOWSTATE" 0
LIB.FORMPROP "BACKCOLOR" 134
LIB.FORMTEXT "UsForm1"
LIB.ADDLABEL "LbI0"
LIB.LABELPROP "LbI0" "WIDTH" 111
LIB.LABELPROP "LbI0" "HEIGHT" 34
LIB.LABELPROP "LbI0" "LEFT" 22
LIB.LABELPROP "LbI0" "TOP" 120
LIB.LABELPROP "LbI0" "DIMFONT" 18
LIB.LABELPROP "LbI0" "ALIGN" 1
LIB.LABELPROP "LbI0" "VISIBLE" 1
LIB.LABELPROP "LbI0" "ENABLED" 1
LIB.LABELPROP "LbI0" "COLORON" 113
LIB.LABELPROP "LbI0" "COLOROFF" 138
LIB.LABELTEXT "LbI0" "LABEL TEXT"
LIB.ADDITEXT "Txt0"
LIB.ITEXTPROP "Txt0" "WIDTH" 82
LIB.ITEXTPROP "Txt0" "HEIGHT" 36
LIB.ITEXTPROP "Txt0" "LEFT" 143
LIB.ITEXTPROP "Txt0" "TOP" 120
LIB.ITEXTPROP "Txt0" "DIMFONT" 21
LIB.ITEXTPROP "Txt0" "ALIGN" 1
LIB.ITEXTPROP "Txt0" "VISIBLE" 1
LIB.ITEXTPROP "Txt0" "ENABLED" 1
LIB.ITEXTPROP "Txt0" "AUTOSET" 1
LIB.ITEXTPROP "Txt0" "NDECIMAL" 3
LIB.ITEXTPROP "Txt0" "MIN" -2000000000
LIB.ITEXTPROP "Txt0" "MAX" 2000000000
LIB.ITEXTPROP "Txt0" "DEST" ${K15}
LIB.ITEXTSETVALUE "Txt0" ${K15}
LIB.ADDCHECK "Check0"
LIB.CHECKPROP "Check0" "WIDTH" 73
LIB.CHECKPROP "Check0" "HEIGHT" 46
LIB.CHECKPROP "Check0" "LEFT" 27
LIB.CHECKPROP "Check0" "TOP" 168
LIB.CHECKPROP "Check0" "DIMFONT" 12
LIB.CHECKPROP "Check0" "ALIGN" 1
LIB.CHECKPROP "Check0" "VISIBLE" 1
LIB.CHECKPROP "Check0" "AUTOSET" 1
LIB.CHECKPROP "Check0" "ENABLED" 1
LIB.CHECKSETVALUE "Check0" ${O10}
LIB.CHECKPROP "Check0" "DEST" ${O10}
LIB.CHECKTEXT "Check0" "ON/OFF"
LIB.ADDCOMBO "Combo0"
LIB.COMBOPROP "Combo0" "WIDTH" 129
LIB.COMBOPROP "Combo0" "HEIGHT" 34
LIB.COMBOPROP "Combo0" "LEFT" 144
LIB.COMBOPROP "Combo0" "TOP" 161
    
```

LIB.FORMPROP "USESTYLE" 0



LIB.FORMPROP "USESTYLE" 1



```

LIB.COMBOPROP "Combo0" "ALIGN" 1
LIB.COMBOPROP "Combo0" "VISIBLE" 1
LIB.COMBOPROP "Combo0" "ENABLED" 1
LIB.COMBOPROP "Combo0" "AUTOSET" 1
LIB.COMBOPROP "Combo0" "FOREGROUND" 19
LIB.COMBOPROP "Combo0" "DEST" $VAR1
LIB.COMBOSETVALUE "Combo0" 2
LIB.COMBOITEM "Combo0" "COMBO ITEM 10" 1
LIB.COMBOITEM "Combo0" "COMBO ITEM 20" 2
LIB.COMBOITEM "Combo0" "COMBO ITEM 30" 3
LIB.ADDSLIDER "Slider0"
LIB.SLIDERPROP "Slider0" "WIDTH" 200
LIB.SLIDERPROP "Slider0" "HEIGHT" 35
LIB.SLIDERPROP "Slider0" "LEFT" 101
LIB.SLIDERPROP "Slider0" "TOP" 237
LIB.SLIDERPROP "Slider0" "DIMFONT" 16
LIB.SLIDERPROP "Slider0" "VISIBLE" 1
LIB.SLIDERPROP "Slider0" "VISLABEL" 1
LIB.SLIDERPROP "Slider0" "ENABLED" 1
LIB.SLIDERPROP "Slider0" "AUTOSET" 1
LIB.SLIDERPROP "Slider0" "NDECIMAL" 3
LIB.SLIDERPROP "Slider0" "TICKP" 3
LIB.SLIDERPROP "Slider0" "TICKF" 10
LIB.SLIDERPROP "Slider0" "MIN" 1
LIB.SLIDERPROP "Slider0" "MAX" 100
LIB.SLIDERPROP "Slider0" "LARGE" 10
LIB.SLIDERPROP "Slider0" "SMALL" 1
LIB.SLIDERPROP "Slider0" "DEST" $PIPP01
LIB.SLIDERSETVALUE "Slider0" 0
LIB.ADDBUTTON "Btn0"
LIB.BUTTONPROP "Btn0" "WIDTH" 60
LIB.BUTTONPROP "Btn0" "HEIGHT" 40
LIB.BUTTONPROP "Btn0" "LEFT" 28
LIB.BUTTONPROP "Btn0" "TOP" 18
LIB.BUTTONPROP "Btn0" "DIMFONT" 12
LIB.BUTTONPROP "Btn0" "ALIGN" 1
LIB.BUTTONPROP "Btn0" "CLOSEFORM" 0
LIB.BUTTONPROP "Btn0" "VISIBLE" 1
LIB.BUTTONPROP "Btn0" "ENABLED" 1
LIB.BUTTONPROP "Btn0" "INPUTUPDATE" 0
LIB.BUTTONPROP "Btn0" "DEST" $VAR1
LIB.BUTTONPRINT "Btn0" "I" @VART
LIB.BUTTONPROP "Btn0" "COLORON" 113
LIB.BUTTONPROP "Btn0" "COLOROFF" 138
LIB.ADDINPUT "Input0"
LIB.INPUTPROP "Input0" "WIDTH" 120
LIB.INPUTPROP "Input0" "HEIGHT" 40
LIB.INPUTPROP "Input0" "LEFT" 29
LIB.INPUTPROP "Input0" "TOP" 71
LIB.INPUTPROP "Input0" "DIMFONT" 16
LIB.INPUTPROP "Input0" "ALIGN" 1
LIB.INPUTPROP "Input0" "VISIBLE" 1
LIB.INPUTPROP "Input0" "ENABLED" 1
LIB.INPUTPROP "Input0" "AUTOSET" 1
LIB.INPUTPROP "Input0" "NDECIMAL" 3
LIB.INPUTPROP "Input0" "MIN" -2000000000
LIB.INPUTPROP "Input0" "MAX" 2000000000
LIB.INPUTPROP "Input0" "INCREMENT" 1
LIB.INPUTPROP "Input0" "DEST" $PIPP0
LIB.INPUTSETVALUE "Input0" 100
LIB.ADDLABEL "Lbl1"
LIB.LABELPROP "Lbl1" "WIDTH" 49
LIB.LABELPROP "Lbl1" "HEIGHT" 26
LIB.LABELPROP "Lbl1" "LEFT" 37
LIB.LABELPROP "Lbl1" "TOP" 329
LIB.LABELPROP "Lbl1" "DIMFONT" 18
LIB.LABELPROP "Lbl1" "ALIGN" 1
LIB.LABELPROP "Lbl1" "VISIBLE" 1
LIB.LABELPROP "Lbl1" "ENABLED" 1
LIB.LABELF "Lbl1" "B" ${O10}
LIB.LABELPROP "Lbl1" "TIMER" 200
LIB.LABELPROP "Lbl1" "COLORON" 113
LIB.LABELPROP "Lbl1" "COLOROFF" 138
LIB.ADDBUTTON "Btn1"
LIB.BUTTONPROP "Btn1" "WIDTH" 60
LIB.BUTTONPROP "Btn1" "HEIGHT" 40
LIB.BUTTONPROP "Btn1" "LEFT" 142
LIB.BUTTONPROP "Btn1" "TOP" 19
LIB.BUTTONPROP "Btn1" "DIMFONT" 12
LIB.BUTTONPROP "Btn1" "ALIGN" 1
LIB.BUTTONPROP "Btn1" "CLOSEFORM" 1
LIB.BUTTONPROP "Btn1" "VISIBLE" 1
LIB.BUTTONPROP "Btn1" "ENABLED" 1
LIB.BUTTONPROP "Btn1" "INPUTUPDATE" 0
LIB.BUTTONPROP "Btn1" "COLORON" 113
LIB.BUTTONPROP "Btn1" "COLOROFF" 138
LIB.BUTTONTEXT "Btn1" "(@)EXIT"
LIB.SHOWFORM

```



## 9.5 LIB.FORMTEXT

Set the NsForm Caption. The properties can be setted befor a LIB.SHOWFORM

### *Syntax*

**LIB.FORMTEXT "CAPTION"**

**CAPTION** (TEXT) :

Text of Caption

**Ex:**

LIB.FORMTEXT "CAPTION"

## 9.6 LIB.ADDLABEL

Add a NsLabel to NsForm. The NsLabel properties can be setted befor a LIB.SHOWFORM

### *Syntax*

**LIB.ADDLABEL "NAME"**

**NAME** (TEXT) :

Univocal Name of NsLabel Whitout special characters

**Ex:**

LIB.ADDLABEL "LBL"

## 9.7 LIB.LABELPROP

Set the NsLabel properties. The properties can be setted before a **LIB.SHOWFORM** but before, is necessary that the NsLabel is added to NsForm with **LIB.ADDLABEL**

### *Syntax*

**LIB.LABELPROP "LBLNAME" "PROPNAME" PROPVALUE (value or variable)**

**LBLNAME** NsLabel Name

**PROPNAME** (Property Name TEXT) :

#### **VISIBLE**

**PropValue 0** (< of ZERO) NsLabel Invisible

**PropValue 1** (> of ZERO) NsLabel Visible (default)

#### **AUTOSIZE**

**PropValue 0** (< of ZERO) NsLabel dimension by WHIDTH e HEIGHT

**PropValue 1** (> of ZERO) NsLabel automatic dimension (default)

#### **ENABLED**

**PropValue 0** (< of ZERO) NsLabel enabled (default)

**PropValue 1** (> of ZERO) NsLabel disabled

#### **WIDTH**

**PropValue** > zero NsLabel Width (if autosize = 0)

#### **HEIGHT**

**PropValue** > zero NsLabel Height (if autosize = 0)

#### **LEFT**

**PropValue** > zero NsLabel Left position in NsForm

#### **TOP**

**PropValue** > zero NsLabel Top position in NsForm

#### **DIMFONT**

**PropValue** Value 6 to 100. Font Dimension

**BACKCLOR**

**PropValue** Value 0 to 140.Set BACKCOLOR (see color table)

**FORECOLOR**

**PropValue** Value 0 to 140.Set FORECOLOR (see color table)

**COLORON**

**PropValue** Value 0 to 140.Set color ON for ON/OFF format (LABELF – LABELPRINT)

**COLOROFF**

**PropValue** Value 0 to 140.Set color OFF for ON/OFF format (LABELF – LABELPRINT)

**STYLE** (default 0)

**PropValue:**

**0** Normal                      **1** *Medium*                      **2** **Bold**                      **3** **Ultra Bold**

**ALIGN** (default 0)

**PropValue:**

**0** Middle Left                      **1** Middle Center                      **2** Middle Right  
**3** Top Left                      **4** Top Center                      **5** Top Right  
**6** Bottom Left                      **7** Bottom Center **8** Bottom Right

**BORDER** (default 0)

**PropValue:**

**0** None                      **1** *Fixed Single*                      **2** *Fixed 3D*

**TIMER** (default 0)

**PropValue** > zero(millisecond) enable the print by **TIMER** for **LABELF**

**Ex:**

```
LIB.FORMPROP "WIDTH" 500
LIB.FORMPROP "HEIGHT" 300
LIB.FORMPROP "STARTPOSITION" 1
LIB.FORMTEXT "TEST LABEL"
LIB.ADDLABEL "LBL"
LIB.LABELPROP "LBL" "AUTOSIZE" 0
LIB.LABELPROP "LBL" "WIDTH" 100
LIB.LABELPROP "LBL" "HEIGHT" 50
LIB.LABELPROP "LBL" "LEFT" 5
LIB.LABELPROP "LBL" "TOP" 10
LIB.LABELPROP "LBL" "DIMFONT" 12
LIB.LABELPROP "LBL" "ALIGN" 0
LIB.LABELPROP "LBL" "BACKCOLOR" 9
LIB.LABELPROP "LBL" "FORECOLOR" 137
LIB.LABELTEXT "LBL" "MY LABEL"
LIB.SHOWFORM
```

**9.8 LIB.LABELTEXT**

Write a Text in to NsLabel

**Syntax**

**LIB.LABELTEXT** "**LBLNAME**" "**TEXT**"

**LBLNAME** NsLabel Name

**TEXT** NsLabel Text

### 9.9 LIB.LABELPRINT

Write a Isous Variable in to NsLabel

VAR Type: \$,.,\$(I), \$(O), \$(Q), \$(R), \$(P), \$(E), \$(S), \$(U), \$(X), \$(Y), \$(W), \$(K)

**Syntax**

**LIB.LABELPRINT "LBLNAME" "FORMAT" VAR**


**LBLNAME** NsLabel Name


**FORMAT** Print Format:

- "B" ON/OFF show COLORON-COLOROFF if USESTYLE=0, or the standard image of IsoUs LED ON/OFF
- "I" Only Integer value
- "Fndec" Number of decimal

B (USESTYLE=1)  (off)  (on)

B (USESTYLE=0)  (COLOROFF)  (COLORON)

I 

F3 

### 9.10 LIB.LABELF

Set the FORMAT for PRINT VAR BY TIMER

**Syntax**

**LIB.LABELF "LBLNAME" "FORMAT" VAR**

**LBLNAME** NsLabel Name

**FORMAT** Print Format:

- "B" ON/OFF show COLORON-COLOROFF if USESTYLE=0, or the standard image of IsoUs LED ON/OFF
- "I" Only Integer value
- "Fndec" Number of decimal

VAR Type: \$,.,\$(I), \$(O), \$(Q), \$(R), \$(P), \$(E), \$(S), \$(U), \$(X), \$(Y), \$(W), \$(K)

### 9.11 LIB.ADDBUTTON

Add a NsButton to NsForm. The NsButton properties can be setted before a LIB.SHOWFORM

**Syntax**

**LIB.ADDBUTTON "NAME"**

**NAME** (TEXT) :

Univocal Name of NsButton Whitout special characters

**Ex:**

LIB.ADDBUTTON "BTN"

## 9.12 LIB.BUTTONPROP

Set the NsButton properties. The properties can be set before a **LIB.SHOWFORM** but before, is necessary that the NsButton is added to NsForm with **LIB.AddbUTTON**

### Syntax

**LIB.BUTTONPROP "BTNNAME" "PROPNAME" PROPVALUE (value or variable)**

**BTNNAME** NsButton Name

**PROPNAME** (Property Name TEXT) :

### VISIBLE

**PropValue 0** (< of ZERO) NsButton Invisible

**PropValue 1** (> of ZERO) NsButton Visible (default)

### ENABLED

**PropValue 0** (< of ZERO) NsButton enabled (default)

**PropValue 1** (> of ZERO) NsButton disabled

### WIDTH

**PropValue** > zero NsButton Width

### HEIGHT

**PropValue** > zero NsButton Height

### LEFT

**PropValue** > zero NsButton Left position in NsForm

### TOP

**PropValue** > zero NsButton Top position in NsForm

### DIMFONT

**PropValue** Value 6 to 100. Font Dimension

### BACKCLOR

**PropValue** Value 0 to 140. Set BACKCOLOR (see color table)

### FORECOLOR

**PropValue** Value 0 to 140. Set FORECOLOR (see color table)

### COLORON

**PropValue** Value 0 to 140. Set color ON for ON/OFF format (BUTTONF – BUTTONPRINT)

### COLOROFF

**PropValue** Value 0 to 140. Set color OFF for ON/OFF format (BUTTONF – BUTTONPRINT)

### STYLE (default 0)

**PropValue:**

**0** Normal

**1** Medium

**2** Bold

**3** Ultra Bold

### ALIGN (default 1)

**PropValue:**

**0** Middle Left

**1** Middle Center

**2** Middle Right

**3** Top Left

**4** Top Center

**5** Top Right

**6** Bottom Left

**7** Bottom Center

**8** Bottom Right

### DEST

*Destination variable writing. Indicates the destination variable where the value is written to Source*

VAR Type: \$, :, \$[O], \$[P], \$[K], \$[A]

### SOURCE

Source variable. Value to write to DEST

When you press the value of the source variable is written to DEST.

VAR Type: \$, :, \$[I], \$[O], \$[Q], \$[R], \$[P], \$[E], \$[S], \$[U], \$[X], \$[Y], \$[W], \$[K]

### CLOSEFORM (default 0)

**PropValue 0** (o < of ZERO) When press the NsForm is Not closed

**PropValue 1** (o > of ZERO) When press the NsForm is closed

**TIMER** (default 0)

**PropValue** > zero(milliseconds) enable the print by **TIMER** for **BUTTONF**

**INPUTUPDATE** (default 0)

**PropValue** =1 when click all INPUT objects in yhe Form, (ITEXT,INPUT,ICHECK) update the destination VAR

### 9.13 LIB.BUTTONTEXT

Write a Text in to NsButton

**Syntax**

**LIB.BUTTONTEXT** "BTNNAME" "TEXT"

**LBLNAME** NsButton Name

**TEXT** NsButton Text

If the TEXT has the prefix (@)text, is showed the image **text.png** saved in **\DataForm\Images**

**LIB.BUTTONTEXT** "BTNNAME" "EXIT"



**LIB.BUTTONTEXT** "BTNNAME" "(@)EXIT"



(image **Exit.png** saved in **\DataForm\Images**)

### 9.14 LIB.BUTTONPRINT

Write a Isous Variable in to NsButton

**Syntax**

**LIB.BUTTONPRINT** "BTNNAME" "FORMAT" \$VAR

**BTNNAME** NsButton Name

**FORMAT** Print Format:

- "B" ON/OFF show **COLORON-COLOROFF** if **USESTYLE=0**, or the standard image of IsoUs LED ON/OFF
- "I" Only Integer value
- "Fndec" Number of decimal

B (USESTYLE=1)		(off)		(on)
B (USESTYLE=0)		(COLOROFF)		(COLORON)
I				
F3				

## 9.15 LIB.BUTTONF

Set the FORMAT for PRINT VAR BY TIMER

### Syntax

**LIB.BUTTONF** "BTNNAME" "FORMAT" VAR

**BTNNAME** Button Name

**FORMAT** Print Format:

"B" ON/OFF show **COLORON-COLOROFF** if **USESTYLE=0**, or the standard image of **ISOUs LED ON/OFF**

"I" Only Integer value

"Fndec" Number of decimal

VAR Type: \$,.;,\$[I], \$[O], \$[Q], \$[R], \$[P], \$[E], \$[S], \$[U], \$[X], \$[Y], \$[W], \$[K]

## 9.16 LIB.ADDINPUT

Add a NsInput to NsForm. The NsInput properties can be set before a LIB.SHOWFORM  
The NsInput Object is used to write numerical value to Isous variable

### Syntax


**LIB.ADDINPUT** "NAME"

**NAME** (TEXT) :

Univocal Name of NsInput Without special characters

Ex:

LIB.ADDINPUT "INP"



Button **SET** when pressed writes the value in Isous variable identified in "**DEST**"  
If **AUTOSET=1** the value is automatically written when this is changed

## 9.17 LIB.INPUTPROP

Set the NsInput properties. The properties can be set before a **LIB.SHOWFORM** but before, is necessary that the NsInput is added to NsForm.

### Syntax

**LIB.INPUTPROP** "INPNAME" "PROPNAME" PROPVALUE (value or variable)

**INPNAME** NsInput Name

**PROPNAME** (Property Name TEXT) :

#### VISIBLE

**PropValue 0** (< of ZERO) NsInput Invisible

**PropValue 1** (> of ZERO) NsInput Visible (default)

#### ENABLED

**PropValue 0** (< of ZERO) NsInput enabled (default)

**PropValue 1** (> of ZERO) NsInput disabled

#### WIDTH

**PropValue** > zero NsInput Width

**LEFT**

**PropValue** > zero NsInput Left position in NsForm

**TOP**

**PropValue** > zero NsInput Top position in NsForm

**DIMFONT**

**PropValue** Value 6 to 100. Font Dimension

**BACKCLOR**

**PropValue** Value 0 to 140. Set BACKCOLOR (see color table)

**FORECOLOR**

**PropValue** Value 0 to 140. Set FORECOLOR (see color table)

**ALIGN** (default 0)

**PropValue:**

**0** Left                    **1** Center                    **2** Right

**DEST**

*Destination variable writing. Indicates the destination variable where the value is written*

VAR Type:        \$,.,\$[O],\$[P],\$[K], \$[A]

**MIN**

**PropValue** Minimum value accepted (double)

**MAX**

**PropValue** Maximum value accepted (double)

**NDECIMAL**

**PropValue** > zero Number of decimals displayed

**INCREMENT**

**PropValue** Increment value when pressed **up** - **down** buttons (double)

**AUTOSET**

**PropValue 0** (< ZERO) The value is writes when pressed the button SET

**PropValue 1** (> ZERO) The value is automatically writes when this changed

VAR Type:        \$,.,\$[O],\$[P],\$[K], \$[A]

## 9.18 LIB.INPUTSETVALUE

Set the initial value of NsInput

**Syntax**

**LIB.INPUTSETVALUE "INPNAME" VAR**

**INPNAME** NsInput Name

VAR Type:        **NUM**,\$,.,\$[I], \$[O], \$[Q], \$[R], \$[P], \$[E], \$[S], \$[U], \$[X], \$[Y], \$[W], \$[K]

**Ex:**

\$VAR=103.2569

LIB.**INPUTSETVALUE** "INP" \$VAR **//SET VALUE AT 103.2569**



## 9.19 LIB.ADDITEXT

Add an ITEXT to NsForm. The ITEXT properties can be setted before a LIB.SHOWFORM  
The ITEXT Object is used to write numerical value to Isous variable

### Syntax

**LIB.ADDITEXT "NAME"**

**NAME** (TEXT) :

Univocal Name of ITEXT without special characters

**Ex:**

LIB.ADDITEXT "TEXT1"

## 9.20 LIB.ITEXTPROP

Set the ITEXT properties. The properties can be setted before a **LIB.SHOWFORM** but before, is necessary that the ITEXT is added to NsForm.

### Syntax

**LIB.ITEXTPROP "TXTNAME" "PROPNAME" PROPVALUE (value or variable)**

**TEXTNAME** ITEXT Name

**PROPNAME** (Property Name TEXT) :

#### VISIBLE

**PropValue 0** (< of ZERO) ITEXT Invisible

**PropValue 1** (> of ZERO) ITEXT Visible (default)

#### ENABLED

**PropValue 0** (< of ZERO) ITEXT enabled (default)

**PropValue 1** (> of ZERO) ITEXT disabled

#### WIDTH

**PropValue** > zero ITEXT Width

#### HEIGHT

**PropValue** > zero ITEXT Height

#### LEFT

**PropValue** > zero ITEXT Left position in NsForm

#### TOP

**PropValue** > zero ITEXT Top position in NsForm

#### DIMFONT

**PropValue** Value 6 to 100. Font Dimension

#### BACKCLOR

**PropValue** Value 0 to 140. Set BACKCOLOR (see color table)

#### FORECOLOR

**PropValue** Value 0 to 140. Set FORECOLOR (see color table)

#### ALIGN (default 0)

**PropValue:**

**0** Left                    **1** Center                    **2** Right

#### DEST

*Destination variable writing. Indicates the destination variable where the value is written*

VAR Type:            \$,.,\$[O],\$[P],\$[K], \$[A]

#### MIN

**PropValue** Minimum value accepted (double)

#### MAX

**PropValue** Maximum value accepted (double)

#### NDECIMAL

**PropValue** > zero Number of decimals displayed

**AUTOSET**

**PropValue 0** (< ZERO) The value is writes when pressed a BUTTON with UPDATEINPUT

**PropValue 1** (> ZERO) The value is automatically writes when is pressed CR

**9.21 LIB.ITEXTSETVALUE**

Set the initial value of ITEXT

**Syntax**

**LIB.ITEXTSETVALUE "TXTNAME" VAR**

**TXTNAME** ITEXT Name

**VAR** Type: **NUM,\$,,\$[I], \$[O], \$[Q], \$[R], \$[P], \$[E], \$[S], \$[U], \$[X], \$[Y], \$[W], \$[K]**

**Ex:**

\$VAR=103.2569

**LIB.ITEXTSETVALUE** "TEXT" \$VAR //SET VALUE AT 103.2569

**9.22 LIB.ADDCHECK**

Add an CHECK to NsForm. The CHECK properties can be setted before a LIB.SHOWFORM

The CHECK Object is used to write a ON/OFF value

**Syntax**

**LIB.ADDCHECK "NAME"**

**NAME** (TEXT) :

Univocal Name of CHECK without special characters

**Ex:**

**LIB.ADDCHECK** "CHECK1"

**9.23 LIB.CHECKPROP**

Set the CHECK properties. The properties can be setted before a **LIB.SHOWFORM** but before, is necessary that the CHECK is added to NsForm.

**Syntax**

**LIB.CHECKPROP "CHECKNAME" "PROPNAME" PROPVALUE (value or variable)**

**CHECKNAME** CHECK Name

**PROPNAME** (Property Name TEXT) :

**VISIBLE**

**PropValue 0** (< of ZERO) CHECK Invisible

**PropValue 1** (> of ZERO) CHECK Visible (default)

**ENABLED**

**PropValue 0** (< of ZERO) CHECK enabled (default)

**PropValue 1** (> of ZERO) CHECK disabled

**WIDTH**

**PropValue** > zero CHECK Width

**HEIGHT**

**PropValue** > zero CHECK Height

**LEFT**

**PropValue** > zero CHECK Left position in NsForm

**TOP**

**PropValue** > zero CHECK Top position in NsForm

**DIMFONT**

**PropValue** Value 6 to 100. Font Dimension

**BACKCLOR**

**PropValue** Value 0 to 140. Set BACKCOLOR (see color table)

**FORECOLOR**

**PropValue** Value 0 to 140. Set FORECOLOR (see color table)

**ALIGN** (default 0)

**PropValue:**

**0** Left                    **1** Center                    **2** Right

**DEST**

*Destination variable writing. Indicates the destination variable where the value is written*

VAR Type:        \$, :, \$[O], \$[P], \$[K], \$[A]

**AUTOSET**

**PropValue 0** (< ZERO) The value is writes when pressed a BUTTON with UPDATEINPUT

**PropValue 1** (> ZERO) The value is automatically writes when CLICK

**9.24 LIB.CHECKSETVALUE**

Set the initial value of CHECK

**Syntax**

**LIB.CHECKSETVALUE "CHECKNAME" VAR**

**CHECKNAME** CHECK Name

VAR Type:        NUM, \$, :, \$[I], \$[O], \$[Q], \$[R], \$[P], \$[E], \$[S], \$[U], \$[X], \$[Y], \$[W], \$[K]

**Ex:**

\$VAR=1

LIB.**CHECKTSETVALUE** "CHECK" \$VAR //SET VALUE AT 1 CHECK CHECKED

**9.25 LIB.CHECKTEXT**

Caption Check

**Syntax**

**LIB.CHECKTEXT "CHECKNAME" "TEXT"**

**CHECKNAME** CHECK Name

**TEXT** Check Caption Text

## 9.26 LIB.ADDCOMBO

Add an COMBO to NsForm. The COMBO properties can be set before a LIB.SHOWFORM  
The COMBO Object is used to write a ON/OFF value

### Syntax

**LIB.ADDCOMBO "NAME"**

**NAME** (TEXT) :

Univocal Name of COMBO without special characters

**Ex:**

LIB.ADDCOMBO "COMBO1"

## 9.27 LIB.COMBOPROP

Set the COMBO properties. The properties can be set before a LIB.SHOWFORM but before, is necessary that the COMBO is added to NsForm.

### Syntax

**LIB.COMBOPROP "COMBONAME" "PROPNAME" PROPVALUE (value or variable)**

**COMBONAME** COMBO Name

**PROPNAME** (Property Name TEXT) :

#### VISIBLE

**PropValue 0** (< of ZERO) COMBO Invisible

**PropValue 1** (> of ZERO) COMBO Visible (default)

#### ENABLED

**PropValue 0** (< of ZERO) COMBO enabled (default)

**PropValue 1** (> of ZERO) COMBO disabled

#### WIDTH

**PropValue** > zero COMBO Width

#### HEIGHT

**PropValue** > zero COMBO Height

#### LEFT

**PropValue** > zero COMBO Left position in NsForm

#### TOP

**PropValue** > zero COMBO Top position in NsForm

#### DIMFONT

**PropValue** Value 6 to 100. Font Dimension

#### FORECOLOR

**PropValue** Value 0 to 140. Set FORECOLOR (see color table)

#### ALIGN (default 0)

**PropValue:**

**0** Left                    **1** Center                    **2** Right

#### DEST

*Destination variable writing. Indicates the destination variable where the value is written*

VAR Type:        \$,.,\$[O],\$[P],\$[K], \$[A]

#### AUTOSET

**PropValue 0** (< ZERO) The value is written when pressed a BUTTON with UPDATEINPUT

**PropValue 1** (> ZERO) The value is automatically written when the ITEM is SELECTED

## 9.28 LIB.COMBOSETVALUE

Set the initial value of COMBO

### *Syntax*

**LIB.COMBOSETVALUE "COMBONAME" VAR**

**COMBONAME** COMBO Name

VAR Type: **NUM,\$,:**

### **Ex:**

\$VAR=2

LIB.**COMBOSETVALUE** "COMBO" \$VAR *//SET VALUE to ITEM 2*

## 9.29 LIB.COMBOITEM

Add an ITEM to COMBO

### *Syntax*

**LIB.COMBOITEM "COMBONAME" "ITEMNAME" VAR**

**COMBONAME** COMBO Name

**ITEMNAME** ITEM Text

**VAR** value for ITEM

VAR Type: **NUM,\$,:**

### **Ex:**

LIB.**COMBOITEM** "COMBO" "ITEM 1" 1 *//ITEM 1 VALUE 1*

LIB.**COMBOITEM** "COMBO" "ITEM 2" 2 *//ITEM 2 VALUE 2*

LIB.**COMBOITEM** "COMBO" "ITEM 3" 3 *//ITEM 3 VALUE 3*

### 9.30 LIB.ADDSLIDER

Add an SLIDER to NsForm. The SLIDER properties can be setted before a LIB.SHOWFORM  
The SLIDER Object is used to write numerical value to Isous variable

#### *Syntax*

#### **LIB.ADDSLIDER "NAME"**

**NAME** (TEXT) :

Univocal Name of SLIDER without special characters

**Ex:**

LIB.ADDSLIDER "SLIDER1"

### 9.31 LIB.SLIDERPROP

Set the SLIDER properties. The properties can be setted before a **LIB.SHOWFORM** but before, is necessary that the SLIDER is added to NsForm.

#### *Syntax*

#### **LIB.SLIDERPROP "SLIDERNAME" "PROPNAME" PROPVALUE (value or variable)**

**SLIDERNAME** SLIDER Name

**PROPNAME** (Property Name TEXT) :

#### **VISIBLE**

**PropValue 0** (< of ZERO) SLIDER Invisible

**PropValue 1** (> of ZERO) SLIDER Visible (default)

#### **ENABLED**

**PropValue 0** (< of ZERO) SLIDER enabled (default)

**PropValue 1** (> of ZERO) SLIDER disabled

#### **VISLABEL**

**PropValue 0** (< of ZERO) LABEL SLIDER Invisible

**PropValue 1** (> of ZERO) LABEL SLIDER Visible (default)

#### **WIDTH**

**PropValue** > zero SLIDER Width

#### **HEIGHT**

**PropValue** > zero SLIDER Height

#### **LEFT**

**PropValue** > zero SLIDER Left position in NsForm

#### **TOP**

**PropValue** > zero ITEXT Top position in NsForm

#### **DIMFONT**

**PropValue** Value 6 to 100. Font Dimension

#### **BACKCLOR**

**PropValue** Value 0 to 140. Set BACKCOLOR (see color table)

#### **FORECOLOR**

**PropValue** Value 0 to 140. Set FORECOLOR (see color table)

#### **LARGE**

**PropValue** defines the quantity of variation when the slider bar has a large change

#### **SMALL**

**PropValue** defines the quantity of variation when the slider bar has a small change

#### **TICKP**

**PropValue** Sign position:

**0** None      **1** TopLeft      **2** BottomRight      **3** Both

#### **TICKF**

**PropValue** Sign frequency

**DEST**

*Destination variable writing. Indicates the destination variable where the value is written*

VAR Type:       **\$,.\$[O],[P],[K], [A]**

**MIN**

**PropValue** Minimum value accepted (double)

**MAX**

**PropValue** Maximum value accepted (double)

**NDECIMAL**

**PropValue** > zero Number of decimals displayed

**AUTOSET**

**PropValue 0** (< ZERO) The value is writes when pressed a BUTTON with UPDATEINPUT

**PropValue 1** (> ZERO) The value is automatically writes when the bar change

**9.32 LIB.SLIDERSETVALUE**

Set the initial value of SLIDER

**Syntax**

**LIB.SLIDERSETVALUE "SLIDERNAME" VAR**

**SLIDERNAME** SLIDER Name

VAR Type:       **NUM,\$,.\$[I], [O], [Q], [R], [P], [E], [S], [U], [X], [Y], [W], [K]**

**Ex:**

\$VAR=103

LIB.**SLIDERSETVALUE** "SLIDER" \$VAR //SET VALUE AT 103

### 9.33 LIB.GETVAR

Allows to read a FORM variable (double) in a IsoUs Variable.

The FORM variables are proprietary of FORM in use (MAX 1000 Variables)

**The Variable 999 contains the status FORM**

**999=1 Form Open      999=0 Form Closed**

#### Syntax

#### LIB.GETVAR SOURCEINDEX DEST

**SOURCEINDEX** Form Variable Index to Read (0 -999), can be a number or a IsoUs variable.

**DEST** IsoUs variable destination

Ex:

```
$VARFORM=100
```

```
LIB.GETVAR $VARFORM $VAR //READ FORM VAR 100 IN $VAR
```

```
LIB.GETVAR 10 $VAR // READ FORM VAR 10 IN $VAR
```

### 9.34 LIB.SETVAR

Allows to write a FORM variable (double) by a IsoUs Variable.

The FORM variables are proprietary of FORM in use (MAX 1000 Variables)

#### Syntax

#### LIB.SETVAR DESTINDEX SOURCE

**DESTINDEX** Form Variable Index to Write (0 -999), can be a number or a IsoUs variable.

**SOURCE** IsoUs source Var

Ex:

```
$VARFORM=100
```

```
$SOURCE=10.123
```

```
LIB.SETVARVAR $VARFORM $ SOURCE //WRITE FORM VAR 100 TO VALUE 10.123
```

```
LIB.SETVAR 10 $ SOURCE // WRITE FORM VAR 10 TO VALUE 10.123
```

### 9.35 LIB.DEBUG

Allows to write in a Window by Gcode, informations for Debug

#### Syntax

#### LIB.DEBUG "TEXT" VAR

**TEXT** Text to write

**VAR** Variable to write

Ex:

```
$VAR=10
```


```
LIB.DEBUG "DEBUG TEST 1" $VAR
```

```
$VAR=15
```

```
LIB.DEBUG "DEBUG TEST 2" $VAR
```

```
$VAR=20
```




```
LIB.DEBUG "DEBUG TEST 3" $VAR
```



































### 9.36 COLOR TABLE

Following color table to refer when the property is a color

0	ALICEBLUE		35	DARKSLATEGRAY		70	LIGHTSALMON	
1	ANTIQUEWHITE		36	DARKTURQUOISE		71	LIGHTSEAGREEN	
2	AQUA		37	DARKVIOLET		72	LIGHTSKYBLUE	
3	AQUAMARINE		38	DEEPPINK		73	LIGHTSLATEGRAY	
4	AZURE		39	DEEPSKYBLUE		74	LIGHTSTEELBLUE	
5	BEIGE		40	DIMGRAY		75	LIGHTYELLOW	
6	BISQUE		41	DODGERBLUE		76	LIME	
7	BLACK		42	FIREBRICK		77	LIMEGREEN	
8	BLANCHEDALMOND		43	FLORALWHITE		78	LINEN	
9	BLUE		44	FORESTGREEN		79	MAGENTA	
10	BLUEVIOLET		45	FUCHSIA		80	MAROON	
11	BROWN		46	GAINSBORO		81	MEDIUMAQUAMARINE	
12	BURLYWOOD		47	GHOSTWHITE		82	MEDIUMBLUE	
13	CADETBBLUE		48	GOLD		83	MEDIUMORCHID	
14	CHARTREUSE		49	GOLDENROD		84	MEDIUMPURPLE	
15	CHOCOLATE		50	GRAY		85	MEDIUMSEAGREEN	
16	CORAL		51	GREEN		86	MEDIUMSLATEBLUE	
17	CORNFLOWERBLUE		52	GREENYELLOW		87	MEDIUMSPRINGGREEN	
18	CORNSILK		53	HONEYDEW		88	MEDIUMTURQUOISE	
19	CRIMSON		54	HOTPINK		89	MEDIUMVIOLETRED	
20	CYAN		55	INDIANRED		90	MIDNIGHTBLUE	
21	DARKBLUE		56	INDIGO		91	MINTCREAM	
22	DARKCYAN		57	IVORY		92	MISTYROSE	
23	DARKGOLDENROD		58	KHAKI		93	MOCCASIN	
24	DARKGRAY		59	LAVENDER		94	NAVAJOWHITE	
25	DARKGREEN		60	LAVENDERBLUSH		95	NAVY	
26	DARKKHAKI		61	LAWNGREEN		96	OLDLACE	
27	DARKMAGENTA		62	LEMONCHIFFON		97	OLIVE	
28	DARKLIVEGREEN		63	LIGHTBLUE		98	OLIVEDRAB	
29	DARKORANGE		64	LIGHTCORAL		99	ORANGE	
30	DARKORCHID		65	LIGHTCYAN		100	ORANGERED	
31	DARKRED		66	LIGHTGOLDENRODYELLOW		101	ORCHID	
32	DARKSALMON		67	LIGHTGRAY		102	PALEGOLDENROD	
33	DARKSEAGREEN		68	LIGHTGREEN		103	PALEGREEN	
34	DARKSLATEBLUE		69	LIGHTPINK		104	PALETURQUOISE	

105	PALEVIOLETRED		140	YELLOWGREEN	
106	PAPAYAWHIP				
107	PEACHPUFF				
108	PERU				
109	PINK				
110	PLUM				
111	POWDERBLUE				
112	PURPLE				
113	RED				
114	ROSYBROWN				
115	ROYALBLUE				
116	SADDLEBROWN				
117	SALMON				
118	SANDYBROWN				
119	SEAGREEN				
120	SEASHELL				
121	SIENNA				
122	SILVER				
123	SKYBLUE				
124	SLATEBLUE				
125	SLATEGRAY				
126	SNOW				
127	SPRINGGREEN				
128	STEELBLUE				
129	TAN				
130	TEAL				
131	THISTLE				
132	TOMATO				
133	TRANSPARENT				
134	TURQUOISE				
135	VIOLET				
136	WHEAT				
137	WHITE				
138	WHITESMOKE				
139	YELLOW				

## 10 COMPILATOR SWITCH

The compiler switch, allows to give some directives to compiler by the constructs:

**IFDEF**  
**ELSEDEF**  
**ENDIFDEF**

This allow to compile only the code which is part of the logic of switch selected.

Currently is available only one system switch:

### AXES

It contains the number of Axes configured in the IsoUs application:

Ex: for 3 AXES configuration

```
IFDEF AXES=3 // AXES NUMBER=3
```

```
  G1 X100 Y100 Z200
```

```
ENDIFDEF
```

```
IFDEF AXES=4 //AXES NUMBER=4
```

```
  G1 X100 Y100 Z200 A200
```

```
ENDIFDEF
```

In this example, only the code **G1X100Y100Z200** will be compiled, the code **G1X100Y100Z200A200** will be removed.

In the normal condition, without switch directive, will be showed an error AXIS NOT CONFIGURED (A)

Is possible add a custom switch, see:

[System Utility](#) – **3.5.2 Add a Custom Parameter**

### 10.1 IFDEF

Instruction IF on the switch selected:

**IFDEF AXES=3**

If the condition is true, the code content between **IFDEF** and **ELSEDEF** or **ENDIFDEF**, will be compiled, otherwise will be removed and compiled the code insert in the **ELSEDEF**

In the IFDEF can be used the following operators:

=	<i>Equal</i>
>	<i>Greater</i>
<	<i>Lower</i>
>=	<i>Greater Equal</i>
<=	<i>Lower Equal</i>
<>	<i>Different</i>

### 10.2 ELSEDEF

Instruction ELSE on the switch selected:

**IFDEF AXES=3**

```
  G1 X100
```

**ELSEDEF**

```
  G1 Y30
```

**ENDIFDEF**

If the condition is true, AXES<>3 the code content between ELSEDEF and ENDIFDEF, will be compiled

### 10.3 ENDIFDEF

Instruction **ENDIFDEF**

## 10.4 NOAXESREADY

This Directive allows to run a Gcode though the axes are not ready. (generally it is inserted at the beginning the Gcode)

### NOAXESREADY

```
G71.1 X // ENABLE X
G71.1 Y // ENABLE Y
G71 X // HOMING X
G71 Y // HOMING Y
```

## 10.5 ONERROR

This Directive allows to programming a Gcode part that will be performed when an error is ocured (Like to M Error)

Following will be performed the **M Error** if is set

### ONERROR

```
$(O1)=0 // DISABLE OUT
$(O2)=0 // DISABLE OUT
ENDON
```

## 10.6 ONSTOP

This Directive allows to programming a Gcode part that will be performed when the CN go from RUN to STOP (Like to M Stop)

Following will be performed the **M Stop** if is set

### ONSTOP

```
$(O1)=0 // DISABLE OUT
$(O2)=0 // DISABLE OUT
ENDON
```

## 10.7 ENDON

Ends **ONERROR** and **ONSTOP**

## 10.8 USET

This Directive allows performed a Macro after the instruction **Tn**

```
USET 5 // AFTER Tn WILL BE PERFORMED M5 MACRO
```

## 10.9 USEH

This Directive allows performed a Macro after the instruction **Hn**

```
USEH 6 // AFTER Hn WILL BE PERFORMED M6 MACRO
```

## 11 MATH FUNCTIONS

### 11.1 SIN

Return the sinus of an angle in a DOUBLE type value.

**Syntax**

**SIN (angle)**

**angle** Mandatory. Angle in radiant (it can be an expression)

**Ex:**

`$VAR=SIN($VAR1*3)`

### 11.2 COS

Return the co-sinus of an angle in a DOUBLE type value.

**Syntax**

**COS (angle)**

**angle** Mandatory. Angle in radiant (it can be an expression)

**Ex:**

`$VAR=COS($VAR1*3)`

### 11.3 LOG

Return the base of natural logarithm in a DOUBLE type value.

**Syntax**

**LOG (expression)**

**expression** Mandatory. Expression.

**Ex:**

`$VAR=LOG($VAR1*3)`

### 11.4 EXP

Return the exponential of an expression in a DOUBLE type value.

**Syntax**

**EXP (expression)**

**expression** Mandatory. Expression

**Ex:**

`$VAR=EXP(10.15)`

### 11.5 INT

Return the integer part of a DOUBLE value rounded

**Syntax**

**INT (expression)**

**expression** Mandatory. Numeric expression

**Es:**

`$VAR=35.14`

`$VAR1=INT($VAR)`

## 11.6 FIX

Return the integer part of a DOUBLE value truncated

### Syntax

#### FIX (expression)

**expression** Mandatory. Numeric expression

Es:

```
$VAR=35.14
```

```
$VAR1=FIX($VAR)
```

## 11.7 ABS

Return the absolute value

### Syntax

#### ABS (expression)

**expression** Mandatory. Numeric expression

Es:

```
$VAR=-35.14
```

```
$VAR1=ABS($VAR)
```

## 11.8 DRG

Enable angle in **DEGREES** for COS,SIN,TAN,ACOS,ASIN,ATAN functions.

**By default at each start of PART PROGRAM angle are setted in radiant**

### Syntax

**DRG**

## 11.9 RAD

Enable angle in **RADIANT** for COS,SIN,TAN,ACOS,ASIN,ATAN functions.

**By default at each start of PART PROGRAM angle are setted in radiant**

### Syntax

**RAD**

## 11.10 SQR

Return the square root of an expression in DOUBLE type value.

### Syntax

#### SQR (expression)

**expression** Mandatory. Expression

Ex:

```
$VAR=SQR($VAR1)
```

## 11.11 TAN

Return the tangent of an angle in a DOUBLE type value.

### Syntax

#### TAN (angle)

**angle** Mandatory. Angle in radiant (it can be an expression)

Ex:

```
$VAR=TAN($VAR1*3)
```

### 11.12 ATAN

Return the arctangent of an expression. Result is from -3.14 to 3.14

**Syntax**

**ATAN (expression)**

**expression**      Mandatory. Expression

**Ex:**

`$VAR=ATAN($VAR1*3)`

### 11.13 ASIN

Return the arc-sinus of an expression.

**Syntax**

**ASIN (expression)**

**expression**      Mandatory. Expression

**Ex:**

`$VAR=ASIN($VAR1*3)`

### 11.14 ACOS

Return the arc-cos of an expression.

**Syntax**

**ACOS (expression)**

**expression**      Mandatory. Expression

**Ex:**

`$VAR=ACOS($VAR1*3)`

## I. ISTRUZIONI PER IL CONTROLLO MULTIPROCESSO

L' istruzioni per il controllo del MultiProcesso, servono per gestire più CNC che sono eseguiti nella stessa unità PC. Non necessita di nessuna configurazione particolare, in quanto questa è automaticamente rilevata dal file IsoUs.cfg.



## 12 FUNCTIONS for Multi process Control

The instructions for multi process control allow to management more CNC (IsoUs Process) in the same PC  
These functions no need any special configuration.

### 12.1 CNC.LOAD

Load a Gcode File in the Process.

#### *Syntax*

**CNC.LOAD CN TypeRun InEditor "PATH"**

**CN** Process Number from 1 to 8

**TypeRun** 0 Load Only  
1 Load and Run  
2 Load and Preview  
3 Load, Preview and Run

**InEditor** 0 Not Send to UsEditor  
1 Send to UsEditor

**PATH** (in quotes) If **PATH** starts with **\$APPPATH**, the path is Relative to IsoUs Folder installation  
The file name must have the extension

*Ex:*

**CNC.LOAD 1 1 1 "\$APPPATH\PROJECT\IMPORT\TEST.ISO" // RELATIVE PATH**

**CNC.LOAD 1 1 1 "C:\FILE\TEST.ISO" // ABSOLUTE PATH**

### 12.2 CNC.RUN

Run Gcode in the Process.

#### *Syntax*

**CNC.RUN CN**

**CN** Process Number from 1 to 8  
If **CN ==-1** Run on all Process

*Ex:*

**CNC.RUN 1 // RUN PROCESS 1**

**CNC.RUN -1 // RUN ALL PROCESS**

### 12.3 CNC.PREVIEW

Preview Gcode in the Process.

#### *Syntax*

**CNC.PREVIEW CN**

**CN** Process Number from 1 to 8  
If **CN ==-1** Preview on all Process

*Ex:*

**CNC.PREVIEW 1 // PREVIEW PROCESS 1**

**CNC. PREVIEW -1 // PREVIEW ALL PROCESS**

## 12.4 CNC.STOP

Stop Gcode in the Process.

### Syntax

#### CNC.STOP CN

**CN** Process Number from 1 to 8  
If **CN ==-1** Stop on all Process

*Ex:*

```
CNC.STOP 1 // STOP PROCESS 1
CNC.STOP -1 // STOP ALL PROCESS
```

## 12.5 CNC.PAUSE

Pause Gcode in the Process.

### Syntax

#### CNC.PAUSE CN

**CN** Process Number from 1 to 8  
If **CN ==-1** Pause on all Process

*Ex:*

```
CNC.PAUSE 1 // PAUSE PROCESS 1
CNC.PAUSE -1 // PAUSE ALL PROCESS
```

## 12.6 CNC.STATUS

Read Status from Process.

### Syntax

#### CNC.STATUS CN \$VAR

**CN** Process Number from 1 to 8

**\$VAR** Return Status (bit mapped)

<b>Bit 0</b>	Run	<b>Bit 1</b>	Error	<b>Bit 2</b>	Axes Move
<b>Bit 3</b>	Pause	<b>Bit 4</b>	Home X Ok	<b>Bit 5</b>	Home Y OK
<b>Bit 6</b>	Home Z Ok	<b>Bit 7</b>	Home A Ok	<b>Bit 8</b>	Home B Ok
<b>Bit 9</b>	Home C Ok	<b>Bit 10</b>	Home U Ok	<b>Bit 11</b>	Home V Ok
<b>Bit 12</b>	Home W Ok	<b>Bit 13</b>	Enable X	<b>Bit 14</b>	Enable Y
<b>Bit 15</b>	Enable Z	<b>Bit 16</b>	Enable A	<b>Bit 17</b>	Enable B
<b>Bit 18</b>	Enable C	<b>Bit 19</b>	Enable U	<b>Bit 20</b>	Enable V
<b>Bit 21</b>	Enable W	<b>Bit 22</b>	Ready to Run (Home and enable Ok on all Axes)		

*Ex:*

```
CNC.STATUS 1 $VAR
$VAR1=$VAR & 1 //TEST RUN
IF $VAR1 = 1
...// IS RUN
```

## 12.7 CNC.STATUSBIT

Read Status bit from Process.

### Syntax

**CNC.STATUS** CN NrBit \$VAR

**CN** Process Number from 1 to 8  
**NrBit** Bit number (see CNC.STATUS)  
**\$VAR** Return Status bit

*Ex:*

CNC.STATUSBIT 1 1 \$VAR

IF \$VAR = 1

...// IS RUN

## 12.8 CNC.INFO

Read informations from Process.

### Syntax

**CNC.INFO** CN InfoType \$VAR

**CN** Process Number from 1 to 8  
**InfoType** Tipo informazione  
**0** Read Demand Gcode Line in execution  
**1** Read Real Gcode Line in execution  
**2** Read Axes Resolution  
**3** Read Feed Resolution  
**\$VAR** Return Info

## 12.9 CNC.AXIS

Read Axis informations from Process.

### Syntax

**CNC.INFO** CN AxisIndex AxisType \$VAR

**CN** Process Number from 1 to 8  
**AxisIndex** Axis Index 0 to 8  
**AxisType** Axis Information  
**0** Read Demand Axis Value  
**1** Read Real Axis Value  
**2** Read Demand Axis Value (Syncro – Precise mode)  
**3** Read Real Axis Value (Syncro – Precise mode)  
**4** Read Total Offset Value (Work Origins, Offset Hn G43 etc.)  
**\$VAR** Return Info

## 12.10 CNC.GROUP

Read Group Axis informations from Process.

### Syntax

**CNC.GROUP CN NrAxes AxisType \$VAR**

**CN** Process Number from 1 to 8  
**NrAxes** Group of Axis 1 to 9  
**AxisType** Axis Information  
**0** Read Demand Axis Value  
**1** Read Real Axis Value  
**2** Read Total Offset Value (Work Origins, Offset Hn G43 etc.)  
**\$VAR** Return Info Start Variable or Array

Ex:

```
// ALLOC 3 VARIABLES FOR 3 AXES
```

```
$VARX=0
```

```
$VARY=0
```

```
$VARZ=0
```

```
CNC.GROUP 1 3 0 $VARX
```

```
// $VARX=VALUE ASSE X
```

```
// $VARY= VALUE ASSE Y
```

```
// $VARZ= VALUE ASSE Z
```

Ex:

```
// ALLOC ARRAY
```

```
DIM $ARR 3
```

```
CNC.GROUP 1 3 0 $ARR
```

```
// $ARR[0]= VALUE ASSE X
```

```
// $ARR[1]= VALUE ASSE Y
```

```
// $ARR[2]= VALUE ASSE Z
```

## 12.11 CNC.READVARADDR

Read a Gcode Variable by Address from Process.

### Syntax

**CNC.READVARADDR CN AddrVar \$VAR**

**CN** Process Number from 1 to 8  
**AddrVar** Variable Address from 0 to 327667  
**\$VAR** Return Value

## 12.12 CNC.READVARNAME

Read a Gcode Variable by Name from Process.

### *Syntax*

**CNC.READVARNAME CN \$VAR "VARNAME"**

**CN** Process Number from 1 to 8  
**\$VAR** Return Value  
**VARNAME** Variable Name UpperCase without \$ (in quotes)

## 12.13 CNC.WRITEVARADDR

Write a Gcode Variable by Address from Process.

### *Syntax*

**CNC.WRITEVARADDR CN AddrVar \$VAR**

**CN** Process Number from 1 to 8  
 If **CN =-1** Write on all Process  
**AddrVar** Variable Address from 0 to 327667  
**\$VAR** Source Value

## 12.14 CNC.WRITEVARNAME

Write a Gcode Variable by Name from Process.

### *Syntax*

**CNC.WRITEVARNAME CN \$VAR "VARNAME"**

**CN** Process Number from 1 to 8  
 If **CN =-1** Write on all Process  
**\$VAR** Source Value  
**VARNAME** Destination Variable Name UpperCase without \$ (in quotes)

## 12.15 CNC.READPARAMAC

Read Machine Parameter from Process.

### *Syntax*

**CNC.READPARAMAC CN \$VAR "PARNAME"**

**CN** Process Number from 1 to 8  
**\$VAR** Return Value  
**PARNAME** Parameter Name (in quotes)

## 12.16 CNC.WRITEPARAMAC

Write Machine Parameter to Process.

### *Syntax*

**CNC.WRITEPARAMAC CN \$VAR "PARNAME"**

**CN** Process Number from 1 to 8  
**\$VAR** Source Value  
**PARNAME** Parameter Name (in quotes)

## 12.17 CNC.ENABLEAXIS

Enable/Disable Axis to Process. (wait sequence finished)

### *Syntax*

#### **CNC.ENABLEAXIS CN AXIS STATE**

<b>CN</b>	Process Number from 1 to 8
<b>AXIS</b>	Axis Index
<b>STATE</b>	Axis State
	<b>0</b> Disable
	<b>1</b> Enable

## 12.18 CNC.HOMEAXIS

Homing Axis to Process. (wait sequence finished) CNC.STOP for force Stop Homing

### *Syntax*

#### **CNC.HOMEAXIS CN AXIS**

<b>CN</b>	Process Number from 1 to 8
<b>AXIS</b>	Axis Index

## 12.19 CNC.READGENERIC

Read Generic Variable (see below Type Generic)

### *Syntax*

#### **CNC.READGENERIC CN TYPE \$PAR \$VAR**

<b>CN</b>	Process Number from 1 to 8
<b>TYPE</b>	Tipo Variable
<b>\$PAR</b>	Additional Parameter (if it is not managed put \$PAR=0)
<b>\$VAR</b>	return Value

## 12.20 CNC.WRITEGENERIC

Write Generic Variable (see below Type Generic)

### *Syntax*

#### **CNC.WRITEGENERIC CN TYPE \$PAR \$VAR**

<b>CN</b>	Process Number from 1 to 8
<b>TYPE</b>	Tipo Variable
<b>\$PAR</b>	Additional Parameter (if it is not managed put \$PAR=0)
<b>\$VAR</b>	Source Value

## Type Generic

TYPE	READ	WRITE	Description	\$PAR
0	V		Read Demand Axis Value (\$[Qn])	Axis Index
1	V		Read Real Axis Value (\$[Rn])	Axis Index
2	V		Read Digital Input (\$[In])	Index (0 to 255)
3	V	V	Read/Write Digital Output (\$[On])	Index (0 to 255)
4	V	V	Read/Write Tool Table Parameter (\$[Un])	Parameter Index
5	V		Read Head Parameter (\$[Hn])	Parameter Index
6	V		Read SPEED (\$[X0])	Not Used
7	V		Read Work Origins Enable (\$[X3])	Not Used
8	V		Read Offset Enable (\$[X4])	Not Used
9	V		Read FEED (\$[X8])	Not Used
10	V		Read Origin Value (\$[Yn])	Not Used
11	V		Read Offset Value (\$[Wn])	Axis Index
12	V		Read H Set	Not Used
13	V		Read T Set	Not Used
14	V	V	Read/Write User Generic (\$[Kn])	User Generic Index
15		V	Write Analo Value for SPINDLE	Not Used

## 13 REMOTE CONTROL FUNCTIONS

Remote functions allows to control more CNC connected in LAN (See **CN REMOTE CONFIGURATION**)

### *RunTimeError:*

<b>E1082</b>	Remote CNC not connect
<b>E1083</b>	Remote CNC operation failure
<b>E1084</b>	Remote CNC Gcode Error
<b>E1085</b>	Remote CNC RUN Error
<b>E1086</b>	Remote CNC File not found
<b>E1087</b>	Remote CNC Axes not ready
<b>E1088</b>	Remote CNC Already in RUN
<b>E1089</b>	Remote CNC Axes not available
<b>E1090</b>	Remote CNCD Gcode Variable not found

### 13.1 REMOTE.LOAD

Load a Gcode file on Remote CNC

#### **Syntax**

**REMOTE.LOAD CN RUN "PATH"**

**CN**                 Number of CNC set in *clientNs.cfg file*

**RUN**               **0** Only Load

**1** Load and Run

**PATH**              Remote Gcode file Path

                      If **PATH** starts with **\$APPPATH**, the path is Relative to Isous Folder installation

#### *Ex:*

**REMOTE.LOAD 0 1 "\$APPPATH\PROJECT\IMPORT\TEST.ISO" //RELATIVE PATH**

**REMOTE.LOAD 0 1 "C:\FILE\TEST.ISO" //ABSOLUTE PATH**

### 13.2 REMOTE.RUN

Run a Gcode file on Remote CNC

#### **Syntax**

**REMOTE.RUN CN**

**CN**                 Number of CNC set in *clientNs.cfg file*

#### *Ex:*

**REMOTE.RUN 0 //run on CN 0**

### 13.3 REMOTE.STOP

Stop a Gcode file on Remote CNC

#### **Syntax**

**REMOTE.STOP CN**

**CN**                 Number of CNC set in *clientNs.cfg file*

#### *Ex:*

**REMOTE.STOP 0 //stop CN 0**



### 13.4 REMOTE.PAUSE

Pause a Gcode file on Remote CNC

#### Syntax

**REMOTE.PAUSE CN**

**CN**                    Number of CNC set in *clientNs.cfg file*

**Ex:**

```
REMOTE.PAUSE 0 //pause CN 0
```

### 13.5 REMOTE.STATUS

Read a STATUS WORD on Remote CNC

#### Syntax

**REMOTE.STATUS CN \$VAR**

**CN**                    Number of CNC set in *clientNs.cfg file*

**\$VAR**                **Gcode** Variable

Return in \$VAR (bit Mapped):

bit 0 → CN ERROR

bit 1 → CN RUN

bit 2 → CN AXES MOV

bit 3 → CN PAUSE

**Ex:**

```
REMOTE.LOAD 0 0 "..."
```

```
REMOTE.LOAD 1 0 "..."
```

```
REMOTE.RUN 0
```

```
REMOTE.RUN 1
```

```
@LBL_1
```

```
REMOTE.STATUS 0 $VAR //READ STATUS CN 0 IN $VAR
```

```
REMOTE.STATUS 1 $VAR1 // READ STATUS CN 1 IN $VAR1
```

```
$V1=$VAR&2 //TEST BIT RUN
```

```
$V2=$VAR1&2
```

```
IF $V1=2 || $V2=2 //WAIT IF RUN
```

```
  GOTO LBL_1
```

```
END_IF
```

### 13.6 REMOTE.MOVE

Read Axes Mov on Remote CNC

#### Syntax

**REMOTE.MOVE CN \$VAR**

**CN**                    Number of CNC set in *clientNs.cfg file*

**\$VAR**                **Gcode** Variable

Return in \$VAR:

0 → Axes Stop

1 → Axes Mov

**Es:**

```
REMOTE.MOVE 0 $VAR //Read Axes Mov in $VAR
```

## 13.7 REMOTE.INFO

Read Info on Remote CNC

### Syntax

**REMOTE.INFO CN TYPE \$VAR**

<b>CN</b>	Number of CNC set in <i>clientNs.cfg file</i>
<b>TYPE</b>	Type of Information: 0 → Get Demand Line Worked 1 → Get Real Line Worked 2 → Get Current FEED 3 → Get % of Override 4 → Get Tool Table Set (T) 5 → Get Head Set (H) 6 → Get Axes Resolution Set (1000,10000 etc.) 7 → Get Feed Resolution Set (1000 etc.)
<b>\$VAR</b>	<b>Gcode</b> Variable

### Ex:

**REMOTE.INFO 0 0 \$VAR //Read Demand Line Worked in \$VAR**

## 13.8 REMOTE.AXIS

Read Axis Info on Remote CNC

### Syntax

**REMOTE.AXIS CN AXIS TYPE \$VAR**

<b>CN</b>	Number of CNC set in <i>clientNs.cfg file</i>
<b>AXIS</b>	Axis 0=X - 1=Y - 2=Z - 3=A - 4=B - 5=C - 6=U - 7=V - 8=W
<b>TYPE</b>	Type of Information: 0 → Get Demand Absolute Axis Value (from ZERO ORIGIN) 1 → Get Demand Relative Axis Value (from Work Origin Set) 2 → Get Real Absolute Axis Value (from ZERO ORIGIN) 3 → Get Real Relative Axis Value (from Work Origin Set) 4 → Not Use 5 → Not Use 6 → Get Value Work Origin Set 7 → Get Value OffsetOrigin Set 8 → Get Work Origin Index Set 9 → Get Offset Origin Index Set
<b>\$VAR</b>	<b>Gcode</b> Variable

### Ex:

**REMOTE.AXIS 0 1 0 \$VAR //Get Y Demand Position value**

### 13.9 REMOTE.GROUP

Read Axes group Info on Remote CNC

#### Syntax

**REMOTE.AXIS CN NAXES TYPE \$VAR**

<b>CN</b>	Number of CNC set in <i>clientNs.cfg file</i>
<b>NAXES</b>	Number of Axes to read
<b>TYPE</b>	Type of Information: 0 → Get Group Demand Absolute Axis Value (from ZERO ORIGIN) 1 → Get Group Demand Relative Axis Value (from Work Origin Set) 2 → Get Group Real Absolute Axis Value (from ZERO ORIGIN) 3 → Get Real Relative Axis Value (from Work Origin Set) 4 → Not Use 5 → Not Use 6 → Get Group Value Work Origin Set 7 → Get Group Value OffsetOrigin Set 8 → Get Group Work Origin Index Set 9 → Get Group Offset Origin Index Set
<b>\$VAR</b>	<b>Gcode Start Variable</b> The Successive variables are get following the start Variable

**ES:**

`$VARX=0 //Start Variable`

`$VARY=0`

`$VARZ=0`

`REMOTE.GROUP 0 3 0 $VARX //Read X,Y,Z in VARX,VARY,VARZ`

### 13.10 REMOTE.READISOVAR

Read a Gcode Variable on Remote CNC from Address

#### Syntax

**REMOTE.READISOVAR CN ADDR \$VAR**

<b>CN</b>	Number of CNC set in <i>clientNs.cfg file</i>
<b>ADDR</b>	<b>Addr</b> Gcode IsoVar from 10 to 32768 (from 0 to 9 are reserved)
<b>\$VAR</b>	<b>Gcode Variable</b>

**Ex:**

`REMOTE.READISOVAR 0 10 $VAR //Read the variable addr 10 (first variable declared)`

### 13.11 REMOTE.READVARNAME

Read a Gcode Variable on Remote CNC from Name

#### Syntax

**REMOTE.READVARNAME CN \$VAR "RemoteVarName"**

<b>CN</b>	Number of CNC set in <i>clientNs.cfg file</i>
-----------	---

**\$VAR**                      **Gcode** Variable  
**RemoteVarName**        Remote Variable Name without \$

**Ex:**

REMOTE.READVARNAME 0 \$VAR "VAR1" //Read the variable name \$VAR1

### 13.12 REMOTE.WRITEISOVAR

Write a Gcode Variable on Remote CNC from Address

**Syntax**

REMOTE.WRITEISOVAR CN ADDR \$VAR

**CN**                      Number of CNC set in *clientNs.cfg file*  
**ADDR**                  **Addr** Gcode IsoVar from 10 to 32768 (from 0 to 9 are reserved)  
**\$VAR**                    **Gcode** Variable

**Ex:**

\$VAR=100.1

REMOTE.WRITEISOVAR 0 10 \$VAR //Write the variable addr 10

### 13.13 REMOTE.WRITENAMEVAR

Write a Gcode Variable on Remote CNC from Name

**Syntax**

REMOTE.WRITENAMEVAR CN \$VAR "RemoteVarName"

**CN**                      Number of CNC set in *clientNs.cfg file*  
**\$VAR**                    **Gcode** Variable  
**RemoteVarName**        Remote Variable Name without \$

**Ex:**

\$VAR=100.1

REMOTE.WRITENAMEVAR 0 \$VAR "VAR1" // Write the variable \$VAR1

### 13.14 REMOTE.READCNVAR

Read a User Generic Variable on Remote CNC

**Syntax**

REMOTE.READCNVAR CN ADDR \$VAR

**CN**                      Number of CNC set in *clientNs.cfg file*  
**ADDR**                  User Generic Variable addr from 0 to 9  
**\$VAR**                    **Gcode** Variable

**Ex:**

REMOTE.READCNVAR 0 1 \$VAR //Read User Generic 1

### 13.15 REMOTE.WRITECNVAR

Write a User Generic Variable on Remote CNC

**Syntax**

**REMOTE.WRITECNVAR CN ADDR \$VAR**

<b>CN</b>	Number of CNC set in <i>clientNs.cfg file</i>
<b>ADDR</b>	User Generic Variable addr from 0 to 9
<b>\$VAR</b>	<b>Gcode</b> Variable

**Ex:**

`$VAR=10`

`REMOTE.WRITECNVAR 0 1 $VAR //Write value 10 in USER GENERIC 1`

### 13.16 REMOTE.READINPUT

Read a Digital Input on Remote CNC

**Syntax**

**REMOTE.READINPUT CN NINP \$VAR**

<b>CN</b>	Number of CNC set in <i>clientNs.cfg file</i>
<b>NINP</b>	Digital Input Number from 0 to 255
<b>\$VAR</b>	<b>Gcode</b> Variable
	0 → Input OFF
	1 → Input ON

**Ex:**

`REMOTE.READINPUT 0 1 $VAR //Read Digital Input 1`

### 13.17 REMOTE.READOUTPUT

Read a Digital Output on Remote CNC

**Syntax**

**REMOTE.READOUT CN NOUT \$VAR**

<b>CN</b>	Number of CNC set in <i>clientNs.cfg file</i>
<b>NOUT</b>	Digital Output Number from 0 to 255
<b>\$VAR</b>	<b>Gcode</b> Variable
	0 → Output OFF
	1 → Output ON

**Ex:**

`REMOTE.READIOUT 0 1 $VAR //Read Digital Output 1`

### 13.18 REMOTE.WRITEOUTPUT

Write a Digital Output on Remote CNC

#### Syntax

**REMOTE.WRITEOUT CN NOUT \$VAR**

<b>CN</b>	Number of CNC set in <i>clientNs.cfg file</i>
<b>NOUT</b>	Digital Output Number from 0 to 255
<b>\$VAR</b>	<b>Gcode Variable</b> 0 → Output OFF 1 → Output ON

#### Ex:

`$VAR=1`

`REMOTE.WRITEOUT 0 1 $VAR //Set Digital Output 1`

## 14 CN REMOTE CONFIGURATION

First to use the Remote Functions, need to configure the remote CNC in the LAN.  
The CNC can be in the same PC, or in the different PC, but connected at same LAN.  
The configuration of Remote CNC is in the following file::

### **NSCLIENT**

#### **NSSERVER**

### **NSCLIENT**

This represents the configuration of one or more CNCs that open the connection to a NS SERVER CNC. To configure client CNCs, just have a file named "ClientNs.cfg" in the Isous installation folder.

#### **ClientNs.cfg**

[USER\_CN 0]

**CN=IpAddr,port** → CN 0 to process 0

**CN=IpAddr,port** → CN 1 to process 0

.

.

[USER\_CN 1]

**CN=IpAddr,port** → CN 0 to process 1 (if present)

**CN=IpAddr,port** → CN 1 to process 1 (if present)

Where:

**IpAddr** → Server IP address for CN 0,1,2 etc.

**port** → Port Number for CN 0,1,2 etc.

### **NSSERVER**

Represents a CNC server in a LAN network. This is to be configured as a server, you must have the PLUGIN "ServerNs.dll" (in PlugIn \ Bin) with the following setup in UsPlugin.cfg file:

```
<Set Name="UsServer" Image="" Title="@_US SERVER" Path="UsPlugIn\Bin\UsServer.dll"
NameSpace="UsServer.GestUsServer" Autorun="False" Button="False" Enable="True" />
```

Additionally, the "ServerNs.cfg" file must be present in the Isous server installation folder that configures the server process listening port.

#### **ServerNs.cfg**

[USER\_CN 0]

**Port** → Port in listening for CN 0

[USER\_CN 1]

**Port** → Port in listening for CN 1 (if present)

.

.

**Note**

Be careful when configuring the Port. You must choose values that are not occupied by other operating system processes (typically higher values, eg 36000)

**Example**

Local LAN Configuration, Server IP Address 10.0.0.34 Port 36000

The PC that contains the server process must then have a static IP 10.0.0.34

The PC that contains the client process can have the same IP address as the same PC, but must have an appropriate address to the network eg: 10.0.0.50

**ClientNs.cfg**

**[USER\_CN 0]**

**CN=10.0.0.34,36000**

**ServerNs.cfg**

**[USER\_CN 0]**

**36000**



## 15 USING LOGIC OPERATORS

In this chapter will be explained how to use logical operator omitting classic math operators (+-\*/).

### 15.1 ROUND BRACKETS ( )

They separate level of expressions, doing priority to content inside the brackets.

### 15.2 ISO EXPRESSIONS and SQUARE BRACKETS [ ]

The use of square brackets is not permitted in generic expression. They are valid only for specific type of variable and exclusively in the functions listed below. In these ISO instructions identify, in them, an expression or a variable. That is because in origin ISO code accepted only numeric fields, therefore to remain compatible at this standard but to have the possibility of a powerful and more flexible language, Isous introduced square brackets [ ] to identify an expression or variable.

#### ISO INSTRUCTIONS WHERE ARE PERMITTED SQUARE BRACKETS [ ]

Axis positions	X,Y,Z,A,B,C,U,V,W - DX,DY,DZ,DA,DB,DC,DU,DV,DW
Axis Feed	F
Speed	S
Tool diameter	D
Arc Center	I,J
Arc Radius	R
Tool	T
Head	H
Origin index	USER_ZERO
Offset index	USER_OFFSET

Ex:

```
G1X1000 // STANDARD ISO GCODE
G1DX1000 // INCREMENTAL VALUE (THE SAME G91)
G1X[$VAR] // USE OF VARIABLE AS AXIS POSITION
G1X[$VAR+$VAR1*SQR(18)] // USE OF EXPRESION AS AXIS POSITION
```

### 15.3 VARIABLE TEST

To test variable Isous uses classic conditional operators = > < <> >= <= !

They are inserted in **IF ELSE END\_IF** cycles allowing to execute cycles conditioned to one or more variable. Equal operators (=) can be combined to other logical operators OR (|) AND (&&). Round brackets can be used to prioritize expressions.

Ex:

```
IF $VAR=0 && $VAR1=5
    G1X100
ELSE
    G1X0
END_IF
```

## 15.4 BIT CONTROL

Isous makes available also operator to control the state of a single bit of a variable. They can be used in **IF ELSE END\_IF** cycles or to **set/reset** single bit of a variable. It is also possible make a shift of the bits (left or right) and negate its state. All bit operations can be made only on INTEGER variables (excluding therefore decimal part).

Ex:

```
IF $VAR & 4           // TEST BIT 3 OF $VAR
    G1X100 // BIT IS ON
ELSE
    G1X0       // BIT IS OFF
END_IF
```

```
$VAR=$VAR | 1 // SET BIT 1 OF $VAR
$VAR=$VAR & 1 // RESET ALL BITS EXCEPT BIT 1 OF $VAR
```

```
$VAR=1
$VAR=$VAR<<3 // $VAR IS SHIFTED LEFT 3 TIME
```

## 16 VARIABLE TYPES

Isous introduced VARIABLE to increase programming facilities. There are two types of variable: INTEGER o DOUBLE (floating point). Variables can be combined in expression as all other common languages.

### 16.1 NUMERIC CONSTANTS

All explicit numeric values are numeric constants. Decimal point can be used.

Ex:

```
G1X100.13
$VAR=25.143
```

### 16.2 GENERIC VARIABLES "\$"

All generic variable are DOUBLE type and they can be used to store values inside PartProgram. When they are inserted in ISO instructions (X,Y,Z ecc) it must be delimited between **square brackets [ ... ]**.

Minimum value            - **1.79769313486232 E308**

Maximum value           **1.79769313486232 E308**

The maximum number of available variables is 2048 and are recognized by \$ prefix followed by an ALPHANUMERIC NAME.

Ex:

```
$VAR=1
$VAR=$VAR1*5
$VAR=SQR($VAR1)
G1X[$VAR]
```

### 16.3 VARIABLES FOR ADDRESS

The Variables management can be do by **ADDRESS**, by a value from 0 to 32767..

**:1000=10** Assign the value 10 to variable with ADDRESS 1000

#### WARNIG

The variables by ADDRESS are shared by variables by NAME (\$), the compiler assign to \$ an address from 0 to 32767 by the number of variables in the Gcode file. May be that the variable by ADDRES is overlapped to variable by NAME. Recommended use address from 10000

### 16.4 VARIABLES FOR POINTER

Like to variables for ADDRESS, but in this case the ADDRESS is assigned by a Variable for NAME (\$).

**\$VAR=1000**

**:\$VAR=10** Assign the value 10 to variable with ADDRESS 1000

**\$VAR++**

**:\$VAR=20** Assign the value 10 to variable with ADDRESS 1001

The type of variables can generate a RUN TIME ERROR

### 16.5 DATA STRUCTURES

IsoUs can manage the Variables in Data Structure. The Data Structure are used for organizing the \$ variables. This allows to simplify the GCODE programmation.

The Data Structures are always **GLOBAL** therefore are visible in the **M functions**.

These are created by **UsStructManager** (see documentation in Promax store).

A structure is defined by a **CATEGORY** (structure name) and one or more **VARIABLES** (data of structure).

Ex.

<b>NAME</b>	<b>TOOLPAR</b>
<b>VARIABLES</b>	<b>PAR1</b>
	<b>PAR2</b>
	<b>PAR3</b>

In **GCODE** is used the following syntax:

**\$TOOLPAR.PAR1=10**

**\$TOOLPAR.PAR2=10+\$TOOLPAR.PAR1**

The data structures are always available once defined by **UsStructManager**

## 16.6 AXIS POSITION VARIABLES

These variables contain the position value of axis and accordingly they are read only.

The maximum number of these variables is 9. They can be used in PartProgram to read axis position in a given time.

### **Demand axis position - ReadOnly**

**\$(Qn)** With **n** from **0** to **8** it identifies the axis. The value of **DEMAND POSITION** is written in the variable and it refers to a **RELATIVE** value inclusive of WORK ORIGIN and OFFSET

With **n** from **100** to **108** it identifies the axis (subtracting 100). . The value of **DEMAND POSITION** is written in the variable and it refers to an **ABSOLUTE** position from HOME position

### **Actual axis position - ReadOnly**

**\$(Rn)** With **n** from **0** to **8** it identifies the axis. The value of **ACTUAL POSITION** is written in the variable and it refers to a **RELATIVE** value inclusive of WORK ORIGIN and OFFSET

With **n** from **100** to **108** it identifies the axis (subtracting 100). . The value of **ACTUAL POSITION** is written in the variable and it refers to an **ABSOLUTE** position from HOME position

### **Relative position Absolute position**

n=0 AXIS X                      n=100 AXIS X

n=1 AXIS Y                      n=101 AXIS Y

n=2 AXIS Z                      n=102 ASSE Z

...etc.                              ...etc.

**Ex:**

```
IF $(Q0)>100.3 // TEST OF X AXIS DEMAND POSITION
```

```
  G101
```

```
END_IF
```

```
$VAR=$(R1) // READ ACTUAL POSITION OF Y AXIS
```

## 16.7 DIGITAL INPUT/OUTPUT VARIABLES

These variables allow to read all digital input or set/reset all digital output of CN. Rember digital output can be shared with PLC cycle on CN. This facilities is useful to make a simple PLC structure directly from ISO language without CN programming. I/O variables consider only 0 and 1 values. **These variables when inserted in PartProgram allow direct access to I/O without waiting axis movement sync. Therefore in specific cases can need to use G62 code (wait end movement) to have sync between axis and I/O.**

### **Input Variables – Read only**

**\$(In)** Where **n** is a value from **0** to **255** and it identifies CN input

**Value=0, Input OFF - Value=1, Input ON**

### **Output Variables – Read/Write**

**\$(On)** Where **n** is a value from **0** to **255** and it identifies CN output

**Value=0, Input OFF - Value=1, Input ON**

**Ex:**

```
IF $(I0)=1 // IF 1st INPUT IS ACTIVE
```

```
  $(O5)=1 // SET 6th OUTPUT
```

```
ELSE
```

```
  $(O5)=0 // ELSE CLEAR IT
```

```
END_IF
```

## 16.8 TIMER VARIABLES

These variables are useful to set system TIMERS. Timers can be used to make delays, time-outs, etc. The maximum numbers of timers available is 10. TIMERS are written with a time in milliseconds. After TIMER is set, it starts automatically to decrement until its value reach 0.

### **Timer Variables – Read/Write**

**\$(Tn)** Where **n** is a value from **0** to **9** and it identifies the timer number

**Ex:**

```
$(T0)=1500           // SET TIMER 0 AT 1550 MILLISECONDS (1.5 SECONDS)
@CICLO
IF $(I0)=1
    GOTO EXIT        // EXIT IF INPUT 1 IS ON
END_IF
IF $(T0)=0           // TEST TIMER
    ERROR 10         // IF TIMER ELAPSES STOP PARTPROGRAM WITH ERROR 10
END_IF
GOTO CICLO           // REPEAT CYCLE
@EXIT
```

## 16.9 TOOL TABLE VARIABLES

They allow to read PARAMETERS from selected TOOL TABLE with **Tn**. The list below describes all parameters available for each TOOL TABLE and, as showed, they are up to maximum of 20 parameters per each tools.

### **Tool table variable – Read/Write**

**\$(Un)** Where **n** is a value from **0** to **19** indicating the parameter address

**Ex:**

`$VAR=$(U0) // READ DIAMETER OF THE SELECTED TOOL`

Address	Description
<b>0</b>	Tool diameter
<b>1</b>	Tool length
<b>2</b>	Maximum tool rpm speed
<b>3</b>	User Define 1
<b>4</b>	User Define 2
<b>5</b>	User Define 3
<b>6</b>	User Define 4
<b>7</b>	User Define 5
<b>8</b>	User Define 6
<b>9</b>	User Define 7
<b>10</b>	User Define 8
<b>11</b>	User Define 9
<b>12</b>	User Define 10
<b>13</b>	User Define 11
<b>14</b>	User Define 12
<b>15</b>	User Define 13
<b>16</b>	User Define 14
<b>17</b>	User Define 15
<b>18</b>	User Define 16
<b>19</b>	User Define 17

## 16.10 HEAD TABLE VARIABLES

These variables allow to read and write parameters of the selected HEAD TABLE with **Hn**. The list below describes all parameters available for each HEAD TABLE and, as showed, they are up to maximum of 20 parameters per each head.

### **Tool table variable – ReadOnly**

**\$(Hn)** Where **n** is a value from **0** to **19** indicating the parameter address

**Ex:**

```
$VAR=$(H0)           // READ OFFSET X
```

Address	Descrizione
<b>0</b>	Head offset from home position of axis X
<b>1</b>	Head offset from home position of axis Y
<b>2</b>	Head offset from home position of axis Z
<b>3</b>	Head offset from home position of axis A
<b>4</b>	Head offset from home position of axis B
<b>5</b>	Head offset from home position of axis C
<b>6</b>	Head offset from home position of axis U
<b>7</b>	Head offset from home position of axis V
<b>8</b>	Sensor offset from 0 head of axis W
<b>9</b>	Sensor offset from 0 head of axis X
<b>10</b>	Sensor offset from 0 head of axis Y
<b>11</b>	Sensor offset from 0 head of axis Z
<b>12</b>	Sensor offset from 0 head of axis A
<b>13</b>	Sensor offset from 0 head of axis B
<b>14</b>	Sensor offset from 0 head of axis C
<b>15</b>	Sensor offset from 0 head of axis U
<b>16</b>	Sensor offset from 0 head of axis V
<b>17</b>	Sensor offset from 0 head of axis W
<b>18</b>	User Define 1
<b>19</b>	User Define 2

## 16.11 AXIS COUNTER VARIABLES

They are useful to read axis position from the interpolator. They don't contain the actual axis position but the position where it will be after position command. Generally these variable anticipate axis position before it has reached it. That is very useful for block restart facilities.

### **Axis counter variables – ReadOnly**

**\$(Cn)** Where **n** is a value from **0** to **8** indicating the axis

## 17 LIMIT AXIS VARIABLES

They are useful to read the limit axis setted

### ***Positive Limit – ReadOnly***

**`$(Nn)`** Where **n** is a value from **0** to **8** indicating the axis

### ***Negative Limit – ReadOnly***

**`$(Sn)`** Where **n** is a value from **0** to **8** indicating the axis



## 18 PREVIEW PARAMETERS

This variable type reads or sets the Preview Parameters (simulation Gcode)


**\$[Pn]** Where “n” is a value from 0 to 16 that indicates the parameter number

Pn	Descrizione	Valori
0	Enable/Disable Rotative Axis	0 Disable 1 Enable
1	Set axis Z direction for rotative Axis	0 Positive direction downward 1 Negative direction downward
2	Simulation Type	0 Line 1 Mesh 2 Lathe 3 Close Mesh 4 LayerT
3	Enable/Disable Heads Offset	0 Disable 1 Enable
4	Select cursor type	0 Pointer 1 RTCP 10-49 Type Tools where 10 Tool0-11 Tool1 etc. 50-99 Type Blade where 50 blade0 -51 Blade1 etc
5	Index Axis Blade	from 0 to Axis number-1
6	Offset Blade	From 0 to 360
7	Tool Diameter	Positive value only
8	Box Start X	See figure below
9	Box Start Y	See figure below
10	Box Start Z	See figure below
11	Box Size X	See figure below
12	Box Size Y	See figure below
13	Box Size Z	See figure below
14	Show box	Value >0 shows the box with parameters P8..P13. This parameter must be written after the parameters P8..P13 are written
15	LASER ON/OFF for RMS (Real machine Simulation)	Value>0 Enable Laser On for simulation focus point of laser in Machine Simulation
16	TOOL ON/OFF for RMS (Real machine Simulation)	Value>0 Enable Tool Spindle On for simulation point of tool contact in Machine Simulation
17	TEST COLLISION ON/OFF for RMS (Real machine Simulation)	Value>0 Enable Test Axes Collision in Gcode Run
18	TOOL LENGTH for RMS (Real machine Simulation)	Value for update the tool length ex: after the G102
19	SHOW MODEL 3D BOX for RMS (Real machine Simulation)	Value>0 show 3D model piece

<b>20</b>	Depth MODEL 3D BOX for RMS (Real machine Simulation)	Depth 3D model piece
<b>21</b>	Width MODEL 3D BOX for RMS (Real machine Simulation)	Width 3D model piece
<b>22</b>	Height MODEL 3D BOX for RMS (Real machine Simulation)	Height 3D model piece
<b>23</b>	Acq like G102 for RMS (Real machine Simulation). If SHOW MODEL 3D BOX Acq on Up of the Box, else on Up of the machine plane	Value = 1 Acq Value = 0 Reset
<b>24</b>	OFFSET on $\$(P23)$	Add an offset on Acq by $\$(P23)$
<b>25-36</b>	RESERVED	Read MinX,MaxX,MinY,MaxY,MinZ,MaxZ MaX1,MinY1,MaxY1,MinZ1,MaxZ1
<b>37</b>	Preview Laser Raster	Value =1 Enable Preview Laser Raster Mode In $\$(p7)$ Diameter Spot Laser Value = 0 Disable

**Show box for piece dimensions**

With the parameters P8..P14 is possible draw a Box for emulate the piece dimensions in working




**Example:**


```

$[P8]=50 // START X
$[P9]=150 // START Y
$[P10]=0 // START Z
$[P11]=300 // SIZE X
$[P12]=200 // SIZE Y
$[P13]=70 // SIZE Z
$[P14]=1 // SHOWS BOX
    
```

**Draw with Tool On outside of piece**



**Draw with Tool On inside of piece**



**Acq Piece origin by \${P23}****Ex:**

H2

 $\${P23}=1$ 

G1X0Y0


G60

G0X202.018Y271.361

G2X203.211Y280.401I236.814J271.368

.

.



## 18.1 GLOBAL VARIABLE

GLOBAL prefix can be applied only to GENERIC variables (\$name) and to use it in M or HM functions. GLOBAL prefix must be used when we want to share a variable between PartProgram and M/HM function, because by default Isous considers LABEL and VARIABLE private.

Ex:

```
//--- EXAMPLE FOR CODE OF PAUSE MACRO
//DEFINE $SAVEX AND $SAVEY AS GLOBAL
GLOBAL $SAVEX
GLOBAL $SAVEY
G62                // WAIT FOR AXIS IN POSITION
$SAVEX=${Q0}      // SAVE AXIS X POSITION
$SAVEY=${Q1}      // SAVE AXIS Y POSITION
GOXOYO

//--- EXAMPLE FOR CODE OF RESTART FROM PAUSE MACRO
//DEFINE $SAVEX AND $SAVEY AS GLOBAL
GLOBAL $SAVEX
GLOBAL $SAVEY
GOX[$SAVEX] Y[$SAVEY] // MOVE AXIS TO POSITION SAVED IN PAUSE MACRO
G62
```

## 18.2 M FUNCTION VARIABLES (FOR CN)

These variable are useful to pass parameter to M functions defined in CN. That allows to condition M cycle by the value of them. The parameters must be write before to call M function. The number of passing parameters is defined in configuration up to maximum of 10 (default 5 parameters).

**ATTENTION:**

The CN get these parameters as integer value.

Ex:

```
// RUN M FUNCTION ON CN PASSING 2 PARAMETER
$_PARAM_1=100
$_PARAM_2=300
M15
```

## 18.3 SPECIAL PARAMETERS VARIABLES

They serve to read some parameters of Isous. The list below shows the readable parameters with these variables.

```
$(X0)   Read the current value of SPEED selected by S function - ReadOnly
$(X1)   Read the index of current WORK ORIGIN - ReadOnly
$(X2)   Read the index of current WORK OFFSET - ReadOnly
$(X3)   Read state of WORK ORIGIN – Value 1 if enabled or 0 if disabled - ReadOnly
$(X4)   Read state of WORK OFFSET – Value 1 if enabled or 0 if disabled – ReadOnly
$(X5)   Read the number of current head selected by H function – ReadOnly
$(X6)   Read the number of current tool selected by T function – ReadOnly
$(X7)   Read The RUN Type – ReadOnly
           0 NORMAL RUN
           1 SIMULATION RUN
           2 GO BLOCK RUN
           3 RETRACE RUN
           4 GCODE EXECUTION TIME CALCULATION RUN
```

- X8**     *Read Last FEED – ReadOnly*
- X9**     *Read coordinate mode – ReadOnly*  
           0 G90 Absolute  
           1 G91 Relative
- X10**    *Read work plane activated – ReadOnly*  
           0 XY G17  
           1 XZ G18  
           2 YZ G19  
           -1 other
- X11**    *Read tool length offset set – ReadOnly*  
           0 None  
           1 Value (+/-) tool length offset set
- X12**    *Read axis tool length offset set – ReadOnly*  
           0 Axis X  
           1 Axis Y  
           2 Axis Z  
           3 Axis A  
           4 Axis B  
           5 Axis C  
           6 Axis U  
           7 Axis V  
           8 Axis W
- X13**    *Read the button pressed by LIB MESSAGE – ReadOnly*
- X14**    *Read the type of GoBlock invoked – ReadOnly*  
           0 GoBlock from line or marker  
           1 GoBlock from M6Tn
- X15**    *Read the Axis Index selected for JOG (Ex: 0=X – 1=Y etc.) – ReadOnly*
- X16**    *Read the Axis status in Velocity mode – ReadOnly*  
           0 Axis Stop  
           1 Axis in Acceleration  
           2 Axis in Deceleration  
           3 Axis in Velocity reached
- X17**    *Read Run from CMD – ReadOnly*  
           0 NORMAL RUN (no CMD)  
           1 RUN CMD  
           2 RUN SCRIPT CMD
- X18**    *Parameter P1 CMD – ReadOnly*
- X19**    *Parameter P2 CMD – ReadOnly*
- X20**    *Parameter P3 CMD – ReadOnly*
- X21**    *Parameter P4 CMD – ReadOnly*
- X22**    *Parameter P5 CMD – ReadOnly*
- X23**    *Parameter P6 CMD – ReadOnly*
- X24**    *Parameter P7 CMD – ReadOnly*
- X25**    *Parameter P8 CMD – ReadOnly*
- X26**    *Parameter P9 CMD – ReadOnly*
- X27**    *Parameter P10 CMD – ReadOnly*
- X28**    *Parameter X Canned Cycles – ReadOnly*
- X29**    *Parameter Y Canned Cycles – ReadOnly*
- X30**    *Parameter Z Canned Cycles – ReadOnly*
- X31**    *Parameter R Canned Cycles – ReadOnly*
- X32**    *Parameter P Canned Cycles – ReadOnly*
- X33**    *Parameter Q Canned Cycles – ReadOnly*
- X34**    *Parameter K Canned Cycles – ReadOnly*
- X35**    *Parameter F Canned Cycles – ReadOnly*

- X36** *Parameter A Canned Cycles – ReadOnly*
- X37** *Parameter B Canned Cycles – ReadOnly*
- X38** *Reserved*
- X39** *Read G43 Status – ReadOnly*  
*0 Not Activated*  
*1 Activated*
- X40-X48** *Read Home Stae Axis (X,Y,Z,A,B,C,U,V,W) – ReadOnly*  
*0 Home Not Performed*  
*1 Home Performed*
- X49-X57** *Read Enable stae Axis (X,Y,Z,A,B,C,U,V,W) – ReadOnly*  
*0 Enable Not Performed*  
*1 Enable Performed*
- [\$X58]** *Read state of SUSPENSION WORK ORIGIN – Value 1 if suspended or 0 if not - ReadOnly*
- [\$X59]** *Read state of SUSPENSION WORK OFFSET – Value 1 if suspended or 0 if not – ReadOnly*
- [\$X60]** *Read current state of STOP\_MODE - ReadOnly*
- [\$X61]** *Read current state of PAUSE\_MODE – ReadOnly*
- [\$X62]** *Read current state of FILTER\_MODE - ReadOnly*
- [\$X63]** *Read horizontal mirror state - ReadOnly*  
*0 Disable*  
*1 Enable*
- [\$X64]** *Read vertical mirror state - ReadOnly*  
*0 Disable*  
*1 Enable*
- [\$X65]** *Read G from Retrace – ReadOnly*  
*0 G0*  
*1 G1*  
*2 G2*  
*3 G3*



## 18.4 WORK ORIGIN AND OFFSET VARIABLES

These variables contain the current position of WORK ORIGIN and WORK OFFSET. The maximum number of these variables is 9 (one for each axis). They can be used in PartProgram to read the current zero positions.

### *Work Origin Variable - ReadOnly*

**\$(Yn)** Where **n** is a value from **0** to **8** indicating the axis. The variable will contain the current position of WORK ORIGIN of axis indicated by **n**

### *Work Offset Variable - ReadOnly*

**\$(Wn)** Where **n** is a value from **0** to **8** indicating the axis. The variable will contain the current position of WORK OFFSET of axis indicated by **n**.

n=0 axis X, n=1 axis Y, n=2 axis Z, etc.

## 18.5 USER GENERIC VARIABLES

These variables are used to exchange data between CN and Isous. The maximum number available is **30**. They can be read or written and are 32 bit INTEGER type.

### *User generic variables - Read/Write*

**\$(Kn)** Where **n** is a value from **0** to **29** indicating the variable

## 18.6 ARRAY VARIABLES - DIM

These variables are used like to USER GENERIC VARIABLES, but these, are **get/set** by Index.

First to use, is necessary declare the ARRAY DIMENSION with Function DIM, and the VARIABLE ARRAY NAME:

Ex:

```
DIM $ARR 10
```

In the above example, was declared an ARRAY with name ARR with 10 elements.

**The ELEMENTS are indexed from 0 to 9**

### ARRAY USAGE

The ARRAY VARIABLES contain the same values of GENERIC VARIABLES (double).

For Get/Set the value from ARRAY, the INDEX value must be enclosed between “[..]”.

Ex:

```
DIM $ARR 10
$INDEX=0
$VAR=2
LOOP 10
    $ARR[$INDEX]=$VAR*$INDEX
    $INDEX=$INDEX+1
END_LOOP
$INDEX=0
LOOP 10
    G1 X[$ARR[$INDEX]]
    $INDEX=$INDEX+1
END_LOOP
```

## 18.7 MARKER VARIABLES

Markers are normal variables written in PartProgram. In enhanced programming, using LOOP cycles and VARIABLES, restart from a LINE NUMBER is not enough, because axis position can be defined by variables written in a LOOP cycle. Using MARKERS it's possible restart PartProgram at value of one of these, not at a specific line number, allowing restart also inside LOOP cycles. MARKERS are defined with instruction **MARKER \$NAMEVAR DESCRIPTION**.

Markers can be restored from PlugIn **"BLOCK RESTART"**

**Ex:**

In the next example it is defined a Marker variable named **\$INC**.

It specifies a counter of the number of piece in working

**MARKER \$INC** PIECE NUMBER

\$VAR=0

\$INC=0

F5

G1X0Y0

LOOP 10

    \$INC=\$INC+1

    G1X200

    \$VAR=\$VAR+50

    GOXOY[\$VAR]

END\_LOOP

It will be possible restart PartProgram when **\$INC** variable (set as MARKER) takes a specific value.

## 18.8 VARIABLE FOR ANALOG SPINDLE OUTPUT

Allows to write in the Analog Output a value generally used for the **SPINDLE SPEED**.

### *Variable Analog Output - Read/Write*

**\$(A0)=val**      Where **val** depends of the Channel resolution

### SETTABLE CHANNEL

Are available up to **16** different channels. These are set from **MACHINE PARAMETERS** table **SPINDLE** by parameter **SPEED\_ANALOG\_CH**.

The Channel from 0 to 15 are refer to Analog output on the **NGIO-NGPP** for **NGWARP** or **NGMSX** for **NGMEVO**. The **Channel 0** is the first analog output of the **FIRST** board **NGIO-NGPP-NGMSX**, the **Channel 1** is the second analog output of the **FIRST** board **NGIO-NGPP-NGMSX**, The **Channel 2** is the first analog output of the **SECOND** board **NGIO-NGPP-NGMSX** etc

The Channel **NGMEVO PWM** is the Analog Output only for **NGMEVO** (optional)

The Channels **SPEED\_X,Y,Z,A,B,C,U,V,W** are referred to control the Axis in SPEED MODE for the function **G108.4** e **G108.5**.

These indicate which axis is connected to **G108.4**

Ex: **SPEED\_X**, the **G108.4** function, is connected to Axis X and the **S** function set the speed for this axis

### CHANNELS RESOLUTION

The Channels have the following resolution:

**Channel 0 a 15**      **12 bit**    **Value from 0 to 2047**

**Channel NGMEVO PWM** **8 bit**    **Value from 0 to 255**

**(WARNING The PWM Channel can saturate ,i.e. reach the 10V before of 255 value)**

The Channel resolution is set from **MACHINE PARAMETERS** table **SPINDLE** by parameter **ANALOG\_BIT\_RES**.

Therefore set the following values:

**Channel 0 -15**      **2048**

**NGMEVO PWM**      **Max 256 generally a value from 210 to 230**

(First to all set this value to 256 , check by write **\$(A0)** with a value from 210 to 255, when the ouput is 10V this is the correct value for the parameter **ANALOG\_BIT\_RES**)

### *Example M3 CW SPINDLE*

```

READ_PARMAC "SPEEDMAXSPINDLE" $MAX_RPM // READ MAX RPM AT 10V
READ_PARMAC "ANALOG_BIT_RES" $BIT_RES // READ BIT RESOLUTION
$CURRENT_SPEED=$[X0] // READ THE CURRENT SPEED SET BY S GCODE FUNCTION
$ANALOG_OUT=$CURRENT_SPEED*$BIT_RES/$MAX_RPM // CALC
$(A0)=$ANALOG_OUT // WRITE
$(O1)=1 //SET CW DIRECTION
$(O2)=1 // START

```

### 18.9 MACRO and Gcode Parameters MANAGEMENT

The J variable (Read/Write) allows to Management the internal Macro

\$[Jn]	Valore	Descrizione
\${J0}	1	Suspend: <b>Mstop,Merror,Mpause,MEndProgram,Mtime,MinterruptDI, MinterruptDO, M50003,M50004,M60001,M60002,M60003,M60004</b>
	0	Resume: <b>Mstop,Merror,Mpause,MEndProgram,Mtime,MinterruptDI, MinterruptDO, M50003,M50004,M60001,M60002,M60003,M60004</b>
\${J1}	1	Suspend: <b>Mstop</b>
	0	Resume: <b>Mstop</b>
\${J2}	1	Suspend: <b>Merror</b>
	0	Resume: <b>Merror</b>
\${J3}	1	Suspend: <b>Mpause</b>
	0	Resume: <b>Mpause</b>
\${J4}	1	Suspend: <b>MEndProgram</b>
	0	Resume: <b>MEndProgram</b>
\${J5}	1	Suspend: <b>Mtime</b>
	0	Resume: <b>Mtime</b>
\${J6}	1	Suspend: <b>MinterruptDI</b>
	0	Resume: <b>MinterruptDI</b>
\${J7}	1	Suspend: <b>MinterruptDO</b>
	0	Resume: <b>MinterruptDO</b>
\${J8}	1	Suspend: <b>M50003</b>
	0	Resume: <b>M50003</b>
\${J9}	1	Suspend: <b>M50004</b>
	0	Resume: <b>M50004</b>
\${J10}	1	Suspend: <b>M60001</b>
	0	Resume: <b>M60001</b>
\${J11}	1	Suspend: <b>M60002</b>
	0	Resume: <b>M60002</b>
\${J12}	1	Suspend: <b>M60003</b>
	0	Resume: <b>M60003</b>
\${J13}	1	Suspend: <b>M60004</b>
	0	Resume: <b>M60004</b>
\${J14}	1	Suspend: <b>STOP – Emergency Only</b>
	0	Resume: <b>STOP</b>
\${J15}	1	Suspend: <b>PAUSE</b>
	0	Resume: <b>PAUSE</b>
\${J16}	1	Activates automatic counter axes update when used Hn or G43
	0	Deactivates automatic counter axes update when used Hn or G43
\${J17}		RESERVED
\${J18}		RESERVED
\${J19}		RESERVED
\${J20}	0	<b>ABSOLUTE</b> center for G2 G3 like to <b>ARC_REL</b> parameter
	1	<b>RELATIVE</b> center for G2 G3 like to <b>ARC_REL</b> parameter
\${J21}	0-13	Buffer dimension for G66 X-100 (0 default value) Values from 0 to 13 0-13 1-16 2-32 3-64 4-128 5-256 6-512 7-1024 8-2048 9-4096 10-8192 11-16384 12-32768 13-65536
\${J22}	0-1	Value =1 Enable conversion S in G100 for Laser Power <b>SVal-&gt;G100 XVal</b> Value=0 Disable (at Run always disable)

## 19 POSITIONER

Isous provides the complete management of one or more axes positioners. These can be of different type and in any case their management is entrusted to the application of CNC in use VTB

### 20 PA-PD(n,par)espr Set Absolute position

**PA** allows movement of the positioner at **ABSOLUTE** target

**PD** allows movement of the positioner at **RELATIVE** target

<b>n</b>	Positioner NUMBER from 0 to MAX
<b>par</b>	Controlo parameter OPTIONAL
<b>null</b>	Start at TARGET <b>ESPR</b> with Pending end of movement
<b>0</b>	Start at TARGET <b>ESPR</b> without <b>Pending end of movement</b>
<b>1</b>	Start at TARGET <b>ESPR</b> with <b>Pending end of movement</b>
<b>2</b>	Start HOMING (Espr must be present but not used)
<b>3</b>	Espr >0 Enable positioner Espr <=0 Disable positioner

*Ex:*

```
PA(0)1000 // START AT TARGET 1000 POSITIONER 0
PA(0,0)1000 // START AT TARGET 1000 without pending end of movement
PA(0)[$VAR] // START AT TARGET$VAR i
PA(0,2)1 // START HOMING
PA(0,3)1 // ENABLE POSITIONER 0
```

### 21 PF(n)espr Set Positioner FEED

Set the FEED positioner. Espr FEED VALUE

**n** Positioner NUMBER from 0 to MAX

*Ex:*

```
PF(0)100 //FEED 100
PF(0)[$VAR] // FEED $VAR
```

### 22 PS(n) STOP Positioner

Stop POSITIONER

**n** Positioner NUMBER from 0 to MAX

*Ex:*

```
PS(0) // Stop positioner 0
```

### 23 \_PM(n,par) Read status Positioner

Read the status positioner

**n** Positioner NUMBER from 0 to MAX

**par** Parameter

<b>0</b>	Return 0 Axis Stop fermo - 1 Axis movment
<b>1</b>	READ demand position
<b>2</b>	READ actual position
<b>3</b>	Return 1 axis enabled – 0 axis disabled
<b>4</b>	Return 1 HOMING make– 0 HOMING not make

5 Return 1 axis in ALLARM – 0 OK

*Ex:*

`$VAR=PM(0,par)`

## 24 WORK SETTING

In this charter are defined all axis motion functions.

### 24.1 DEFINITION OF AXIS POSITIONS

They define axis positions in the several interpolation functions (G0-G1-G2-G3). The axis code can be followed by a numeric value or by an expression identifying the position.

#### AXIS CODES

<b>X</b>	<b>Axis X</b>
<b>Y</b>	<b>Axis Y</b>
<b>Z</b>	<b>Axis Z</b>
<b>A</b>	<b>Axis A</b>
<b>B</b>	<b>Axis B</b>
<b>C</b>	<b>Axis C</b>
<b>U</b>	<b>Axis U</b>
<b>V</b>	<b>Axis V</b>
<b>W</b>	<b>Axis V</b>
<b>I</b>	<b>Arc center for X axis of work plane</b>
<b>J</b>	<b>Arc center for Y axis of work plane</b>
<b>K</b>	<b>Arc center for Z axis of work plane (only for G18 -G19)</b>
<b>R</b>	<b>Arc radius</b>

#### Syntax

CODE value or expression

Ex:

```
X100Y20           // POSITION BY NUMERIC VALUE
DX100Y20         // RELATIVE AND ABSOLUTE
X[$VAR]Y[$VAR1]  // POSITION BY VARIABLES
X[cos($VAR)+$VAR1] // POSITION BY EXPRESSION
```

#### 24.1.1 Axis definition for Channel Address

<b>QX</b>	<b>Channel 0</b>	<b>QY</b>	<b>Channel 1</b>
<b>QZ</b>	<b>Channel 2</b>	<b>QA</b>	<b>Channel 3</b>
<b>QB</b>	<b>Channel 4</b>	<b>QC</b>	<b>Channel 5</b>
<b>QU</b>	<b>Channel 6</b>	<b>QV</b>	<b>Channel 7</b>
<b>QW</b>	<b>Channel 8</b>		

The axis position for channel address, allows to always refer to Axis not considering the AXES NAME

Ex if the axes are called in the following mode:

X	Channel 0
Y	Channel 1
Z	Channel 2
B	Channel 3
C	Channel 4
W	Channel 5

QX,QY etc. always refer to the channel and not at name

So

**G1 X100 Y200 B300**

Is like to

**G1 QX100 QY200 QA300**

### 24.1.2 G90 – PROGRAMMING WITH ABSOLUTE POSITIONS

#### Syntax

**G90**

#### Function type

*MODAL (default)*

#### Cancel

**G91**

#### Description

All following positions refer to current ZERO (HOME POSITION, WORK ORIGIN, WORK OFFSET), If no work origin or offset are used positions refer directly to home position.

### 24.1.3 G91 - PROGRAMMING WITH INCREMENTAL POSITIONS

#### Syntax

**G91 G91.1 G91.2**

#### Function type

*MODAL*

#### Cancel

**G90**

#### Description

All following positions refer to current axis position.

**G91.1** Force the values in ABSOLUTE (G90) and store the current state (G90-G91)

**G91.2** Resume the state stored with G91.1 (G90 if was G90 or G91 if was G91)




### 24.1.4 Definition of absolute and incremental positions

Ex:

```

G90           // SET ABSOLUTE POSITIONS
G1X100Y100   // AXIS MOVE TO P1=100,100
G91           // SET INCREMENTAL POSITIONS
X5Y-3        // AXIS MOVE TO P2=105,97
G90           // SET ABSOLUTE POSITIONS
X0Y0         // AXIS MOVE TO P3=0,0

```



## 24.2 WORK ORIGIN

Isous can manage up to **256 different work origins** selectable by **G94**, **G92** and **USER\_ZERO** instructions. A work origin define a point of reference in relationship with home position.

### 24.2.1 Work origin By INDEX

These origins can be set on the fly by taking the value contained in 'file index' ZERI.VAL ". Unlike USER\_ZERO, this can have different indexes for each axis.

#### Syntax

**OXIndex OYIndex ....**

Function type

**MODAL**

Cancel

**G92-G82**

Parameters

**Index –Index Value from file “ZERI.VAL”**

#### Description

Defines the new origin of the axes based on the value contained in 'index set

Es:

```

OX0 OY1 OZ3 // SET origin X from INDEX 0, Y Index 1,Z Index 3

```



**24.2.2 G94 – Work origin at position defined with parameter****Syntax****G94 Xvalue Yvalue .... (DX,DY ecc. Relative value)**

Function type


**MODAL**

Cancel

**G92-G82****Parameters****X,Y,Z,A,B,C,U,V,W (QX,QY,QZ,QA,QB,QC,QU,QV,QW) followed by origin position****Description**

It defines the new origin of one or more axis. Axis not included in parameters list keep the origin unchanged. The new position of zero axis will be defined in the parameter value.

The position value in the parameter refer to an ABSOLUTE position from HOME POSITION regardless of **G90 G91**. The new origin is automatically enabled with G94.

**Ex:****G94 X80Y35 // SET NEW WORK ORIGIN AT 80,35**

**24.2.3 G94.n – Save work orgini at Index****Syntax****G94.n X Y Z etc****Function type****MODAL****Parameters****X,Y,Z,A,B,C,U,V,W Axis to save****.n Number of INDEX ZERO (from 0 to 255).****Description**

Save the current index origins for the axes selected

**Ex:****G94.1 XY // SAVE THE ORIGINS INDEX 1 FOR X,Y****24.2.4 G54, G55, G56, G57, G58, G59 - Work origin from memory file****Syntax****G54 (axis code)****G54 XYZ .... or G54.n XYZ - G54 QX QY QZ .... o G54.n QX QY QZ****Function type****MODAL****Cancel****G92-G82****Parameters****X,Y,Z,A,B,C,U,V,W (QX,QY,QZ,QA,QB,QC,QU,QV,QW)****.n Number of INDEX ZERO (from 0 to 255). If omitted, uses the parameter USER\_ZERO to set index****Description**

It defines the new origin of one or more axis. Axis not included in parameters list keep the origin unchanged. The new position of zero axis will be defined in the parameter value.

The position value will be get from the ORIGIN FILE made by **PLUGIN WORK ORIGIN**.

The new origin is automatically enabled with these instructions.

If **G54** is invoked without parameters **AXIS X** will be set.

The **G54** function, can use the INDEX ZERO indicate in the **.n**

**G54.n** where **n** is a value from 0 to 255 refered to INDEX ORIGIN

If the parameter **.n** is omitted, is used **USER\_ZERO** to set index.

The **.n** parameter not changes the value of **USER\_ZERO** parameter.

Similarly: (these can not use the **.n** parameter)

**G55 for AXIS Y****G56 for AXIS Z****G57 for AXES XY****G58 for AXES YZ****G59 for AXES XZ**

Unlike G94, these functions set WORK ORIGIN from a file saved on pc allowing reload of ORIGINS after switch-off.

**Ex:****USER\_ZERO 0 // uses INDEX 0 (Option default)****G54 XYZ // Set ORIGIN to X Y Z****USER\_ZERO 1 // uses INDEX 1**

**G55** // Set origin Y

**G54.2 XYZ** // SET Origin on XYZ by INDEX 2

**24.2.5 G92 – Work origin in current axis position****Syntax****G92 XYZ etc.**

Function type

*MODAL*

Cancel

*G94-G82***Parameters***X,Y,Z,A,B,C,U,V,W (QX,QY,QZ,QA,QB,QC,QU,QV,QW) axis to be zero***Description**

It defines the new origin of one or more axis in the current position. Axis indicated are zeroed in current position.

**24.2.6 G82 – Work origin in current axis position with sensor offset**

(Shifted on G1082 if USE\_G80\_CYCLES=TRUE)

**Syntax****G82 XYZ G82 QX QY QZ etc.**

Function type

*MODAL*

Cancel

*G94-G92***Parameters***X,Y,Z,A,B,C,U,V,W (QX,QY,QZ,QA,QB,QC,QU,QV,QW) axis to be zero***Description**

It defines the new origin of one or more axis in the current position taking into account acquisition sensor (G102). Axis indicated are zeroed in current position adding sensor offset.

**This function must be used with origin acquisition cycles by G102.****24.2.7 G98 – G53 - Suspend work origin****Syntax****G98****G53**

Function type

*MODAL*

Cancel

*G82 G92 G94 -G54-G55-G56-G57-G58-G59***Description**

It suspends all work origins. All following positions will be refer to HOMING POSITION (if WORK OFFSETS G93 or G95 are disabled)

**24.2.8 G99 – Restore work origin****Syntax****G99**

Function type

*MODAL*

Cancel

*G98***Description**

Restore work origin set with G92 or G94, disabling G98.

**24.2.9 G940 MOVE axes excluding WORK ORIGIN only in the actual block****Syntax****G940 G1Xval Yval****Function type**

deleting

**Description**

All axis movements follow G940 are performed with reference to home axes (WORK ORIGIN EXCLUDES)

**24.2.10 USER\_ZERO – Index of WORK ORIGIN LIST****Syntax****USER\_ZERO** expression**Function type****MODAL****Parameters**

Expression or value indicating the index of ORIGIN LIST to be used

**Description**


Work origin is enabled with the position indexed in the ORIGIN LIST by USER\_ZERO.

**Ex:**

```

USER_ZERO 0
G94 X20Y20           // STORE ORIGIN 0
USER_ZERO 1
G94 X50Y50           // STORE ORIGIN 1
USER_ZERO 2
G94 X150Y100        // STORE ORIGIN 2
USER_ZERO 0           // ENABLE ORIGIN 0
G1X10Y10           // MOVE TO P1
USER_ZERO 1           // ENABLE ORIGIN 1
G1X10Y10           // MOVE TO P2
USER_ZERO 2           // ENABLE ORIGIN 2
G1X10Y10           // MOVE TO P3

```





## 24.3 WORK OFFSET

Isous can manage up to **256 different work offsets** selectable by **G93**, **G95** and **USER\_OFFSET** instructions. A work offset is an additional work origin respecting G92 and G94 functions. As the last one these define a point of reference in relationship with home position. For example see WORK ORIGIN.

### 24.3.1 G93 - Work offset at position defined with parameter

#### Syntax

**G93 Xvalue Yvalue .... (DX,DY ecc. Relative value)**

**G93 P(n)value DP(n)value .... for positioner**

Or **DOXvalue DOYvalue**

#### Function type

**MODAL**

#### Cancel

**G85 G95**

#### Parameters

**X,Y,Z,A,B,C,U,V,W (QX,QY,QZ,QA,QB,QC,QU,QV,QW) followed by offset position**

#### Description

It defines the new offset of one or more axis. Axis not included in parameters list keep the offset unchanged. The new position of zero axis will be defined in the parameter value.

The position value in the parameter refer to an ABSOLUTE position from HOME POSITION regardless of **G90 G91**. The new offset is automatically enabled with G93.

### 24.3.2 G95 - Work offset in current axis position

#### Syntax

**G92 XYZ etc.**

#### Function type

**MODAL**

#### Cancel

**G85 G93**

#### Parameters

**X,Y,Z,A,B,C,U,V,W (QX,QY,QZ,QA,QB,QC,QU,QV,QW) axis to be offset**

#### Description

It defines the new offset of one or more axis in the current position. Axis indicated are zeroed in current position.

### 24.3.3 G85 - Work offset in current axis position with sensor offset

#### Syntax

**G85 XYZ G85 QX QY QZ etc.etc.**

#### Function type

**MODAL**

#### Cancel

**G93-G95**

#### Parameters

**X,Y,Z,A,B,C,U,V,W (QX,QY,QZ,QA,QB,QC,QU,QV,QW) axis to be zero**

#### Description

It defines the new offset of one or more axis in the current position taking into account acquisition sensor (G102). Axis indicated are zeroed in current position adding sensor offset.

**This function must be used with origin acquisition cycles by G102.**

#### **24.3.4 G86 - Hardware preset axis on module 360 degrees**

##### **Syntax**

**G86** XYZ etc. **G86** QX QY QZ etc.

##### **Function type**

**IMMEDIATE**

##### **Parameters**

**X,Y,Z,A,B,C,U,V,W (QX,QY,QZ,QA,QB,QC,QU,QV,QW)** axis to be preset

##### **Description**

The G86 function, is used for rotative axes.

It preset in hardware mode, the absolute axis position to the relative angle.

Ex:

I position axis is 1.450, the relative degrees is 10

#### **24.3.5 G96 - Suspend work offset**

##### **Syntax**

**G96**

##### **Function type**

**MODAL**

##### **Cancel**

**G85 G93 G95**

##### **Description**

It suspends all work offset. All following positions will be refer to HOMING POSITION (if WORK ORIGINS G92 or G94 are disabled).

#### **24.3.6 G97 - Restore work origin**

##### **Syntax**

**G97**

##### **Function type**

**MODAL**

##### **Cancel**

**G96**

##### **Description**

Restore work offset set with G93 or G95, disabling G96.

#### **24.3.7 USER\_OFFSET - Index of WORK OFFSET LIST**

##### **Syntax**

**USER\_OFFSET** expression

##### **Function type**

**MODAL**

##### **Parameters**

Expression or value indicating the index of OFFSET LIST to be used

##### **Description**

Work offset is enabled with the position indexed in the OFFSET LIST by USER\_OFFSET.

Ex:

```
USER_OFFSET 0
G94 X20Y20          // STORE OFFSET 0
USER_OFFSET 1
G94 X50Y50          // STORE OFFSET 1
USER_OFFSET 2
G94 X150Y100 // STORE OFFSET 2
USER_OFFSET 0 // ENABLE OFFSET 0
G1X10Y10          // MOVE TO P1
USER_OFFSET 1 // ENABLE OFFSET 1
G1X10Y10          // MOVE TO P2
USER_OFFSET 2 // ENABLE OFFSET 2
G1X10Y10          // MOVE TO P3
```

Refer to ORIGIN example for drawing.

## 24.4 Work head selection – H function

ISOUS can manage up to **256 different tools heads**.

Each head refer to home position by the value in the HEADS TABLE.

By default no head is enabled, with Hn function it's possible to select one of 256 available heads (first head =0). All offset (one for each axis) of the selected head will be automatically enabled.

### 24.4.1 Hn – Select head

#### Syntax

**H** expression

Function type

*MODAL*

Parameters

Expression or value identifying selected head (firts head 0)

#### Description

Offset of the selected head are enabled.

Ex:

**H0** // SELECT FIRST HEAD

### 24.4.2 G87 – Suspend head offset

#### Syntax

**G87**

Function type

*MODAL*

Cancel

*G88*

#### Description

Offset of selected head are disabled.

Ex:

**G87** // SUSPEND HEAD OFFSET

### 24.4.3 G88 – Restore head offset

#### Syntax

**G88**

Function type

*MODAL*

Cancel

*G87*

#### Description

Last enabled head offset are restored.

Ex:

**G88** // RESTORE HEAD OFFSET

## 24.5 ROTATIVE AXIS

ISOUS can manage rotative axis in several modes. G36 function selects mode.

### 24.5.1 G36 – Rotative axis definition

#### Syntax

**G36 Xmode AXISNAME**

Function type

**MODAL**

Parameters

Mode: 0 → Disable (set linear axis)

1 → Shorter path.

2 → Always positive

3 → Always negative

4 → Shorter path when G1, disabled when G2/G3

AXISNAME name of rative axis (ex A,B etc.)

#### Description

##### Mode 1,4 - Shorter path

CN chooses the shorter path to reach the position selected.

Mode 4 is similar to mode 1 but in G2/G3 interpolation this facilities is disabled.


Ex:

**G36 X1 A**


**G1 A45**

**G1 A315**

first movement **G1 A45**



second movement **G1 A315**



##### Mode 2,3 – Always positive/negative


The selected axis rotates always in the same sense.

**G36 X2 A**


**G1 A45**

**G1 A315**

first movement **G1 A45**



second movement **G1 A315**



## 24.6 HARDWARE PRESET OF AXIS

In particular cases can be necessary preset axis positions in Hardware mode allowing to avoid Overflow in single direction axis.

**Hardware preset must be used with particular attention, because if axis works with a following error, it doesn't take into consider. Consequently it's possible to lost encoder pulses and reference to home position.**

### 24.6.1 G89 – Hardware preset of axis position

#### Syntax

**G89** Xvalue Yvalue .... (DX,DY ecc. Relative value)

#### Function type

*DIRECT*

#### Cancel

*All origin and offset functions*

#### Parameters

*X,Y,Z,A,B,C,U,V,W (QX,QY,QZ,QA,QB,QC,QU,QV,QW) followed by preset value*

#### Description

It defines a new value for current axis positions.

## 24.7 HARDWARE PRESET OF AXIS

In some cases it is necessary to preset the counters of the axes after recovering from a PAUSE, or to RETRACE. This is because during the PAUSE or first RETRACE, the axes are moved using special functions (shift-type etc..).

Not properly updating the counters, abnormal movements may occur during the step of interpolation axes. Generally counters axes are always updated and therefore there is no need an update, but there are cases such as those listed above that require an update. Always use an upgrade at the end of the axis M of recovery from the PAUSE by RETRACE is still a good thing .

### 24.7.1 G84 – Preset Axes counters

(Shifted on G1084 if USE\_G80\_CYCLES=TRUE)

#### Syntax

**G84** X Y Z **G84** QX QY QZ....

#### Function type

*DIRECT*

#### Parameters

*X,Y,Z,A,B,C,U,V,W (QX,QY,QZ,QA,QB,QC,QU,QV,QW) axes to update*

Unless indicated no axis are updated all axes

#### Description

The G84 function copies the values of the coordinates axes by process (typically taken from PAUSE or RETRACE) the process of WORK.

### 24.7.2 G83 – Preset CPU 1 counters

(Shifted on G1083 if USE\_G80\_CYCLES=TRUE)

#### Syntax

**G83**

#### Function type

*DIRECT*

#### Description

**The G83 function is only used to force the update of the counters of the CPU 1, the one that works on MACRO PAUSE, STOP, ERROR.**

**it is advisable to start with the MACRO code G83**

## 24.8 CANNED CYCLES

IsoUs Use 4 Canned Cycles:

G81,G82,G83,G84 (G1081,G1082,G1083,G1084)

### 24.8.1 G1080 – Disabled Canned Cycles

(Shifted on G80 if USE\_G80\_CYCLES=TRUE)

**Syntax**

**G1080**


### 24.8.2 G1081 – Drilling Cycle

(Shifted on G81 if USE\_G80\_CYCLES=TRUE)

**Syntax**

**G1081 Xval Yval Zval Qval Rval Kval Fval**

- X** X position first drilling (optional) not inserted start for current point
- Y** Y position first drilling (optional) not inserted start for current point
- Z** Drilling Depth
- Q** Return Type (Optional) if **Q=1** return to **point 2** in **G1** with **F** programmed, if **Q<>1** or **not inserted** return to **point 2** in **G0**
- R** Disengagement
- K** Repetition (Optional) Active only if G91 and X or Y is inserted)
- F** Drilling Feed (Optional)




- 1) Move in G0 X,Y
- 2) Move in G0 ad R
- 3) Drilling in G1 a Z
- 4) Return in G0 ad R if Q<>1 or not inserted.  
Return in G1 if Q=1

**24.8.3 G1082 – Drilling Cycle**

(Shifted on G82 if USE\_G80\_CYCLES=TRUE)

**Syntax****G1082 Xval Yval Zval Qval Pval Rval Kval Fval**

- X** X position first drilling (optional) not inserted start for current point  
**Y** Y position first drilling (optional) not inserted start for current point  
**Z** Drilling Depth  
**Q** Return Type (Optional) if **Q=1** return to **point 2** in **G1** with **F** programmed, if **Q<>1** or **not inserted** return to **point 2** in **G0**  
**P** Dwell Ms  
**R** Disengagement  
**K** Repetition (Optional) Active only if G91 and X or Y is inserted)  
**F** Drilling Feed (Optional)



- 1) Move in G0 X,Y
- 2) Move in G0 ad R
- 3) Drilling in G1 a Z
- 4) Dwell P Ms
- 5) Return in G0 ad R if Q<>1 or not inserted.  
Return in G1 if Q=1




**24.8.4 G1083 – Drilling Cycle**

(Shifted on G83 if USE\_G80\_CYCLES=TRUE)

**Syntax****G1083 Xval Yval Zval Rval Qval Kval Fval**

<b>X</b>	X position first drilling (optional) not inserted start for current point
<b>Y</b>	Y position first drilling (optional) not inserted start for current point
<b>Z</b>	Drilling Depth
<b>P</b>	Peck Drilling distance (optional)
<b>R</b>	Disengagement
<b>Q</b>	Increase
<b>K</b>	Repetition (Optional) Active only if G91 and X or Y is inserted)
<b>F</b>	Drilling Feed (Optional)



- 1) Move in G0 X,Y
- 2) Move in G0 to R
- 3) Drilling in G1 to Q
- 4) Return G0 to R
- 5) Drilling in G0 to last + DELTA\_G83 (D) Parameter
- 6) Repeat to end


If is insert the P parameter, in the point 4 return not in R position, but in P value position

**24.8.5 G1084 – Tapping Cycle**

(Shifted on G84 if USE\_G80\_CYCLES=TRUE)

**Syntax****G1084 Xval Yval Zval Pval Rval Kval Qval Fval Aval Bval**

- X** X position first drilling (optional) not inserted start for current point  
**Y** Y position first drilling (optional) not inserted start for current point  
**Z** Tapping Depth  
**P** Dwell Ms  
**R** Disengagement  
**K** Repetition (Optional) Active only if G91 and X or Y is inserted)  
**Q** Tapping STEP (mm) only for INTERPOLATE MODE (**MODE\_G84=TRUE**)  
**F** Tapping Feed (Optional)  
**A** Tapping CW or CCW (Optional) if **A=1** CCW  
**B** Return FEED Multiplier (Optional) from point 4 to point 5  
 Ex: **B=2** the FEED (**F**) is multiplied for 2  
 Only value >0



- 1) Move in G0 X,Y
- 2) Move in G0 ad R
- 3) Tapping in G1 to Z interpolate with Axis A A (Set S and F ROT\_G84 parameter defines CW or CCW rotation)
- 4) Dwell P Ms
- 5) Return in G1 to R

## 24.9 SELECT WORK PLANE

Work plane defines:

- The plane for circular interpolation
- The plane where to calculate the axis stop (fast interpolation G60)
- The plane where to calculate the radius tool compensation

### 24.9.1 G17 – Select work plane on X-Y

**Syntax**

**G17**

Function type

*MODAL*

Cancel

*G18 G19 G70*

### 24.9.2 G18 - Select work plane on X-Z

**Syntax**

**G18**

Function type

*MODAL*

Cancel

*G17 G19 G70*

### 24.9.3 G18.1 - Select work plane on X-Z but not in PREVIEW

**Syntax**

**G18.1**

Function type

*MODAL*

Cancel

*G17 G19 G70*

*Select the work plane on X-Z, but in PREVIEW remains X-Y*

### 24.9.4 G19 - Select work plane on Y-Z

**Syntax**

**G19**

Function type

*MODAL*

Cancel

*G17 G18 G70*

### 24.9.5 G19.1 - Select work plane on Y-Z but not in PREVIEW

**Syntax**

**G19.1**

Function type

*MODAL*

Cancel

*G17 G18 G70*

*Select the work plane on Y-Z, but in PREVIEW remains X-Y*

### 24.9.6 G70 - Select work plane on axis by parameters

**Syntax****G70** AXIS1 AXIS2

Function type

*MODAL*

Cancel

*G17 G18 G19***Parameters***Name of the couple of axis formed the new work plane*

Ex:

**G70XA** // select work plane on axis X and A**G70QXQA** // select work plane on Channel 0 Channel 3

## 24.10 START SEARCH OF HOME POSITION

With G71 function Isous allows to execute searching of home position directly in PartProgram. It can be used, for example, when there are spindle axis with double function:

### **SPEED AXIS CONTROLLED AXIS**

In these cases when we switch function mode to a controlled axis it will be necessary to make searching of home position.

#### **24.10.1 G71 – Start Homing cycle**

##### **Syntax**

**G71 AXIS**

Function type

*DIRECT*

Parameter

*Name of axis to be homed*

##### **Description**

It starts searching of home position for selected axis. Searching mode is defined by machine parameter RZERO\_MODE. PartProgram waits for ending of homing procedure.

However STOP PROGRAM is always active. By the parameter of configuration TIME\_OUT\_HOME can be generated an error (1005 Time Out axis Home) if searching isn't terminated in the set time.

Ex:

**G71 X**

#### **24.10.2 G71.1 Enable Axis**

##### **Syntax**

**G71.1 AXIS**

Function type

*DIRECT*

Parameter

*Name of axis to be enabled*

##### **Description**

Enable the Axis selected

Ex:

**G71.1 X**

#### **24.10.3 G71.2 Disable Axis**

##### **Syntax**

**G71.2 AXIS**

Function type

*DIRECT*

Parameter

*Name of axis to be disabled*

##### **Description**

Disable the Axis selected

Ex:

**G71.2 X**

## 24.11 AXIS MOVEMENT FUNCTIONS

### 24.11.1 G0 – Rapid positioning

#### Syntax

**G0**

#### Function type

*MODAL*

#### Cancel

**G1 G2 G3**

#### Description

G0 defines linear movement type with maximum axis speed.

Maximum speed of each axis is defined by machine parameters.

Isous use a specific calculation of axis speed reducing to minimum the axis STRESS during rapid positioning. Unlike other CN where G0 defines **NOT-INTERPOLATED** movement, Isous move axis always in **INTERPOLATION** mode, but calculating the best speed. In this mode we can obtain always a **FLUID MOTION** where all axis start and arrive simultaneously.

Furthermore it is used a specific **ACCELERATION** parameter different from the working one. It is recommended to use G0 only for movement with tool not in working.

Ex:

**G0X0Y0Z0** // MOVE TO 0,0,0 POSITION

### 24.11.2 G0.1 – Rapid positioning with private Acceleration

#### Syntax

**G0.1 AxisName Value**

#### Function type

*Immediate*

#### Cancel

**G1 G2 G3**

#### Description

**G0.1** defines linear movement type with maximum axis speed with private Acceleration. The Acceleration is got from **ACC\_G0.1\_AxisName** parameter. Only one axis at time can be insert in the **G0.1** function. The others features are the same of **G0**.

Ex:

**G0.1 X0** // MOVE TO 0 POSITION

### 24.11.3 G0.2 – Rapid positioning for “Transported Axes”

**Syntax****G0.2****Function type****MODAL****Cancel****G1 G2 G3****Description**

G0.2 is like to G0, but the velocity vector is calculated only in the couple of axes of **WORK PLANE**, and the others axes are “**TRANSPORTED**”. This allows to Tangential Axes don’t use the **VELOCITY VECTOR**.

Ex:

**G0X100Y100A150** // MOVE TO 100,100,150 POSITION WHERE A IS A TANGENTIAL AXIS

**24.11.4 G1 – Linear interpolation a programmed F speed****Syntax****G1****Function type***MODAL***Cancel***G0 G2 G3***Description**

G1 defines linear interpolation mode at programmed speed. If movement are on selected work plane and it's enabled **FAST interpolation (without stop on edge) G60**, Isous calculates automatically stop on edge. G1 enables movement at programmed F speed and can be modified by override potentiometer (if not disabled with G11). According to CN we can obtain different performance about number of segment processed in a time unit. Cn of NG35 series process about **350 segments per second**, instead **120** for CN of NGM13 series. That defines the maximum working velocity when the path is formed by **micro-segments**. All CN have a movement buffer, Isous tries to maintain it full (in G60 mode). If buffer empties CN stops axis obtaining a not fluid movement.

Ex:

**G1X300Y200Z20****24.11.5 G1.1 – G1-G2-G3 Suspension and Set G0****Syntax****G1.1****Function type***Immediate***Cancel***G1 G2 G3***Description**

G1.1 save the current Gx setted (G1 G2 G3) and force a G0 for the next movements

Ex:

**G1.1X300Y200Z20****24.11.6 G1.2 – Resume Gx saved with G1.1****Syntax****G1.2****Function type***Immediate***Cancel***G0***Description**

G1.2 Resume the G saved with G1.1

Ex:

**G1.2X300Y200Z20**



**24.11.7 G2/G3 - Circular interpolation a programmed F speed**

**Syntax**

**G2 (cw)**

**G3 (ccw)**

**Function type**

**MODAL**

**Cancel**

**G0 G1**

**Description**

G2 and G3 define circular interpolation at programmed speed. If movement are on selected work plane and it's enabled **FAST interpolation (without stop on edge) G60**, Isous calculates automatically stop on edge. G2 and G3 enable movement at programmed F speed and can be modified by override potentiometer (if not disabled with G11). Circular interpolation can be executed by center parameters I and J, or by radius parameter R. With the second one it's not possible to generate a complete circle, for that it must be used I and J.


**SHORT WAY and LONG WAY arc**

Using radius parameter there are two arcs defined by the same parameters. The selection is via radius sign.

If RADIUS is positive a SHORT WAY ARC is generated.

If RADIUS is negative a LONG WAY ARC is generated.

See the example for details.



LONG WAY ARC  
R-150

SHORT WAY ARC  
R150

Ex:

**G0X100Y100**

**G2X300Y100R-150** // EXECUTE LONG WAY ARC

**G0X100Y100**

**G2X300Y100R150** // EXECUTE SHORT WAY ARC

**24.11.8 G30 - Enable automatic insert of fillet on edges****Syntax****G30 Rradius Aangle**

Function type

**MODAL**

Cancel

**G33**

Parameters

**R** value of fillet radius (radius=0 disables the function)**A** Angle degree of insert threshold**Description**

G30 inserts automatically fillets on edges. The fillet radius is defined with parameter R, parameter A defines the angle threshold under which G30 function doesn't intervenes leaving path unchanged. This function is useful to soften movement in angular path.


Fillet is inserted only if it can be contained inside two segment.

Setting a RADIUS=0 the function is disabled.

Ex:

// NORMAL PATH WITHOUT G30


```
G0 X75.45 Y157.46
G1 X107.84 Y167.43
G1 X108.3 Y142.73
G1 X117.36 Y150.44
G1 X126.2 Y139.34
G1 X140.92 Y142.51
```



Ex:

// SAME PATH USING G30

```
G0 X75.45 Y157.46
G30 R5 A20 // RADIUS=5 ANGLE=20 deg.
G1 X107.84 Y167.43
G1 X108.3 Y142.73
G1 X117.36 Y150.44
G1 X126.2 Y139.34
G1 X140.92 Y142.51
```



R=5 mm

## **G31 – Suspend of automatic insert of fillet**

### **Syntax**

**G31**

**Function type**

*MODAL*

**Cancel**

*G30*

### **Description**

Suspend G30. It can be restore with G32.

## **24.11.9 G32 - Restore of automatic insert of fillet**

### **Syntax**

**G32**

**Function type**

*MODAL*

**Cancel**

*G31*

### **Description**

Restore G30 suspended by G31.

**24.11.10 G33 - Enable automatic insert of bevel on edges****Syntax****G33 Rlen Aangle****Function type****MODAL****Cancel****G30****Parameter**

**R**      *length of bevel (len=0 disables the function)*  
**A**      *Angle degree of insert threshold*

**Description**


G33 inserts automatically bevels on edges. The bevel length is defined with parameter R, parameter A defines the angle threshold under which G33 function doesn't intervene leaving path unchanged. This function is useful to soften movement in angular path.

Bevel is inserted only if it can be contained inside two segments.

Setting a RADIUS=0 the function is disabled.


Ex:

```
// NORMAL PATH WITHOUT G33
G0 X75.45 Y157.46
G1 X107.84 Y167.43
G1 X108.3 Y142.73
G1 X117.36 Y150.44
G1 X126.2 Y139.34
G1 X140.92 Y142.51
```



Ex:

```
// SAME PATH USING G33
G0 X75.45 Y157.46
G33 R5 A20 // LEN=5MM ANGLE=20 deg.
G1 X107.84 Y167.43
G1 X108.3 Y142.73
G1 X117.36 Y150.44
G1 X126.2 Y139.34
G1 X140.92 Y142.51
```



Len=5 mm

**24.11.11**      ***G34 - Suspend of automatic insert of bevel*****Syntax****G34****Function type***MODAL***Cancel***G33***Description**

Suspend G33. It can be restore with G35.

**24.11.12**      ***G35- Restore of automatic insert of bevel*****Syntax****G35****Function type***MODAL***Cancel***G34***Description**

Restore G33 suspended by G34.

**24.11.13 G102 – Start searching sensor position****Syntax****G102****G102.2****Function type*****DIRECT*****Description**

It start acquisition from sensor.

Axis move to positions selected by X,Y,Z etc. The values refer to an absolute or relative position according with G90 G91. Selected **WORK ORIGIN** and **WORK OFFSET** are considered too. More axis can be move simultaneously (interpolated) and the speed is set with the machine parameter **ACQ\_VEL**.

Also a acquisition mode can be selected by machine parameter **ACQ\_MODE**.

Executing can be stopped by activation of **SENSOR** or by reaching **TARGET** position. In the first case PartProgram continues to execute from next block to G102.

In case of reaching of **TARGET** position PartProgram ends with **ACQ. SENSOR ERROR**.


**G102** waits for axis stop before to proceed with acquisition cycle.

**G102.2** In case of reaching of **TARGET** position doesn't generate any ALARM

**Ex:****G90****G102 X100****G92 X**

// ACQUISITION MOVING ONLY AXIS X UP TO POSITION 100

// SET WORK ORIGIN IN ACQUIRED POINT



**24.11.14 G102.1 – Acquisition from PxVision System****Syntax****G102.1 XYZABCUVWFS (parameters)****Function type*****DIRECT*****Description**

IsuUs can acquired data from **PxVision** system. For use **G102.1** must be installed the PlugIn:

***UsPxVisionAcq***

With this function is possible the following operations:

**Work Origins****Tool Length and Diameter measure****Objects Measures****Objects Detection**

**G102.1** function uses the **X** parameter for define the acquisition type (see the PxVision document for more informations)

***X PARAMETER***                      ***Defines the acquisition Type*****Marker Detection**                      **Detect a Marker and get Center****X=0**      **Circular Marker Detection****X=1**      **Square Marker Detection****X=2**      **Type1 Marker Detection****X=3**      **Hole Marker Detection****Probe Acquisition**                      **Virtual probe and get data acquisition****X=100**      **Probe Single Point****X=101**      **Probe Work Origins****X=102**      **Probe Tool Measure****Detector**                                      **Objects detection****X=200**      **Gray Detector****X=201**      **Contrast Detector****X=202**      **Brightness Detector****X=203**      **Color Detector****X=204**      **Area Detector****Measures**                                      **Generic Objects measures****X=300**      **Cross Section****X=301**      **Calliper****X=302**      **Fit Line****X=303**      **Fit Circle****X=304**      **Gap Cross Section*****Y PARAMETER***                      ***Defines the return data referred to axes values*****Y=0**                      **The values are in RELATIVE all values include Work Origins, Offset etc. set by IsuUs****Y=1**                      **The values are in ABSOLUTE all values are refer to machine origins**

The data returned by **G102.1** are put in the IsoUs Variables by ADDRESS “:”.  
The start Address is configured by **PlugIn UsPxVisionAcq** :

**START\_ADDRESS**        **DATA\_INPUT**    Data Inputs for single function (Reserved)  
**START\_ADDRESS+100**   **DATA\_OUTPUT**   Data returned from function

Eg: **START\_ADDRESS= 10000**        **DATA\_OUTPUT =10100.**

**Is recommended use Address from 10000 to 15000**

### **G102.1 X0-1-2-3 MARKER DETCTION**

#### G102.1 X0 e G102.1 X2 (Circular, Type1)

##### Add Parameters - None

<b>DATA_OUTPUT</b>	<b>1</b> Acq Ok	<b>0</b> Acq Error
<b>DATA_OUTPUT +1</b>	<b>X</b> Center Marker (mm) referred to Camera Center	
<b>DATA_OUTPUT +2</b>	<b>Y</b> Center Marker (mm) referred to Camera Center	
<b>DATA_OUTPUT +3</b>	<b>Radius</b> Marker (mm)	
<b>DATA_OUTPUT +4</b>	<b>Angle</b> Marker (drg)	

#### G102.1 X1 (Square)

##### Add Parameters - None

<b>DATA_OUTPUT</b>	<b>1</b> Acq Ok	<b>0</b> Acq Error
<b>DATA_OUTPUT +1</b>	<b>X</b> Center Marker (mm) referred to Camera Center	
<b>DATA_OUTPUT +2</b>	<b>Y</b> Center Marker (mm) referred to Camera Center	
<b>DATA_OUTPUT +3</b>	<b>Width</b> Marker (mm)	
<b>DATA_OUTPUT +4</b>	<b>Height</b> Marker (mm)	
<b>DATA_OUTPUT +5</b>	<b>Angle</b> Marker (drg)	

#### G102.1 X3 (Hole)


##### Add Parameters - None

<b>DATA_OUTPUT</b>	<b>1</b> Acq Ok	<b>0</b> Acq Error
<b>DATA_OUTPUT +1</b>	<b>X</b> Center Marker (mm) referred to Camera Center	
<b>DATA_OUTPUT +2</b>	<b>Y</b> Center Marker (mm) referred to Camera Center	
<b>DATA_OUTPUT +3</b>	<b>Radius</b> Marker (mm)	



**G102.1 X100-101-102 Probe Acquisition**  
**G102.1 X100 Bval Zval (Single Point)**

Start Probe  
 X,Y Axes Position  
 +/- Offset B Parameter



**Add Parameters**


**B** Optional Offset in mm +/- in the acquisition direction set by Z of Probe (default 10mm)

**Z** Mandatory Probe direction  
 Z=0 Y POSITIVE  
 Z=1 Y NEGATIVE  
 Z=2 X POSITIVE  
 Z=3 X NEGATIVE

DATA\_OUTPUT 1 Acq Ok 0 Acq Error  
 DATA\_OUTPUT +1 X Probe (mm) referred to Machine Origins  
 DATA\_OUTPUT +2 Y Probe (mm) referred to Machine Origins

**G102.1 X101 Vval(Work Origins)**

For this function, is necessary configure one or more **JOBS** from PxVisionBrowser with **4 ProbeSinglePoints** that define **2 points Start, End** for X direction and **2 points Start, End** for Y direction



**Add Parameters**

**V** Mandatori JOB index (Insert in PlugIn UsPxVisionAcq) for use

DATA\_OUTPUT 1 Acq Ok 0 Acq Error  
 DATA\_OUTPUT +1 X Origin  
 DATA\_OUTPUT +2 Y Origin  
 DATA\_OUTPUT +3 Angle


**G102.1 X102 Vval (Tool Measure)**

Diameter and Tool Length measure


For use this function, is necessary to configure one or more **JOBS** by **PxVisionBrowser** application with parameters for Length Measure in **ProbeLine** and Diameter measure in **Calliper**

Configure the **ProbeLine** and **Calliper** for contain the max tool dimensions

**ProbeLine**



**Calliper**



**Add Parameters**

**V** Mandatori JOB index (Insertit in PlugIn UsPxVisionAcq) for use

<b>DATA_OUTPUT</b>	<b>1</b> Acq Ok	<b>0</b> Acq Error
<b>DATA_OUTPUT +1</b>	<b>Length</b> Tool (mm)	
<b>DATA_OUTPUT +2</b>	<b>Diameter</b> Tool (mm)	

**G102.1 X200-201-202-203-204** **Detector**

For use this function, is necessary to configure the Detectors by **PxVisionBrowser** application

**G102.1 X200 G102.1 X201 G102.1 X202 X203 X204 (Gray,Contrast,Brightness,Color,Area)**

**Add Parameters - None**

<b>DATA_OUTPUT</b>	<b>1</b> Acq Ok	<b>0</b> Acq Error (detector 1)
<b>DATA_OUTPUT +1</b>	<b>1</b> Acq Ok	<b>0</b> Acq Error (detector 2)
<b>DATA_OUTPUT +2</b>	<b>1</b> Acq Ok	<b>0</b> Acq Error (detector 3)
..		
Etc.		

**G102.1 X300-301-302-303-304** **Measures**

For use this function, is necessary to configure the Measures by **PxVisionBrowser** application

**G102.1 X300 G102.1 X301 (Cross Section,Calliper)**

**Add Parameters - None**

<b>DATA_OUTPUT</b>	<b>1</b> Acq Ok	<b>0</b> Acq Error (Config 1)
<b>DATA_OUTPUT +1</b>	<b>Measure</b> (mm) (Config 1)	
<b>DATA_OUTPUT +2</b>	<b>1</b> Acq Ok	<b>0</b> Acq Error (Config 2)
<b>DATA_OUTPUT +3</b>	<b>Measure</b> (mm) (Config 2)	
<b>DATA_OUTPUT +4</b>	<b>1</b> Acq Ok	<b>0</b> Acq Error (Config 3)
<b>DATA_OUTPUT +5</b>	<b>Measure</b> (mm) (Config 3)	
..		
Etc..		

**G102.1 X302 (Fit Line)****Add Parameters - None**

<b>DATA_OUTPUT</b>	<b>1</b> Acq Ok	<b>0</b> Acq Error (Config 1)
<b>DATA_OUTPUT +1</b>	<b>Len Line</b> (mm) (Config 1)	
<b>DATA_OUTPUT +2</b>	<b>Angle Line</b> (drg) (Config 1)	
<b>DATA_OUTPUT +3</b>	<b>1</b> Acq Ok	<b>0</b> Acq Error (Config 2)
<b>DATA_OUTPUT +4</b>	<b>Len Line</b> (mm) (Config 2)	
<b>DATA_OUTPUT +5</b>	<b>Angle Line</b> (drg) (Config 2)	
<b>DATA_OUTPUT +6</b>	<b>1</b> Acq Ok	<b>0</b> Acq Error (Config 3)
<b>DATA_OUTPUT +7</b>	<b>Len Line</b> (mm) (Config 3)	
<b>DATA_OUTPUT +8</b>	<b>Angle Line</b> (drg) (Config 3)	
..		
Etc.		

**G102.1 X303 (Fit Circle)****Add Parameters - None**

<b>DATA_OUTPUT</b>	<b>1</b> Acq Ok	<b>0</b> Acq Error (Config 1)
<b>DATA_OUTPUT +1</b>	<b>Center X</b> (mm) referred to Camera Center (Config 1)	
<b>DATA_OUTPUT +2</b>	<b>Center Y</b> (mm) referred to Camera Center (Config 1)	
<b>DATA_OUTPUT +3</b>	<b>Radius</b> (mm) (Config 1)	
<b>DATA_OUTPUT +4</b>	<b>1</b> Acq Ok	<b>0</b> Acq Error (Config 2)
<b>DATA_OUTPUT +5</b>	<b>Center X</b> (mm) referred to Camera Center (Config 2)	
<b>DATA_OUTPUT +6</b>	<b>Center Y</b> (mm) referred to Camera Center (Config 2)	
<b>DATA_OUTPUT +7</b>	<b>Radius</b> (mm) (Config 2)	
..		
Etc.		

**G102.1 X304 (Gap Cross Section)****Add Parameters - None**

<b>DATA_OUTPUT</b>	<b>1</b> Acq Ok	<b>0</b> Acq Error (Config 1)
<b>DATA_OUTPUT +1</b>	<b>Max Val</b> (mm) (Config 1)	
<b>DATA_OUTPUT +2</b>	<b>Min Val</b> (mm) (Config 1)	
<b>DATA_OUTPUT +3</b>	<b>1</b> Acq Ok	<b>0</b> Acq Error (Config 2)
<b>DATA_OUTPUT +4</b>	<b>Min Val</b> (mm) (Config 2)	
<b>DATA_OUTPUT +5</b>	<b>Min Val</b> (mm) (Config 2)	
Etc.		

**BarCode Reader**

Can be read **BarCode** and **QrCode**, before to use this function, must create a list by PlugIn **UsPxVisionAcq**, for associate the BarCode or QrCode to an **INDEX**

**G102.1 X400****Add Parameters - None**

<b>DATA_OUTPUT</b>	<b>1</b> Acq Ok	<b>0</b> Acq Error (Config 1)
<b>DATA_OUTPUT +1</b>	<b>Index in the list (-1) not found</b>	

**G102.1 X401   Ocr Reader**

Can be read a text string without Cr/Lf.

As the BarCode, also the Text String must coded by PlugIn **UsPxVisionAcq** for associate the OcrCode to an **INDEX**

**G102.1 X401****Add Parameters - None**

<b>DATA_OUTPUT</b>	<b>1</b> Acq Ok	<b>0</b> Acq Error (Config 1)
<b>DATA_OUTPUT +1</b>	<b>Index in the list (-1) not found</b>	

## 24.12 PROGRAMMING AXIS INTERPOLATION SPEED

Interpolation speed is a very important parameter to obtain a fine working. Speed value is expressed in Mt/min with a resolution dependent by Isous configuration. Selected interpolation speed can be changed in automatic way (arc auto-reduction), or manually with parameter **F** or override potentiometer. F parameter acts only when invoked in PartProgram and however at begin of next segment, OVERRIDE potentiometer instead acts in any time allowing immediately change of speed.

### 24.12.1 F – Speed of axis interpolation

#### Syntax

**F**val

Function type

**MODAL**

Parameter

**Val**      *Value in Mt/min of speed*

#### Description

F function set vectorial speed of the axis. Such speed will be separated by interpolator according with the programmed trajectory.

G0 movement are not affected by parameter F.

Ex:

**G0 X**75.45 **Y**157.46      // RAPID MOVEMENT AT F MAX

**F**10.3      // SET AXIS SPEED AT 10.3 MT/MIN

**G1 X**107.84 **Y**167.43

### 24.12.2 ARC speed auto-reduction

Function type

*Configuration programming*

Parameter

*See Isous configuration*

#### Description

Isous uses a special algorithm which allows to reduce automatically axis speed during circular interpolation. It simplifies F programming in path formed by arcs without to insert an appropriate speed for each arc (lower speed for lower radius – bigger speed for bigger radius), Isous does it for you.

The calculation is base on the centrifugal acceleration and it must be manually searched experimentally .

## 24.13 Work Plane Transformation

Here they are explained all function relative to manage with work plane such as: rotation and mirror.

### 24.13.1 G120 – Vertical mirror

#### Syntax

**G120**

Function type

**MODAL**

Cancel


**G121**

#### Description

It enables vertical mirror on selected work plane. It acts inverting automatically the sign of axis Y.

Ex:

```
G121 // DISABLE G120
// ***** EXECUTE FIRST SQUARE
G0 X100 Y100
G1 X150
Y50
X100
Y100
// ***** END FIRST SQUARE
G120 // ENABLE VERTICAL MIRROR
// ***** EXECUTE SECOND SQUARE
G0 X100 Y100
G1 X150
Y50
X100
Y100
// ***** END SECOND SQUARE
```



### 24.13.2 G121 – Disable vertical mirror

#### Syntax

**G121**

Function type

**MODAL**

Cancel

**G120**

#### Description

Disable vertical mirror on work plane.

**24.13.3 G24 – Horizontal mirror****Syntax****G24**

Function type

*MODAL*

Cancel

*G25***Description**


It enables horizontal mirror on selected work plane. It acts inverting automatically the sign of axis X.

Es:

```

G25 // DISABLE G24
// ***** EXECUTE FIRST SQUARE
G0 X100 Y100
G1 X150
Y50
X100
Y100
// ***** END FIRST SQUARE
G24// ENABLE VERTICAL MIRROR
// ***** EXECUTE SECOND SQUARE
G0 X100 Y100
G1 X150
Y50
X100
Y100
// ***** END SECOND SQUARE

```

**24.13.4 G25 – Disable horizontal mirror****Syntax****G25**

Function type

*MODAL*

Cancel

*G24***Description**

Disable horizontal mirror on work plane.

**24.13.5 G22 – Echange axis of work plane****Syntax****G22**

Function type

*MODAL*

Cancel

*G23***Description**

Axis of work plane are exchanged between them (ex. X with Y).

**24.13.6 G23 – Restore axis of work plane****Syntax****G23**

Function type

**MODAL**

Cancel

**G22****Description**

Restore the original axis of work plane.

**24.13.7 G26 – Exchange axis by parameter****Syntax****G26 Axis1 Axis2**

Function type

**MODAL**

Cancel

**G27****Description**

A couple of selected axis by parameters are exchanged between them.

Ex:

**G26 YZ // EXCHANGE Y WITH Z****G26 QYQZ // EXCHANGE CHANNEL 1 WITH CHANNEL 2****24.13.8 G27 – Suspend G26****Syntax****G27**

Function type

**MODAL**

Cancel

**G26****Description**

It suspends the axis exchanging set with G26

**24.13.9 G28 – Restore G26**

(Shifted on G1028 if USE\_G80\_CYCLES=TRUE)

**Syntax****G28**

Function type

**MODAL**

Cancel

**G27****Description**

Restore axis exchanging set with G26



**24.13.10**      ***G1028 – Return to Home***  
 (Shifted on G28 if USE\_G80\_CYCLES=TRUE)

**Syntax**

**G1028 Xval Yval Zval....**

**Description**

Return to **HOME** , the Axes values are indicates in the parameters **G28HOME\_X, G28HOME\_Y** etc. **Xval,Yval,Zval** etc. Optional Parameters  
 If they are inserted before to go to HOME position the Axes are moved to Xval,Yval,Zval position  
 The FEED is get to previous F set or the G0 function

**24.13.11**      ***G51 – Suspend work plane rotation***

**Syntax**

**G51**

Function type

**MODAL**

Cancel

**G50 G52**

**Description**

Suspend the rotation of work plane.

**24.13.12**      ***G52 – Restore work plane rotation***

**Syntax**

**G52**

Function type

**MODAL**

Cancel

**G51**

**Description**

Restore last work plane rotation set with G50.

**24.13.13 G50 - Work plane rotation****Syntax****G50 X**centerx **Y**centery **Z**angle (DX,DY Relative value)**Function type**

Disabled when PartProgram start

**Parameters**


**X**      **Rotation center axis X**  
**Y**      **Rotation center axis Y**  
**Z**      **Rotation angle in degree**

**Description**

It execute a rotation of work plane. All following position will be modified with this transformation.  
 At each start of PartProgram rotation center is disabled, or if Angle is 0.

**Ex:**

```
// ROTATION OF A SQUARE
$ROT=0
LOOP 24
G0 X100 Y100
G1 X150
Y50
X100
Y100
$ROT=$ROT+15// INCR. ANGLE
G50 X100 Y50 Z[$ROT]// ROTATION
END_LOOP
```



**24.13.14 G1050 – Disable Scaling****Syntax****G1050**

Function type

**MODAL**

Cancel

**G1051****Description**

G1050 function, disable SCALING G1051

**24.13.15 G1051 – Enable Scaling****Syntax****G1051 Xcentrox Ycentroy Zcentroz IratioX Jratioy Kratioz Pratioxyz**

Function type

**MODAL**

Cancel

**G1050****Parameters**

**X** *X Scaling Center – se non inserito viene presa la posizione attuale dell' asse X*

**Y** *Y Scaling Center – se non inserito viene presa la posizione attuale dell' asse Y*

**Z** *Z Scaling Center – se non inserito viene presa la posizione attuale dell' asse Z*

**I** *X Ratio – X<1 reduces X>1 increases - if it is not inserted, uses the previous value*

**J** *Y Ratio – Y<1 reduces Y>1 increases - if it is not inserted, uses the previous value*

**K** *Z Ratio – Z<1 reduces Z>1 increases - if it is not inserted, uses the previous value*


**P** *XYZ Ratio – P<1 reduces P>1 increases – Uses the same Ratio for X,Y,Z*

**IF NO PARAMETERS ARE INSERTED (Only G1051) the previous values are used****Description**

G1051 allows to scaling the Gcode with X,Y,Z Coordinate center.


Ex:

```
//ORIGINAL
G0X0Y0
G1X10Y10
Y20
X20
Y10
X10
G0X0Y0
//SCALING
G1051 X15Y15I0.5J0.5
G1X10Y10
Y20
X20
Y10
X10
G0X0Y0
//SCALING
G1051 X15Y15I2J2
G1X10Y10
Y20
X20
Y10
X10
```



Ex:

```
//ORIGINAL
G0X0Y0
G1X10Y10
Y20
X20Y30
G3X40Y30R10
G1X50Y20
X50Y10
X10Y10
G0X0Y0
//SCALING
G1051 X30Y20I0.5J0.5
G1X10Y10
Y20
X20Y30
G3X40Y30R10
G1X50Y20
X50Y10
X10Y10
G0X0Y0
```



**24.13.16**      ***G103 – Set RTCP parameters*****Syntax****G103** Xval Yval Zval ..... **G103** QXval QYval QZval**Function type****MODAL****Parameters****X**      *Value of parameter X***Y**      *Value of parameter Y***Z**      *Value of parameter Z*

.....

**Description**

**Isous** uses a **RTCP** (rotate tool center point) adaptable to any geometry of the machine. Therefore the value passed to function by **G103** (max 9 value X,Y,Z,A,B,C,U,V,W) will determine the right parameters for a specific geometry. The calculation of RTPC must be set in installation phase and it will be necessary the intervention of a specialized technician. **G103** passes the parameters to CN without enabling RTCP function. Enable/disable is demanded to **G104-G105** function.

**24.13.17**      ***G104 – Enable/restore RTCP*****Syntax****G104****Function type****MODAL****Cancel****G105****Description**G104 enable or restore **RTCP** function on CN.**24.13.18**      ***G104.1 – Enable/restore RTCP*****Syntax****G104.1****Function type****MODAL****Cancel****G105****Description**G104 enable or restore **RTCP** function on CN moving the X,Y,Z based the rotative Axes position**24.13.19**      ***G105 – Disable RTCP*****Syntax****G105****Function type****MODAL****Cancel****G104****Description****G105** disable **RTCP** function on CN restoring normal interpolation. RTCP function can be restored with **G104**.


## 25 TOOL RADIUS COMPENSATION

ISOUS manages the tool offset compensation, that can be activated with G41 and G42 ISO function. These functions allow to adjust the tool track, according to the tool diameter. Using this mode, it's possible to have some interference on the tool track, if we have high diameter tools.

ISOUS can display on its interface, a graphic preview, where it will be shown interfering points, due to make possible to adjust the track, previous to the work start.

However, the tool compensation will take high attention on the track elaboration.

Furthermore, it will insert automatically connection arcs (with tool radius as arc radius), if the intersection point of the compensation tracks is very far away from the real intersection point.



### 25.1.1 G41/G42 – Enable left/right radius tool compensation

#### Syntax

**G41**

Function type

**MODAL**

Cancel

**G40**

#### Description

G41 Enable left compensation.

G42 Enable right compensation.

Tool diameter is set by **D** function or by tool table **Tn**.

### 25.1.2 G40 – Disable radius tool compensation

#### Syntax

**G40**

Function type

**MODAL**

Cancel

**G41 - G42**


#### Description

G40 disables the radius tool compensation (both left and right).

PATH WITH G41

Ex:

```
D5// DIAMETER=5mm
G41// LEFT COMP.
G0X30Y40
G1X10Y10
G1X50Y30
G2X80Y30R15
G1X90Y25
G1X110
G1X130Y20
G40
```




PATH WITH G40

ADDING ARC

Ex:

```
D5// DIAMETER=5mm
G42// RIGTH COMP.
G0X30Y40
G1X10Y10
G1X50Y30
G2X80Y30R15
G1X90Y25
G1X110
G1X130Y20
G40
```



PATH WITH G42

25.1.3 D – Tool diameter

Syntax

Dvalue

Function type

MODAL

Cancel

Tn (optional correction set by TOOL TABLE)

Parameter

Value Tool diameter in mm

Description

D allows to set the value in mm of tool diameter to be used with G41 G42.

**Tool diameter D must be set before G41-G42 and it must not changed until the compensation remains active.**

### 25.1.4 G47 – Set tool entry mode

#### Syntax


**G47** Xval

Function type

**MODAL**


#### Description

G47 allow to choose two modes of tool entry. The default mode is **G47 X0**: compensation starts on next segment. With **G47 X1** compensation starts immediately and it is useful with closet shape.



Ex. Working with **G47 X0** (default)

Ex. Working with **G47 X1**



#### NOTE:

Using G47X1 tool must be positioned in start point byl PartProgram (so already shifted from shape of tool radius). The end of compensation instead must follow this scheme:

**G0 Z (UP) // raise Z**

**G40 // disable compensation**

**G1 Z (UP) // raise Z again**

Example for compensation of a square:

**G47 X1**

**F 2.5**

**G0 X 26.2332 Y 26.1708 // move tool on start point**

**F 5**

**G1 Z 0 // move Z to work position**

**D 3 // set tool diameter**

**G42 // enable compensation G42**

**G1 X 24.7332 Y 26.1708**

**G1 X 24.7332 Y 76.1708**

**G1 X 74.7332 Y 76.1708**

**G1 X 74.7332 Y 26.1708**

**G1 X 24.7332 Y 26.1708**

**G0 Z 20 // raise Z**

**G40 // disable compensation**


**G1 Z 20 // raise Z again**



## 25.2 TOOL LENGHT COMPENSATION

It's possible to compensate tool length on any axis. It is useful when we want to work the same PartProgram with tools of different length. Tool length compensation acts only in the direction selected by G43 function.

The axis affected by compensation is selectable as well as length of correction. Length correction compensates movement on the selected axis. The effective tool length must be the measure of projection tools from spindle.



### 25.2.1 G43 – Enable tool length compensation from parameter

#### Syntax

**G43 Xlen Kmode AXISdir(+/-)** (DX Relative value)

#### Function type

**MODAL**

#### Cancel

**G45** (optional correction set by Tool Table)

#### Parameters

**len** tool length in mm es: 12.35

If LEN=0 tool length is taken by tool table Tn

**Mode** Optional K parameter, this can have the following values:

**K0** Normal Mode how if K is omitte

**K1** With this parameter, the tool length is used how additional OFFSET , therefore the axis value (ABSOLUTE,RELATIVE) is immediately updated  
In this mode the "dir" parameter is not considered, the direction is defined by "LEN" sign (+ or -)

**K2** As K1 but the sign of LEN TOOLS from table is inverted

**AXIS** Axis on which apply length compensation

**dir** Direction of compensation

+ positive

- negative

#### Description


G43 enables tool length compensation. Corrections are applied only in the selected axis.

#### Ex:

**G43 X10.3 Z+** // ENABLE POSITIVE COMPENSATION ON AXIS Z OF LEN=10.3mm

**25.2.2 G44 – Disable tool length compensation G43****Syntax****G44****Function type****MODAL****Cancel****G43****Description**

G44 disable tool length compensation set with G43

**25.2.3 G44.1 (2) – Suspend/Resume G43****Syntax****G44.1 // Suspend G43****G44.2 // Resume G43 with old parameters****Function type****MODAL****Cancel****G43****Parameters****25.2.4 G45 – Enable tool length compensation from tool table T****Syntax****G45 AXISdir(+/-)****Function type****MODAL****Cancel****G43** (optional correction set by Tool Table)**Parameters****AXIS** Axis on which apply length compensation**dir** Direction of compensation**+ positive****- negative****Description**G45 works like G43 but the length of tool is taken only in the tool table with **Tn**.**Ex:****G45 Z+ // ENABLE POSITIVE TOOL LENGTH COMPENSATION ON AXIS Z**

### 25.2.5 *G46 -- Disable tool length compensation G45*

**Syntax****G46****Function type***MODAL***Cancel***G45***Description**

G46 disable tool length compensation set with G45

## 25.3 INTERPOLATION MODES

Isous can use several axis interpolation modes allowing to adapt it in a lot of types of machine.

### 25.3.1 G60 – Enable FAST interpolation without stop on segments

#### Syntax

**G60**

Function type

**MODAL**


Cancel

**G61**

#### Description

**G60** enables interpolation without stop on segments. The threshold of angle under which axis don't stop is set by machine parameter.

In the points where axis don't stop, it is generated an optimal trajectory minimizing error. **G60** avails a buffer of movements inside CN which can be set from a value up to **1024** on NG35 series. It allows to work in fluid way paths formed by micro-segments.



### 25.3.2 G61 – Enable interpolation with stop on segments

#### Syntax

**G61**

Function type

**MODAL**

Cancel

**G60**

#### Description

**G61** enables interpolation with stop on segment. In this interpolation mode axis are stop at the end of each segment.

### 25.3.3 G62 – Wait for stop axis

#### Syntax

**G62**

Function type

**MODAL**

#### Description

**G62** waits until axis are stopped and movement buffer is empty. It is useful when CN is in fast interpolation and we need to wait all movements are terminated. Obviously It is obsolete working in G61 (stop on segment).

**25.3.4 G63 – Interpolation outside work plane (PX\_MOVETO)****Syntax****G63****Function type****MODAL****Cancel****G64-G65****Description**

**G63** enables interpolation with axis outside work plane. In this way it's possible to work trajectories in the space (3D) without to consider the work plane.

The stop on segment is programmed by G62. G63 is particularly useful in 3D working where movement is formed by three or more axis. Generally in this interpolation mode are executed working from CAM at which is demanded the calculation of edge on segments inserting G62 in the fit point.

**25.3.5 G64 – Interpolation on work plane (default)****Syntax****G64****Function type****MODAL****Cancel****G63-G65****Description**

**G64** enables interpolation mode considering the work plane. This is the default mode selected on CN. **G64** calculates vectorial speed only with the axis of work plane (PX\_LINETO), moving consequently the other.

Isous verifies automatically if there are movement of the work plane axis, otherwise it works as G63.

Using this mode it can verify some inconvenient when the two axis of the work plane do very little movement. The following example explains that.

**G68 MUST BE ENABLED****Ex:****G64****G17****G1X0.001Y0.001Z10**

In the above example axis X and Y on work plane move very little in relation to axis Z causing an high speed on axis Z that can be bigger than its limit.

The solution to that is the following:

**G63****G17****G1X0.001Y0.001Z10****G64**

Enabling interpolation outside work plane, Isous calculates the vectorial speed with all axis instead only the two axis of work plane.

**25.3.6 G65 – Enable 3D interpolation PX\_MOVETO with calculated stop on edge by parameters****Syntax****G65****Function type****MODAL****Cancel****G63-G64****Description****G65** Enables 3D interpolation calculating stop on edge by CN parameters.**G63-G64 MUST NOT BE ENABLED****Ex:****G65****G1X100Y100Z10**

In the example PX\_MOVETO (interpolation outside work plane) is used and stop on edge is calculated automatically by CN.

**25.3.7 G75 – Enable G64 for movement inside the work plane , G65 for movement outside the work plane****Syntax****G75****Function type****MODAL****Cancel****G63-G64****Description**

**G75** Enable interpolation 2D **G64** when the movements are inside the work plane with **SGLP**, Enable interpolation 3D **G65** when the movements are outside the work plane with **SGL3D**.

**G63-G64 MUST NOT BE ENABLED**

### 25.3.8 G66 – AFC – Adaptive Feed Control

#### Syntax

G66 Xval Yvin Zval Aval

#### Function type


Disabled when PartProgram start

#### Parameters

**Xval** *0=disable AFC, 1=Enable AFC*  
 if greater than 1, is carried out a moving average on the value of F calculated and the number of samples indicated in xVal. This makes it more "soft" means the change of the F calculated.

**Yvin** *(optional) axis inertia*  
*Vin > 1 deceleration space increases*  
*If it isn't present Vin=1 is set (no inertia)*

**Zval** *(optional) Indicates the values of Delta F to below which are not considered.*  
 ex:  
 Val = 0.3, a delta F d 0.3 or less is not considered and therefore the F is left to the previously calculated.



**Aval** Minimum value below which is not diminished the F  
 Ex: if Val = 0.1 to 0.1 lower values of F are limited to 0.1

#### ATTENTION

To correct working of G66, also G69 (look ahead depth) must be set

#### Description

G66 enables the AFC filter to auto-calculate interpolation speed by path type. With SGLAFC\_n parameters, the AFC algorithm computes the optimal speed for each segment. The analysis of speed is carried out in the **look ahead** segments buffer (set by G69). Obviously more the buffer is deep, more the result is accurate. The AFC algorithm works only on **G1** segments and it makes sense only in paths formed by **MICRO-SEGMENTS**. It's basilar understand AFC can change the axis speed in each single segment and therefore the resulting speed can be inconstant along path. The SGLAFC\_ parameter of each single axis defines the instant speed gap it can bear without problems. If, in the analyzed segment, even a single axis exceeds its threshold, the speed is reduce to fit set parameters. In the presence of edges (defined by SGL3D\_n parameters) axis are decelerated to a stop.

AFC is very useful in works where it doesn't need a constant speed along path. In such a cases AFC allows to move at speed as high as the path makes it possible, slowing in critical points (curves).

**25.3.9 G66 X-100 – NEW AFC – Adaptive Feed Control****Syntax****G66 X-100 Yarc Zaccs A fmin B flevel C val U axisIndex V minLen W angDiff F numSeg S radiusMax****Function type**

Disabled when PartProgram start

**Parameters**

<b>X-100</b>	<i>NAFC - New AFC enabled 0 Disabled -101 Disabled in PREVIEW Use X-101 for enabled the NEW AFC but disabled in PREVIEW Some times the new AFC can slow the PREVIEW function</i>
<b>Ypeaks</b>	<i>(optional) Enabled only if C parameter has the bit 8 set to 1 (new algorithms) define the value for peaks feed reduction(see following) default=0</i>
<b>Zaccs</b>	<i>(optional) Inserts a SMOOTHING filter on ACC PEAKS Decimal Values from 0 to 1 (ex Z0.7) big values, means filter weak. Default value=0</i>
<b>A fmin</b>	<i>(optional) Minimum value below which is not diminished the F Ex: if Val = 0.1 to 0.1 lower values of F are limited to 0.1. Default value Disable</i>
<b>B FastMode</b>	<i>(optional) Fast Mode for Acc calculation FastMode=0 The Acceleration is controlled also on the segments of the FindArc function FastMode=1 The Acceleration is not controlled on the segments of the FindArc function Default FastMode=1</i>
<b>C val</b>	<i>(Optional) Special Functions see description. Default value=0</i>
<b>U AxisIndex</b>	<i>(Optional) If is used the tangential Axis (like to cutter) insert the Axis Index (0,1,2) that indicate the tangential Axis.</i>
<b>V minLen</b>	<i>(Optional) Indicates the minimum length (mm) for G1 element to be considered an ARC. G1 elements greater this value, are not considered as an ARC. Used only when the FindArc function is enabled parameter C bit 4=1. Default value=10 mm</i>
<b>W RadiusTol</b>	<i>(Optional) Indicates the tolerance of the Radius for FindArc function All the G1 segments which fall within the indicated tolerance are considered members of the same ARC. Higher values give less precise data. Default value 5 (5 % of tolerance)</i>
<b>F numSeg</b>	<i>(Optional) Indicates the minimum number of consecutive G1 elements that respect the parameters V and W to be considered an ARC. Used only when the FindArc function is enabled parameter C bit 4=1. Default value=3</i>
<b>S radiusMax</b>	<i>(Optional) Indicates the maximum radius calculated by FindArc function. Radius greater this value are not considered as an ARC. Used only when the FindArc function is enabled parameter C bit 4=1. Default value=100 mm</i>

**Description****G66 X-100** enables the new algorithm **NAFC** for Feed calculate on the Gcode files.This new algorithm is better than old **G66** and uses the following parameters:**ACC\_MAX\_X,Y,Z** etc.



The **ACC\_MAX\_** parameter must be set to a value greater or equal to **ACC\_LAV** parameter. It means the max acceleration that the Axis can support, over it , the FEED is reduced.

**G66 X-100** uses a look ahead depth equal to CNC, therefore is not necessary set the **G69** function.

Usually is not necessary insert other optional parameters for the **G66 X-100**, only the parameters **ACC\_MAX\_** are setted, but is possible improve the algorithm by the **Z** and **B** parameters.

**Z** decimal values from **0** (disabled) to **5** (minimum effect) uses a smoothing on ACC PEAKS Reference value could be **Z0.5**. With this parameter, are avoided big feed reduction.

**B** integer values from **0** (disabled) to **5** (maximum effect) improve the feed calculation.

If is necessary excluded the **G2 G3** from the algorithm, set the **Y** to **1**.

In this case,the **G2-G3** feed reduction is performed by **ACC\_RAGGIO\_MAX** parameter.

Set **ACC\_RAGGIO\_MAX** to a value **90** if the **G2-G3** feed reduction is included in the algorithm.

If is used the tangential Axis (Cut Plotter ) insert in the **U** parameter, the index of axis (0-1-2 etc.)

The tangential axis speed control is made when the system must interpolate on the work-plane, with the optional third axis moved in position "in time". For example with the "transported axis" (**G68**) or on the arcs (**G2-G3**) where the speed is always and only calculated on the work-plane axes.

In these cases, on every segment, the actual speed of the third axis will be compared with the maximum (**VMAX\_**) inserted in the parameter list. If it'll be overcome, a new interpolation speed will be calculated, to make the tangential axis to move at his maximum speed. In this way, the segment will be executed at the maximum possible speed, but always supported by all axes.

Setting the bit 5 to 1, this control will be disabled.

#### FindArc

If the Bit 4 of parameter C is set to 1 (decimal value=16), is enabled the algorithm **FindArc**. It search ARCS in the consecutive G1 elements by parameters **V W F S**.

If an ARC is found, the RADIUS is calculated and the FEED is reduced by **ACC\_RAGGIO\_MAX** parameter, as G2-G3 element.




This function can operate with **NAFC** algorithm (feed reduced by **ACC\_MAX\_**) but this has the priority.

**C Parameter Special Functions Bit Mapped**

**Bit 0=1** RLS Removes the Short Segments G1 tath can't be worked at current FEED

**Bit 1=1** JOING1 Join the G1 belonging the same line G1



**Bit 2=1** Excludes the FEED reduction  
Only RLS and JOING1


**Bit 3=1** Excludes NAFC. Feed calculation by ACC\_MAX\_

**Bit 4=1** Enables FINDARC

**Bit 5=1** Excludes tangential axis from FEED control

**Bit 6=1** Use First Point, Middle Point and Last Point for FindArc (0,n/2,n)

**Bit 6=0** Use Last Three Points for FindArc (n-2,n-2,n)



**Bit 7=1** G2-G3 Outside ACC\_RAGGIO\_MAX are taken for FindArc as G1

**Bit 8=1** Enable the new algorithms for G66 X-100 (recommended) some parameters have the following meaning


**ZFdiv** (optional) Divisor factor for FEED reduction during acceleration peaks. The FEED calculate by algorithm is further divided by this value.  
Default 0 (disabled)

**FPamp** (optional) Value of FEED amplitude for define a peak (see following)

**BPtime** (optional) Value of FEED time for define a peak (see following)

**Feed peaks reduction**

The algorithms for automatic FEED reduction, can produce some unnecessary FEED PEAKS i.e. movements at max feed for a short time.



These peaks can be identified and reduced for a homogeneous speed.


**B** parameter enables the peaks reduction feed. It defines the TIME.

**B=1** all peaks are reduced. **B=4** only the peaks that have the time  $\leq 4$  unity are reduced (default 0 disabled)

**F** parameter defines the peaks amplitude (mt/min). Practicamente vengono considerati picchi solamente se hanno una

**F=0** all peaks are reduced. **F=8.1** only the peaks that have the feed  $\geq 8.1$  mt/min unity are reduced (default 0 all peaks)

**Y** parameter defines the divisor factor for feed reduction in a peak. **Y=2** the feed is decreased of 50% (default 2 50%)



**25.3.10 G67 – Px\_Moveto for movement outside plane and Px\_Lineto for inside one****Syntax****G67**

Function type

**MODAL**

Cancel

**G68****Description**

**G67** works with a combination of PX\_MOVETO for movement outside work plane (3D) and PX\_LINETO for movements inside work plane. Furthermore when PX\_MOVETO is used axis are stop at end of segment.

**G63-G65 MUST NOT BE ENABLED****G68****25.3.11 G68 – Always using of PX\_LINETO in G1 “TRANSPORTED AXIS” (with possibility to combine with PX\_MOVETO)****Syntax****G68 Xval YTangAxis**

Function type

**MODAL**

Cancel

**G67**

Parameter

**Xval***Optional parameter (it must be enabled G69)**val>0 limit speed of eventually tangential axis**If tangential axis exceed this speed transported axis is disabled and PX\_MOVETO is invoked**Val=0 disable**Val=-1 axis is never transported, but it is only calculated the edge threshold on work plane (as G65 but with SGLP)***YTangAxis***Optional Index of axis to be set as TANGENTIAL***Description**

**G68** invokes always PX\_LINETO for movement both inside and outside work plane, allowing to manage interpolation for particular machine types (for ex. cutting with tangent blade).

**AXIS OUTSIDE WORK PLANE BECAME “TRANSPORTED”**

These axis (outside plane), moving to final position with determination of vectorial speed by the only axis on work plane, don't affect the resulting speed of tool.

An example of use with this interpolation mode can be the CUTTING PLOTTER one, where the blade must be tangent to path. Resulting working speed is really the programmed one by F, tangential axis instead will be moved to its final position in the same time of the other.

X parameter allows to obtain mixed interpolation between “TRANSPORTED AXIS” and normal axis.

Using this interpolation mode there can come out a problem: the “TRANSPORTED AXIS” can reach a speed over its limit. Setting this limit with X parameter Isous identifies such points and invoke PX\_MOVETO reducing resulting speed.

**G63-G65 MUST NOT BE ENABLED**

**25.3.12 G69 – LHK – Buffer look ahead depth****Syntax****G69 Xval AXISTANG****Function type**

Disabled when PartProgram start

**Parameters**

**val**                      *Number of elements in the buffer*  
                               *If VAL<20 AFC is disabled*  
                               *VAL is limited to number of blocks of PartProgram*

**ASSIXTANG**    *Optional axis to be set as TANGENTIAL (Ex. Z A etc.)*  
                               *If it isn't present no tangential axis is set*

**Description**

**G69** defines and enables the deep of **look ahead** segments buffer. It allows proper operation in functions which use it (G66 – G72 – G73 – G74). More the buffer is deep, more the result is accurate.

Depth is however limited to a value <20 (LHK disabled) to value major of part program length. A typical value can be 200.

This function also defines an optional tangential axis (for ex. cutting blade). This is necessary because functions related to **G69** (G66 – G72 – G73 – G74) can change the original path, adding or removing segments necessitating to recalculate the angle of tangent axis.

**Ex:****G69 X200 A**

In the above example buffer depth is set at 200 elements and axis A is set as TANGENTIAL.

## 25.4 ISOUS FILTERS

Isous is equipped with several filtering algorithms to modify original path formed by PartProgram. Filter can be useful especially when PartPrograms comes from CAM (for ex. scanner acquisition) having a "NOISE" path. Filters acts only in G1 blocks and however it must be enabled G69 function (LHK depth). They can be **2D** features (work plane axis) or **3D** features (work plane axis and depth axis). Filters however **DOESN'T ACT ON MORE THAN THREE AXIS**.

### WARNING

*The depth axis is automatically taken from axis XYZ which remains outside work plane.*

*Work plane X,Y    Depth axis Z*

*Work plane X,Z    Depth axis Y*

*Work plane Y,Z    Depth axis X*

*When filtering is active current working lines in PART PROGRAM can be shifted to original ones. It can happen some of these are removed and other are divided in more segments.*

### SEQUENCE OF FILTER

All available filters can be combined together, it can be invoked in following sequence:

NOISE	G73	(if enabled)
NURBS G72	(if enabled)	
FINE NOISE	G73	(if enabled)
RLS	G74	(if enabled)
SMOOTHING	G106	(if enabled)
AFC	G66	(if enabled)

**25.4.1 G72 – N.U.R.B.S (Non Uniform Rational Bspline) (2D 3D)****Syntax****G72 Xval Yminlen Zorder Alenseg****Function type**

Disabled when PartProgram start

**Parameters**

<b>val</b>	<b>0 – disable NURBS filter 1 – enable NURBS filter</b>
<b>minlen</b>	<b>Minimum G1 segment length to be inserted in NURBS filter. Filter acts in a buffer which has a continuous series of segments with a length less than MINLEN parameter. When a segment greater than this length is met, the NURBS buffer is computer making an interpolation on points. The typical default value is 0.2 mm <u>Optional parameter, if it isn't present last value or default value is taken.</u></b>
<b>order</b>	<b>Order of NURBS curve (value from 1 to 7) It defines the accuracy of resulting. Lower value corresponds to a best accuracy. order=1 original point are carried back. Typical default value is 3. <u>Optional parameter, if it isn't present last value or default value is taken.</u></b>
<b>lenseg</b>	<b>It defines the minimum segments length at output curve resulting to points interpolation. At lower value corresponds to a less segments length and to a greater number of resulting segments (curve more accurate) Typical default value is 0.2mm <u>Optional parameter, if it isn't present last value or default value is taken.</u></b>

**Description**

NURBS are a type of curve suitable to solve B-Spline problem, mainly the impossibility to draw simple shape as circle. By this evolution it's possible to generate conic curves, and to represent very complex curves with less number of control points.

N.U.R.B.S. (Not Uniform Rational B-Spline) are rational curves defined by control points and its relative weights.

Increasing the weights value of a point the curve approaches to the point. On the contrary the point will cause a less variation on the curve.

**ISOUS** uses this interpolation mode to **"SOFTEN"** a series of segments.


Some example are showed below to better explain NURBS filter.

**NURBS filter acts also on 3D paths**

**NURBS FILTER IS THE SECOND TO BE INVOKED ON ORIGINAL PATH**


**ORIGINAL PATH**

```
G0 X107.16 Y130.27
G1 X100.59 Y131.18
G1 X100.14 Y129.37
G1 X96.74 Y130.73
G1 X95.38 Y129.14
G1 X92.66 Y130.5
G1 X89.95 Y128.46
G1 X86.55 Y131.41
G1 X82.24 Y129.14
G1 X77.71 Y132.31
G1 X72.95 Y128.91
G1 X67.97 Y132.31
G1 X62.98 Y129.37
G1 X57.55 Y133.45
G1 X52.34 Y129.59
```




**PATH FILTERED with NURBS MiLen=7mm Order=3 LenSeg=0.2mm**

```
G69X200 // ENABLE LHK
// ENABLE NURBS LEN 7 MM ORDER 3 SEGMENT 0.2
G72X1Y7
G0 X107.16 Y130.27
G1 X100.59 Y131.18
G1 X100.14 Y129.37
G1 X96.74 Y130.73
G1 X95.38 Y129.14
G1 X92.66 Y130.5
G1 X89.95 Y128.46
G1 X86.55 Y131.41
G1 X82.24 Y129.14
G1 X77.71 Y132.31
G1 X72.95 Y128.91
G1 X67.97 Y132.31
G1 X62.98 Y129.37
G1 X57.55 Y133.45
G1 X52.34 Y129.59
```



**PATH FILTERED with NURBS MiLen=5mm Order=3 LenSeg=0.2mm**

```
G69X200 // ENABLE LHK
// ENABLE NURBS LEN 5 MM ORDER 3 SEGMENT 0.2
G72X1Y5
G0 X107.16 Y130.27
G1 X100.59 Y131.18
G1 X100.14 Y129.37
G1 X96.74 Y130.73
G1 X95.38 Y129.14
G1 X92.66 Y130.5
G1 X89.95 Y128.46
G1 X86.55 Y131.41
G1 X82.24 Y129.14
G1 X77.71 Y132.31
G1 X72.95 Y128.91
G1 X67.97 Y132.31
G1 X62.98 Y129.37
G1 X57.55 Y133.45
G1 X52.34 Y129.59
```



**SEGMENT LENGTH >= 5 mm (not filtered)**




**PATH FILTERED with NURBS MiLen=7mm Order=5 LenSeg=0.2mm**

With higher order NURBS path deviates most from the original path

```
G69X200 // ENABLE LHK
```

```
G72X1Y7Z5
G0 X107.16 Y130.27
G1 X100.59 Y131.18
G1 X100.14 Y129.37
G1 X96.74 Y130.73
G1 X95.38 Y129.14
G1 X92.66 Y130.5
G1 X89.95 Y128.46
G1 X86.55 Y131.41
G1 X82.24 Y129.14
G1 X77.71 Y132.31
G1 X72.95 Y128.91
G1 X67.97 Y132.31
G1 X62.98 Y129.37
G1 X57.55 Y133.45
G1 X52.34 Y129.59
```




**PATH FILTERED with NURBS MiLen=7mm Order=2 LenSeg=0.2mm**

With Order=2 changes are almost null even in marked circles original path is slightly modified

```
G69X200 // ENABLE LHK
```

```
G72X1Y7Z1
G0 X107.16 Y130.27
G1 X100.59 Y131.18
G1 X100.14 Y129.37
G1 X96.74 Y130.73
G1 X95.38 Y129.14
G1 X92.66 Y130.5
G1 X89.95 Y128.46
G1 X86.55 Y131.41
G1 X82.24 Y129.14
G1 X77.71 Y132.31
G1 X72.95 Y128.91
G1 X67.97 Y132.31
G1 X62.98 Y129.37
G1 X57.55 Y133.45
G1 X52.34 Y129.59
```




**PATH FILTERED with NURBS MiLen=7mm Order=1 LenSeg=0.2mm**

Original path not filtered

```
G69X200 // ENABLE LHK
```

```
G72X1Y7Z1
G0 X107.16 Y130.27
G1 X100.59 Y131.18
G1 X100.14 Y129.37
G1 X96.74 Y130.73
G1 X95.38 Y129.14
G1 X92.66 Y130.5
G1 X89.95 Y128.46
G1 X86.55 Y131.41
G1 X82.24 Y129.14
G1 X77.71 Y132.31
G1 X72.95 Y128.91
G1 X67.97 Y132.31
G1 X62.98 Y129.37
G1 X57.55 Y133.45
G1 X52.34 Y129.59
```



### 25.4.2 G73 – NOISE (2D-3D)

#### Syntax

**G73 Xval Yminang Zminlen Aonlyvar**

#### Function type

Disabled when PartProgram start

#### Parameters

**val**                    *0 – disable NOISE, disable FINE NOISE*  
                           *1 – enable NOISE, disable FINE NOISE*  
                           *2 – disable NOISE, enable FINE NOISE*  
                           *3 – enable NOISE, enable FINE NOISE*

**minang** *Minimum edge angle to be consider noise*

*Typical default value is 25 degree*

*Optional parameter, if it isn't present last value or default value is taken.*

**minlen**

*Minimum G1 segment length to be inserted in NOISE filter.*

*Filter acts in a buffer which has a continuous series of segments with a length less than MINLEN parameter. When a segment greater than this length is met, the NOISE buffer is computer making an interpolation on points.*

*Typical default value is 0.4 mm*


*Optional parameter, if it isn't present last value or default value is taken.*

**onlyvar** *0 – remove all edge matching the parameters*

*1 – remove only cusps matching the parameters (sudden changes of angle)*

*Typical default value is 0*

*Optional parameter, if it isn't present last value or default value is taken.*



#### Description

**NOISE** filter helps to remove **G1** segments forming small edge (or cusps) which are defined as noise.

This is very useful in combination with NURBS filters increasing its performance.


Some example are showed below to better explain NOISE filter.

**NOISE filter acts in 2D or 3D paths**

**NOISE FILTER IS THE FIRST FILTER IT IS INVOKED IN THE ORIGINAL PATH**

**ORIGINAL PATH**


```
G0 X107.16 Y130.27
G1 X100.59 Y131.18
G1 X100.14 Y129.37
G1 X96.74 Y130.73
G1 X95.38 Y129.14
G1 X92.66 Y130.5
G1 X89.95 Y128.46
G1 X86.55 Y131.41
G1 X82.24 Y129.14
G1 X77.71 Y132.31
G1 X72.95 Y128.91
G1 X67.97 Y132.31
G1 X62.98 Y129.37
G1 X57.55 Y133.45
G1 X52.34 Y129.59
```



**PATH FILTERED with MinAng=45 MinLen=5**

```
G69X200 // ABILITA LHK
G73X1Y45Z5
```


```
G0 X107.16 Y130.27
G1 X100.59 Y131.18
G1 X100.14 Y129.37
G1 X96.74 Y130.73
G1 X95.38 Y129.14
G1 X92.66 Y130.5
G1 X89.95 Y128.46
G1 X86.55 Y131.41
G1 X82.24 Y129.14
G1 X77.71 Y132.31
G1 X72.95 Y128.91
G1 X67.97 Y132.31
G1 X62.98 Y129.37
G1 X57.55 Y133.45
G1 X52.34 Y129.59
```



**PATH FILTERED with MinAng=45 MinLen=3**

```
G69X200 // ABILITA LHK
G73X1Y45Z3
```

```
G0 X107.16 Y130.27
G1 X100.59 Y131.18
G1 X100.14 Y129.37
G1 X96.74 Y130.73
G1 X95.38 Y129.14
G1 X92.66 Y130.5
G1 X89.95 Y128.46
G1 X86.55 Y131.41
G1 X82.24 Y129.14
G1 X77.71 Y132.31
G1 X72.95 Y128.91
G1 X67.97 Y132.31
G1 X62.98 Y129.37
G1 X57.55 Y133.45
G1 X52.34 Y129.59
```




**25.4.3 G74 – RLS Remove Len Segment (2D 3D)****Syntax****G74 Xval Ylenmin****Function type**

Disabled when PartProgram start

**Parameters**

**val**                    *0 – disable RLS filter*  
                           *1 – enable RLS filter*

**lenmin**                *Minimum G1 segment length allowed.*  
                           *Segments with length less than this value are removed.*  
                           *Typical default value is 0.5 mm*  
                           *With lenmin=0 the value is automatically calculated by programmed speed (F).*  
                           *Optional parameter, if it isn't present last value or default value is taken.*

**Description**

**RLS** filter allows to remove “**SHORT**” **G1** segments which couldn't be worked at requested speed (travel time less than CN sample). Setting a **ZERO** value, Isous calculates automatically the length optimizing it to current speed. The result is an exclusion of “void segment”, freeing the movement BUFFER and allowing greater work speed.

**ATTENTION**

When RLS is enable override potentiometer is disabled.

**RLS filter atcs on both 2D and 3D paths**

**RLS FILTER IS 4th TO BE INVOKED ON ORIGINAL PATH**

**25.4.4 G106 – Smoothing (2D 3D)****Syntax****G106.ax Xval ALevel Bminlen****Function type**

Disabled when PartProgram start

**Parameters**

<b>.ax</b>	<i>Axis index where is set the filter (from 0 to n) normally 0 is X axis ex: G106.0</i>
<b>val</b>	<i>0 – Filter Smoothing <b>disabled</b> 1 - Filter Smoothing <b>Enabled</b></i>
<b>Level</b>	<i>Smoothing level (from 0 to 1) Values low have more effect to smoothing ex. A0.3 Typical value is 0.7 <u>Optional parameter, if it isn't present last value or default value is taken.</u></i>
<b>minlen</b>	<i>Minimum G1 segment length allowed. Segment more large this value, not are inserted in the filter Typical default value is disable The length is calculated by axes vector (for all axes). Is necessary set only one time If the parameter is not present, the last length value is used</i>

**Description**

The **SMOOTHING** filter, is used to smoothing G1 segment, it allows to increase the execution speed, but decreased the precision respect to original path.


The **SMOOTHING** is activated for any axes with separate parameters.

**THE SMOOTHING FILTER IS 5th TO BE INVOKED ON ORIGINAL PATH**

**ORIGINAL PATH**

```


G60
G0 Z3
G0X30.4845 Y258.703
F15
G01 Z-1
X36.1945 Y260.416 F15
X40.7625 Y257.8465
X44.7595 Y260.1305
X52.7535 Y260.416
X63.6025 Y256.99
X67.0285 Y250.138
X63.0315 Y247.854
X60.1765 Y244.428
X64.7445 Y239.289
X61.033 Y239.289
X62.746 Y234.721
X65.601 Y235.863
X70.4545 Y235.5775
X75.0225 Y238.147
X84.7295 Y237.8615
X87.299 Y239.86
X95.5785 Y239.86
X99.0045 Y241.002
X101.2885 Y236.1485
X107.284 Y237.576
X116.1345 Y231.866
X145.2555 Y233.008
X158.103 Y230.4385
X170.9505 Y234.15
X178.088 Y232.1515
X194.9325 Y229.2965
X200.357 Y232.437
X205.7815 Y219.304
X196.0745 Y216.1635
X193.7905 Y207.5985
X196.6455 Y199.89
X193.7905 Y198.748
X196.36 Y190.4685
X194.076 Y186.4715
X194.9325 Y182.4745
X199.5005 Y179.334
X193.7905 Y177.9065
X200.0715 Y175.0515
X193.7905 Y172.7675
X198.644 Y170.769
X191.5065 Y167.343
X196.6455 Y163.346
X191.221 Y161.062
X195.789 Y158.207
X188.0805 Y156.494
X191.792 Y153.068
X188.0805 Y150.784
X191.5065 Y148.2145
X179.801 Y138.793
X160.387 Y147.0725
G0 X160.387 Y147.0725
    
```



**PATH – Smoothing on X,Y level A0.2 Min Len Segment 8 mm B8**

```

G60
G0 Z3
G69X200
G106.0 A0.2 B8
G106.1
G0X30.4845 Y258.703
F15
G01 Z-1
X36.1945 Y260.416 F15
X40.7625 Y257.8465
X44.7595 Y260.1305
X52.7535 Y260.416
X63.6025 Y256.99
X67.0285 Y250.138
X63.0315 Y247.854
X60.1765 Y244.428
X64.7445 Y239.289
X61.033 Y239.289
X62.746 Y234.721
X65.601 Y235.863
X70.4545 Y235.5775
X75.0225 Y238.147
X84.7295 Y237.8615
X87.299 Y239.86
X95.5785 Y239.86
X99.0045 Y241.002
X101.2885 Y236.1485
X107.284 Y237.576
X116.1345 Y231.866
X145.2555 Y233.008
X158.103 Y230.4385
X170.9505 Y234.15
X178.088 Y232.1515
X194.9325 Y229.2965
X200.357 Y232.437
X205.7815 Y219.304
X196.0745 Y216.1635
X193.7905 Y207.5985
X196.6455 Y199.89
X193.7905 Y198.748
X196.36 Y190.4685
X194.076 Y186.4715
X194.9325 Y182.4745
X199.5005 Y179.334
X193.7905 Y177.9065
X200.0715 Y175.0515
X193.7905 Y172.7675
X198.644 Y170.769
X191.5065 Y167.343
X196.6455 Y163.346
X191.221 Y161.062
X195.789 Y158.207
X188.0805 Y156.494
X191.792 Y153.068
X188.0805 Y150.784
X191.5065 Y148.2145
X179.801 Y138.793
X160.387 Y147.0725
G0 X160.387 Y147.0725
    
```



## 25.5 Interrupt MACRO

Allows to use 3 types of MACRO that are execute in **INTERRUPT MODE**.

These MACRO have a fixed NUMBER and must be created with this number

<i>Time</i>	<i>M50000</i>
<i>On Digital Input</i>	<i>M50001</i>
<i>On Digital Output</i>	<i>M50002</i>
<i>Each Axes Movement</i>	<i>M50003 e M50004</i>

The management of these macro is performed by **G107** function

### 25.5.1 G107 – Management Interrupt Macro

#### Syntax

#### G107 X0

Disable All Interrupt Macro – Excluding M50003 and M50004

#### G107 X1

Enable All Interrupt Macro – Excluding M50003 and M50004

#### G107 X2

Suspend All Interrupt Macro – Excluding M50003 and M50004

#### G107 X3

Resume All Interrupt Macro – Excluding M50003 and M50004  
(If they are disabled remain disabled)

#### G107.0 Xtime

Macro M50000 activated at Time

Time in millisecond (X-1 Disabled)

When the MACRO is in execution, it is automatically disabled, and will be enabled when the execution is finished

Example:

#### 1) Generate MACRO 50000

```
G62                // WAIT AXES STOP
$SAVEX=$[Q0]       // SAVE X
$SAVEY=$[Q1]       // SAVE Y
$SAVEZ=$[Q2]       // SAVE Z
G0X0Y0Z0           // MOVE AXES
G4F1               // PAUSE
G0X[$SAVEX]Y[$SAVEY] // RESUME AXES VALUES XY
G0Z[$SAVEZ]        // RESUME AXIS VALUE Z
G4F1               // PAUSE
```

#### 2) Activation in the Gcode each 5 Seconds

G107.0 X5000

The macro M50000 will be executed each 5 seconds



**G107.1 XDI**

Macro M50001 Activated when the DIGITAL INPUT IS ON

DI Indicate the DIGITAL INPUT NUMBER from 0 to 31 (-1 Disabled)

When the MACRO is in execution, it is automatically disabled, and will be enabled when the execution is finished

Example:

1) Generate MACRO 50001

```
G62                // WAIT AXES STOP
$SAVEX=${Q0}       // SAVE X
$SAVEY=${Q1}       // SAVE Y
$SAVEZ=${Q2}       // SAVE Z
G0X0Y0Z0          // MOVE AXES
G4F1              // PAUSE
G0X[$SAVEX]Y[$SAVEY] // RESUME AXES VALUES XY
G0Z[$SAVEZ]       // RESUME AXIS VALUE Z
G4F1              // PAUSE
```

2) Activation in the Gcode when the FIRST DIGITAL INPUT IS ON

G107.1 X0

The M50001 will be executed when the DIGITAL INPUT will be from OFF to ON

**G107.2 XDO**

Macro M50002 Activated when the DIGITAL OUTPUT IS ON

DO Indicate the DIGITAL OUTPUT NUMBER from 0 to 31 (-1 Disabled)

When the MACRO is in execution, it is automatically disabled, and will be enabled when the execution is finished

Example:

1) Generate MACRO 50002

```
G62                // WAIT AXES STOP
$SAVEX=${Q0}       // SAVE X
$SAVEY=${Q1}       // SAVE Y
$SAVEZ=${Q2}       // SAVE Z
G0X0Y0Z0          // MOVE AXES
G4F1              // PAUSE
G0X[$SAVEX]Y[$SAVEY] // RESUME AXES VALUES XY
G0Z[$SAVEZ]       // RESUME AXIS VALUE Z
G4F1              // PAUSE
```

2) Activation in the Gcode when the FIRST DIGITAL OUPUT IS ON

G107.2 X0

The M50002 will be executed when the DIGITAL OUPUT will be from OFF to ON

**G107.3 Xp1 Yp2 Zp3 Ap4 Bp5 Cp6****G107.4 Xp1 Yp2 Zp3 Ap4 Bp5 Cp6**

Macro M50003 and M50004 Activated each Axes movement

If the Gcode line, contains the Axes movement, the M50003 or M50004, will called

Parameter:

P1	0	Disable Macro M50003 or M50004
	1	Enable Macro M50003 or M50004
P2..P6		User Parameter can be used in the M50003 and M50004 code
		These Parameters are passed by Address
		P2 Address 20000
		P3 Address 20001
		P4 Address 20002
		P5 Address 20003
		P6 Address 20004

Example:

1) Generate MACRO 50003

```

$FEED1=${[:20000]           // FEED1 ON P2 Y
$FEED2=${[:20001]           // FEED2 ON P3 Z
F[$FEED1]
G1X0Y0Z0                     // MOVE AXES WITH FEED1 (Y)
G4F1                         // PAUSE
F[$FEED2]
G1X100Y100Z100             // MOVE AXES WITH FEED2 (Z)
G4F1                         // PAUSE

```

1) Activation in the Gcode

```

G0X0Y0Z0
G107.3 X1 Y10.2 Z5.3 // ENABLE M50003 WITH FEED1=10.2 AND FEED2=5.3
F2
G1X20Y20Z20 // TO END THIS LINE THE M50003 IS CALLED
G1X30Y30Z30 // TO END THIS LINE THE M50003 IS CALLED
G1X40Y40Z40 // TO END THIS LINE THE M50003 IS CALLED
G107.3 X0 // DISABLE M50003

```

The FEED setted in the Gcode, are saved first the M50003 or M50004 execution, and restored to end Macro

## 25.6 EMERGENCY MACRO M60000 in STOP Mode

The **EMERGENCY MACRO M60000** is activated when the **CN** finds an **EMEGENCY ALARM** and it is in **STOP** mode. When the CN is in **RUN** mode will be activated the **MACRO ERROR** configured. The **EMERGENCY MACRO** has a fixed code **M60000**.

Therefore is necessary generate a macro **M60000** by PluGIn **MHM** and it will be immediately ready. Generally in this macro is insert only the code for Digital or Analog outputs management, because the Axes movement will be stooped by CN when the Emergency will be found.

For disactivate the EMERGENCY MACRO M60000 is necessary remove from the folder **DATA\_M** the file **M60000.bin**. The folder **DATA\_M** is in the IsoUs folder installation.

## 25.7 G108 Management Special Axes

This function allows of management the Special Axes. This enable special functions on the axis different from normal use.

### 25.7.1 G108.0 G108.1 G108.2 G108.3 - Master Slaves Axes

The function G108.0 .1 .2 .3 allows to enable the MASTER-SLAVE.

In other words, allows to connect one or more axes to single master. So, when the master it is moved, the slaves axes are moved in the same mode of master axes

Is possible management up to 4 Groups of Master Slaves respectively with G108.0 G108.1 G108.2 and G108.3

The max number of slaves connected to master, is 8.

#### Syntax

#### G108.x 0

Remove all slaves of the group

#### G108.x 1

Suspend all slaves of the group

#### G108.x 2

Resume all slaves of the group previously programmed

#### G108.x M,S1,S2,S3..(-)S4 ecc.

Coonects the Slaves

M = Axis Master (is always the first programmed with G108.x)

S1 = Slave 1

S2 = Slave 2

Etc.

The sign "-" before of slave, inverts the slave direction, respect to master

#### Example:

G108.0 X,A,-C // X Master A Slave C slave with invert direction

G108.1 Y,Z,B,U // Y Master Z,B,U Slaves

.

.

G108.0 0 // Remove first Group of slaves

**25.7.2 G108.4 G108.5 G108.6 SPEED MODE AXIS**

The **G108.4** function, allows to connect one Axis from Interpolator to **SPEED MODE**, therefore the axis is no longer controlled by a target value, but in velocity mode. The **SPEED** can be set by the Function **S** if the channel is set in correct mode (see [16.8](#))

The function **G108.5** retrieve the Axis from **SPEED MODE** to **INTERPOLATOR MODE**

The function **G108.6** is like to **G108.5** but the Axis value is RESET to ZERO.

This allows to avoid the AXIS LIMITS ERROR

The Axis status in Speed mode can be read by special variable [\\$\[X16\]](#)

**Syntax****G108.4 X,Y,Z,A,B,C,U,V,W**

Connects the Axis (one Only) From Interpolator to Speed mode.

**G108.5 X,Y,Z,A,B,C,U,V,W**

Retrieve the Axis from Speed Mode To Interpolator mode.

**G108.6 X,Y,Z,A,B,C,U,V,W**

Retrieve the Axis from Speed Mode To Interpolator mode. VALUE IS RESET TO ZERO

**25.7.3 G108.7 G108.8 G108.9 Physical exchange Axes**

The **G108.7** allows to exchange a pair of Axes in the **CNC** level

Is possible to exchange one or more pair of Axes

**G108.8** Restore the pair of Axes previously exchanged

**G108.9** Restore **ALL** pair of Axes previously exchanged

**Syntax****G108.7 XA**

Exchange X with A

**G108.8 XA**

Restore the pair XA in the original mode

**G108.9**


Restore **ALL** pair previously exchanged

### 25.7.4 G108.10 G108.11 eGear Axes Management

**G108.10 .11** function, allow to management the Electronic Gear Axes.

By this function, is possible to **LINK** an **INTERPOLATED AXIS X,Y,Z** etc. to an external **ASYNCHRONOUS AXIS** .

For example, a conveyor belt that move the object to work, that can be **FOLLOW** by an interpolated **AXIS** for make the **JOB**.



In the above example, the MASTER AXIS is move in a direction transporting the material to be processed.

The **G108.10** function, allow the **LINK** the **X AXIS** (slave) to **MASTER AXIS** and the **MASTER FEED** will be add to **X FEED AXIS**.

The **G108.10** work with parameters [EGEAR\\_KEM](#), [EGEAR\\_KED](#), [EGEAR\\_ACC](#)

#### Syntax

#### **G108.10 X,Y,Z,A,B,C,U,V,W**

**LINK** the axis (only one) to **MASTER** defined in the VTB application.

#### **G108.11 X,Y,Z,A,B,C,U,V,W**

**UNLINK** the axis to **MASTER** defined in the VTB application.

### 25.7.5 G108.12 G108.13 - Peripheral speed management

G108.12/13 instructions allow to harmonize the peripheral speed of a rotary axis, against the speed of other axes. This algorithm calc the “shadow” radius, the distance between the work point and the centre of rotary axis and maintain constant the speed of work point, even with a varying radius.

Result will be a movement with a speed different from the given one, but with a constant speed of work point.

Can be set up two rotary axes, with the related rotation axis.

#### Syntax

#### G108.12 Y,B

set axis to be used

#### G108.13 1

enable management

#### G108.13 0

disable management


In the example, B axis is set as rotary axis, with Y as rotation axis.

In this case, the “shadow” radius is given by the distance between the work point and the centre of rotation axis defined by [CENTRE\\_X\\_R1](#)

, [Errore. L'origine riferimento non è stata trovata.](#) parameters.

More information on centre position definition, check the related section in this manual (see [Cap 25.21](#)).

The example declaration, set the rotary axis as explained in picture below.



## 25.8 VIRTUAL AXIS

Virtual axis are commands inserted in the interpolation buffer but they don't refer to a real axis. In detail they are synchronous command which can enable events in precise point of path. This commands must be used when CN works with fast interpolation. Furthermore command function must be implemented in CN.

### 25.8.1 G100 – Comando sincrono per asse virtuale

#### Syntax

**G100 Xcmd**

#### Function type

*Direct*

#### Parameter

*Cmd      Command code to send to CN*

#### Description

**G100** sends a command to CN synchronously with path. Such a command must be implemented in CN by VTB environment to work properly (refer to CN documentation).

Example to manage a digital output in fast interpolation.

PartProgram

**G60      //ENABLE FAST INTERPOLATION**

**G1X100Y100**

**X120Y110**

**X130**

**G100 X1// SET OUTPUT**

**X200Y160**

**X210Y180**

**G100 X0// CLEAR OUTPUT**

**X300Y200**

**X310Y220**

Two function must be implemented in CN for:

G100 X0 Clear output

G100 X1 Set output

This is the VTB code to be written in TaskPlc using output n.0

' **G100 command for set/clear output**

**ISOV1.out0=INTERPOLA1.cmd**



## 25.9 OTHER GENERIC G FUNCTIONS

### 25.9.1 G4 – Timed pause

#### Syntax

**G4** Fvalue

Function type

*Direct*

Parameter

*Value Time seconds (resolution up to tenth of second)*

#### Description

G4 allows to pause PartProgram for the time set by F parameter.

Ex:

**G4**F2.5 // PAUSE OF 2.5 SEC

### 25.9.2 G4.1 – Time Add on Calc Time

#### Syntax

**G4.1** Fvalue

Function type

*Direct*

Parameter

*Value Time in sec to add*

#### Description

G4.1 adds an extra time to Calc Time Function. This allows to include extra PLC time (wait input etc.)

Normally it is inserted in the M functions M3,M4,M5 M6 etc.

This function is activated only during Calc Time function, and it is excluded in a normal RUN.

### 25.9.3 G10 – Enable external OVERRIDE potentiometer

#### Syntax

**G10**

Function type

*Modal - default*

Cancel

**G11**

#### Description

G10 enables speed control by external potentiometer.

### 25.9.4 G11 – Disable external OVERRIDE potentiometer

#### Syntax

**G11**

Function type

*Modal*

Cancel

**G10**

#### Description

G11 disables speed control by external potentiometer.

### 25.9.5 G101 – Axis Stop command

**Syntax****G101****Function type***Direct***Description**

G101 commands a stop to axis in current position. The example below explains this function.

**Ex:**

In this example axis X move to position 100. During positioning a digital input is tested (Input 0), if it activates the movements is stopped. If axis terminates its movement PartProgram is ended with an error.

```

G60
F1
G1X100
@INITLOOP
IF $[Q0]=100 // IF X REACHES 100
    GOTO ERR // ERROR
END_IF
IF $[I0]=1 // WAIT FOR INPUT
    G101 // IF ACTIVE, AXIS STOP AND EXIT
    GOTO EXIT
ELSE
    GOTO INITLOOP // CONTINUE LOOP
END_IF
@EXIT
.
.

@ERR
.
.

```

### 25.9.6 G80 – Forced pause by code

(Shifted on G1080 if USE\_G80\_CYCLES=TRUE)

**Syntax****G80 Xcode****Function type***Direct***Parameter****Code** *Code of pause (refer to configuration)***Description**

G80 forced CN to pause state and setting a pause code. **CODE** parameter defines the message code to be showed. If code hasn't been configured a message "NO CODE PAUSE" is showed. The PAUSE procedure is the same of the hardware one.

**Ex:**

```
G80 X4 // PAUSE IS FORCED WITH CODE 4
```

**25.9.7 G81 – Management secondary axes LIMITS**

(Shifted on G1081 if USE\_G80\_CYCLES=TRUE)

**Syntax****G81 X**mode**Function type***Direct***Parameter***mode**Mode of LIMITS management***X0**Set **FIRST POSITIVE LIMITS** (default – LIMITE\_P\_ )**X1**Set **FIRST NEGATIVE LIMITS** (default – LIMITE\_N\_ )**X2**Set **SECOND POSITIVE LIMITS** (2ND\_LIMITE\_P\_ )**X3**Set **SECOND NEGATIVE LIMITS** (2ND\_LIMITE\_N\_ )**Description**

Sometimes is necessary change in temporary mode the Axes limits for make the axes movements outside to primary limits (Eg: TOOL CHANGE)

In Isous is possible used the SECONDARY LIMITS positive and negative

**Machine parametrs:****2ND\_LIMITE\_N\_****2ND\_LIMITE\_P\_**

This parameters can be activated or disactivated by G81 function.

If the secondary limits remain activated, when the PART PROGRAM is finished, automatically are reset to primary LIMITS.

This function is typically used to TOOL CHANGE MACRO (M6)

**Ex:****G81 X3** // ACTIVE SECONDARY NEGATIVE LIMITS

.

**G81 X1** // ACTIVE PRIMARY NEGATIVE LIMITS**25.9.8 G20 – Axes Values in Inch****Syntax****G20****Function type***Modal***Cancel****G21****Description**

G20 Enable the Programmation Axes Values in Inch.(G0-G1-G2-G3 etc)

**25.9.9 G21 – Axes Values in Millimeters****Syntax****G21****Function type***Modal - Default***Cancel****G20****Description**

G20 Enable the Programmation Axes Values in Millimeters.(G0-G1-G2-G3 etc)

## 25.10 VARIABLE MANAGEMENT FUNCTIONS

Isous manages files which can contain the state of some variable. These files are stored on the PC HardDisk. It's possible to load them (one at a time) by Partprogram. When file has been loaded a list of saved variables is filled. The length of the list depends to the number of stored variable. There is no limit to list length. These variables can be read or written in the list by specific instructions in the PartProgram. In other words it's possible to obtain Backups of variables state for generic use.

### 25.10.1 LOAD\_VAR – load a variables file in current list

#### Syntax

**LOAD\_VAR** filename

#### Parameter

Filename	Name of the file to be loaded
	<i>The name can contain extension but there must not be delimitation characters (+-* etc.)</i>

#### Description

**LOAD\_VAR** load the file named initializing the internal list with values container in the file. The list is defined as an ARRAY of double values and we can access them by **GET\_VAR** and **WRITE\_VAR** functions. If the file will be not found Isous will show the relative error.

#### Ex:

```
LOAD_VAR MYFILE.PNT // LOAD FILE
GET_VAR $VAR1 0 // SET VAR1 FROM INDEX 0 OF THE LIST
GET_VAR $VAR2 1 // SET VAR2 FROM INDEX 1 OF THE LIST
```

### 25.10.2 GET\_VAR – Read a value from the loaded list and store it in a variable

#### Syntax

**GET\_VAR** \$var index

#### Parameters

\$var	Name of the destination variable
Index	Expression indicating the index in the list

#### Description

**GET\_VAR** reads a value in the current list and stores it in a variable. The list must have been sized (by DIM\_VAR) or however it must have a size greater or equal to INDEX. If index is over the list size an error will be showed.

#### Ex:

```
LOAD_VAR MYFILE.PNT // LOAD FILE
$INDEX=0
LOOP 10
    GET_VAR $VAR1 $INDEX // LOAD X POSITION
    GET_VAR $VAR2 $INDEX+1 // LOAD Y POSITION
    G1 X[$VAR1]Y[$VAR2] // MOVE
    $INDEX=$INDEX+2 // INCREASE INDEX
END_LOOP
```

**25.10.3 WRITE\_VAR – Write a value in the loaded list getting it from a variable****Syntax****WRITE\_VAR** \$var index**Parametri**

<i>\$var</i>	<i>Name of the source variable</i>
<i>index</i>	<i>Expression indicating the index in the list</i>

**ATTENTION:** list must be sized for INDEX value

**Description**

**WRITE\_VAR** allows to store a value of the current list in a variable. The list must have been sized (by DIM\_VAR) or however it must have a size greater or equal to INDEX. If index is over the list size an error will be showed.

**Ex:**

```

DIM_VAR 10           // SIZE LIST WITH 10 EMPTY ELEMENTS
WRITE_VAR $VAR1 0    // STORE VAR1 IN INDEX 0 OF THE LIST
WRITE_VAR $VAR1 1    // STORE VAR2 IN INDEX 1 OF THE LIST
SAVE_VAR MYFILE.PNT // SAVE FILE

```

**25.10.4 SAVE\_VAR – save a variables file with current list****Syntax****SAVE\_VAR** filename**Parameter**

<i>filename</i>	<i>Name of the file to be saved</i>
-----------------	-------------------------------------

*The name can contain extension but there must not be delimitation characters (+-\* etc.)*

**Description**

**SAVE\_VAR** saves the value in the current list to the named file.

**Ex:**

```

DIM_VAR 10           // SIZE LIST WITH 10 EMPTY ELEMENTS
WRITE_VAR $VAR1 0    // STORE VAR1 IN INDEX 0 OF THE LIST
WRITE_VAR $VAR1 1    // STORE VAR2 IN INDEX 1 OF THE LIST
SAVE_VAR MYFILE.PNT // SAVE FILE

```

**25.10.5 FILE\_EXISTS – test if a file exists****Syntax****FILE\_EXISTS** \$var filename**Parameters**

<i>\$var</i>	<i>Variable where to store result:</i> <i>0=file not found, 1=file exists</i>
<i>filename</i>	<i>Name of the file</i> <i>The name can contain extension but there must not be delimitation characters (+-* etc.)</i>

**Description**

**FILE\_EXISTS** allows to test if a variable file exists.

**Ex:**

```

FILE_EXISTS $VAR MYFILE.PNT // TEST FILE
IF $VAR=0           // FILE NOT FOUND
....
END_IF

```

**25.10.6 ADD\_VAR – Add a value to current list****Syntax****ADD\_VAR** value**Parameter**

<i>value</i>	<i>Expression or variable which value will be appended to the list</i>
--------------	--

**Description**

**ADD\_VAR** appends a value to the current list. The list will be resizing to contain the new element.

**Ex:**

```

ADD_VAR $VAR1           // APPEND VALUE FROM VAR1
ADD_VAR 10.23          // APPEND VALUE FROM CONSTANT
ADD_VAR $VAR2*($VAR3+$VAR4) // APPEND VALUE FROM EXPRESSION

```

**25.10.7 REMOVE\_VAR – Remove a value from current list****Syntax****REMOVE\_VAR** Index**Parameter**

<i>index</i>	<i>Expression indicating index of list to be removed</i>
--------------	--

**Description**

**REMOVE\_VAR** remove a value from the current list. All index above the removed one will be re-indexed. If the index is over the list size an error will be showed.

**Ex:**

```

REMOVE_VAR 1 // REMOVE VALUE AT INDEX 1

```

**25.10.8 CLEAR\_VAR – Remove all values from the current list****Syntax****CLEAR\_VAR****Description**

**CLEAR\_VAR** erase all the values from the current list. List will be sized at zero and the value cannot be restored.

**Ex:**

```

CLEAR_VAR           // CLEAR ALL CURRENT LIST

```

**25.10.9 DIM\_VAR – Size current list to a specific number of elements****Syntax****DIM\_VAR** Nelem**Parametri**

<i>Nelem</i>	<i>Expression indicating the number of elements to be sized (the value of all elements will be set with ZERO)</i>
--------------	---

**Description**

**DIM\_VAR** allows to re-size the current list. All last value will be lost and the new values will be set with ZERO.

**Ex:**

```
DIM_VAR 10           // SIZE LIST WITH 10 ELEMENTS
```

**25.10.10 COUNT\_VAR – Get the number of elements in the current list****Syntax****COUNT\_VAR** \$var**Parameter**

<i>\$var</i>	<i>Variable where to store the list size</i>
--------------	--

**Description**

**COUNT\_VAR** gets the number of elements of the current list and store the value in a variable.

**Ex:**

```
COUNT_VAR $VAR1      // STORE SIZE IN VAR1
IF $VAR1=0          // IF LIST IS EMPTY
    DIM_VAR 10        // RE-SIZE THE LIST
```



## 25.11 HM FUNCTIONS

HM functions are an upgrade to standard M functions. They can use parameters passed to function when invoked like common high level languages as C.

Parameters are then read by HM function writing it in private variables.

HM functions reside on PC and they must be created with the specific utility of human interface.

### 25.11.1 Call of HM functions

#### Syntax

**HM**num par1 par2 par3 ....

#### Function type

*Direct*

#### Parameters

*Num*    *Number code of HM function*

*PARn*   *Variable or constant. Parameters must be separated by space*

#### Description

HM with code **NUM** is invoked passing it the parameters defined with **PARn**.

**HM functions always wait for emptying of the MOVEMENT BUFFER before it is really invoked.**

**All parameters defined in the declaration must be inserted, else an error will be generated.**

Ex:

**HM**10 \$VAR1 \$VAR2 12.3 24.125    // CALL OF HM 10 PASSING 4 PARAMETERS

### 25.11.2 Building of a HM function

A **HM** function, before to be used, must be built and pre-compiled by specific option in the human interface.

**HM** functions are formed by ISO code and they can be used all Isous functions. After pre-compiling **HM** is available to PartProgram.

**VARIABLES** and **LABELS** declared inside HM function are **PRIVATE** (not visible in PartProgram). In other words

**VARIABLES** and **LABEL** could be a same name both in HM function and PartProgram, Isous recognized that automatically. It's possible to share **VARIABLES** with Partprogram declaring them with **GLOBAL prefix**.

Inside **HM** function it's possible call other **HM** or **M** functions both on CN and PC.

#### Example of building of a HM function

```
GET $PAR1 $PAR2 $PAR3 $PAR4 // READ PARAMETERS
GLOBAL $PAUSE // SHARE $PAUSE WITH PART PROGRAM
F[$PAR3] // SET FEED AT $PAR3
G1 X[$PAR1] Y[$PAR2] Z[$PAR3] // LINEAR INTERPOLATION
G4 F[$PAUSE] // PAUSE
```

As we can see from the example, a HM function is very similar to the high level languages. If there was a need to return a value we can do it using **GLOBAL** variables.

## 25.12 M FUNCTIONS

There are two type of M function:

- **Inside CN**
- **Inside PC**

Obviously function cannot have the same number. **M inside PC** are priority to **M inside CN**. If both they were present Isous invokes the PC one.

### 25.12.1 M functions inside CN

M function inside CN have to be built with VTB environment (refer to relative documentation). They can read some parameters from PartProgram or return it a value by some predefined variables.

#### PREDEFINED VARIABLES

<code>\$_PARAM_1</code>	parameter 1
<code>\$_PARAM_2</code>	parameter 2
<code>\$_PARAM_3</code>	parameter 3
.	
.	
<code>\$_PARAM_n</code>	parameter n

The number of parameters available depends to Isous configuration, but it's a limit of 10 parameters (default 5). Each time PartProgram writes or reads a variable of `$_PARAM_n` type, they are read from CN memory. `$_PARAM` variables are 32 bit **INTEGER**. All parameters must be written before invoking M function and read at the end of it. **M functions always wait for emptying of the MOVEMENT BUFFER before it is really invoked.**

Ex:

```
$_PARAM_1=134 // WRITE PARAMETER 1
$_PARAM_2=$VAR// WRITE PARAMETER 2
$_PARAM_3=12600 // WRITE PARAMETER 3
M100 // INVOKE M100 FUNCTION
$VAR1=$_PARAM_1 // READ PARAMETER 1 MODIFIED BY M100
```

### 25.12.2 M function inside PC

**M** function inside PC are very similar to HM functions, the only difference is that M functions cannot have any parameter. Therefore exchange of value must be made with GLOBAL variables.

A **HM** function, before to be used, must be built and pre-compiled by specific option in the human interface.

**HM** functions are formed by ISO code and they can be used all Isous functions. After pre-compiling **HM** is available to PartProgram.

**VARIABLES** and **LABELS** declared inside HM function are **PRIVATE** (not visible in PartProgram). In other words

**VARIABLES** and **LABEL** could be a same name both in HM function and PartProgram, Isous recognized that automatically. It's possible to share **VARIABLES** with Partprogram declaring them with **GLOBAL prefix**.

Inside **HM** function it's possible call other **HM** or **M** functions both on CN and PC.

#### Example of building of a M function

```
GLOBAL $VAR1           // SHARE $VAR1 WITH PART PROGRAM
GLOBAL $VAR2           // SHARE $VAR2 WITH PART PROGRAM
G1 X$VAR1 Y$VAR2       // LINEAR INTERPOLATION
```

## 25.13 Essential M FUNCTIONS

In this section are described the essential M functions. These are necessary for correct machine operation.

### 25.13.1 START M

This function is execute when START PROGRAM is required. Its use is not important, because the preparatory M functions are inserted in to Part Program

### 25.13.2 END M

This function is execute when END PROGRAM is required. Its use is not important, because the preparatory M functions are inserted in to Part Program.

### 25.13.3 STOP M

This function is execute when STOP PROGRAM button is pressed. This function is VERY IMPORTANT.

It usually STOP ALL AXES and Spindle, water etc

#### *Essential Functions In M STOP*

- 1) **G101 Stop axes**
- 2) **G62 Wait axes stop**
- 3) **SET/RESET output for spindle,water etc.**
- 4) **Eventually parking axes**

Se nessuna M di STOP viene configurata, il CNC blocca solamente gli assi nel punto di STOP.

If no M STOP configured, will stop only the axes by CNC.

### 25.13.4 PAUSE M

This function is execute when PAUSE PROGRAM button is pressed. This function is VERY IMPORTANT.

usually this function stops the spindle. the water and saves the positions axes for pause resume.

#### *Essential Functions In M PAUSE (ex 3 axes)*

- 1) **GLOBAL \$SAVEX GLOBAL variable for X AXIS**
- 2) **GLOBAL \$SAVEY GLOBAL variable for Y AXIS**
- 3) **GLOBAL \$SAVEZ GLOBAL variable for Z AXIS**
- 4) **G62 Wait axes stop**
- 5) **\$SAVEX=\${Q0} Save X position**
- 6) **\$SAVEY=\${Q1} Save Y position**
- 7) **\$SAVEZ=\${Q2} Save Z position**
- 8) **SET/RESET output for spindle,water etc.**
- 9) **Eventually parking axes**

If M PAUSE is not configured, will stop only the axes by CNC.

**25.13.5 RESUME PAUSE M**

This function is execute when START button is pressed after PAUSE PROGRAM. This function is VERY IMPORTANT. usually this function repositions the axes and SET/RESET output for spendle, water etc.

**Essential Functions In M RESUME PAUSE (ex 3 assi)**

- 1) GLOBAL \$SAVEX **GLOBAL variable for X AXIS**
- 2) GLOBAL \$SAVEY **GLOBAL variable for Y AXIS**
- 3) GLOBAL \$SAVEZ **GLOBAL variable for Z AXIS**
- 4) G96 **Offset suspension**
- 5) G98 **Work origins suspension**
- 6) G0 Z0 **Z axis to safety position**
- 7) F1 **SPEED axes**
- 8) G1 X[\$SAVEX] Y[\$SAVEY] **Axes X,Y, etc. To initial positions (these are saved by M pause)**
- 9) G62 **Wait axes in positions**
- 10) G1 Z[\$SAVEZ] **Axis Z to initial position (this is saved by M pause)**
- 11) G62 **Wait Z axis in position**
- 12) G97 **ResumeOffset**
- 13) G99 **Resume Work origins**
- 14) **SET/RESET output for spendle,water etc.**

If no M resume pause configured, the CNC axes back to the starting point in the interpolation of a set F in the machine parameter "VRIPOS"

**25.13.6 GO BLOCK M**

This function is execute when START button is pressed by PlugIn **"GO BLOCK"**. usually this function repositions the axes and SET/RESET output for spendle, water etc.

**Essential Functions In GO BLOCK M (ex 3 assi)**

- 1) \$POSX=\$[C0] **Axis X position calculated by CNC**
- 2) \$POSY=\$[C1] **Axis Y position calculated by CNC**
- 3) \$POSZ=\$[C2] **Axis Z position calculated by CNC**
- 4) G96 **Offset suspension**
- 5) G98 **Work origins suspension**
- 6) G0 Z[0] **Z axis to safety position**
- 7) F1 **SPEED axes**
- 8) G1 X[\$POSX] Y[\$POSY] **Axes X,Y, etc. To initial positions**
- 9) G62 **Wait axes in positions**
- 10) G1 Z[\$POSZ] **Axis Z to initial position**
- 11) G62 **Wait Z axis in position**
- 12) G97 **ResumeOffset**
- 13) G99 **Resume Work origins**
- 14) **SET/RESET output for spendle,water etc.**

**25.13.7 GO RETRACE M**

This function is execute when START button is pressed by PlugIn **"RETRACE"**. usually this function repositions the axes and SET/RESET output for spendle, water etc.

**Essential Functions In M RETRACE**

- 1) **SET/RESET output for spendle,water etc.**

## 25.14 DEFINING DEPTH AXIS

The depth axis is used for some functions Isous. Normally, this axis is related to the work plan selected:

<i>Work Plane XY</i>	<i>Depth axis Z</i>
<i>Work Plane XZ</i>	<i>Depth axis Y</i>
<i>Work Plane YZ</i>	<i>Depth axis X</i>

The depth axis is used by the simulation process and the way PREVIEW and by G47 function

### 25.14.1 G48 Define Depth axis

#### Syntax

**G48** axis name

Function type

immediate

#### Parameters

*Axis Name*                      *ex: X,Y,Z,A,B etc.*

#### Description

G48 definisce un asse di profondità diverso da quelli scelti in automatico da Isous.

Se l' asse scelto è uguale ad uno degli assi del piano di lavoro impostato, viene generato un errore di Run Time.

G48 defines a depth axis different to axis chose automatically by Isous

Ex:

**G48 A** // A is depth axis

## 25.15 MILD MODE – EDGE SMOOTHING

Isous can use a special algorithm for EDGE SMOOTHING

With the PARAMETERS MILD\_ (MILD\_X – MILD\_Y etc.) you can Smooth the edge with various value.


The MILD MODE can be activated on single Axis.

The MILD\_ set of value can be used from 200 to 20 (estimated values)

The G49 function, manages the MILD MODE.

Following you can see a MILD MODE example values

The MILD function, works for EDGE under the parameters **SGLP\_MILD** for 2D or **SGL3D\_MILD\_** for 3D (G65) Edges, above these values aren't SMOOTHED by MILD



### 25.15.1 G49 MILD MODE Managing

#### Syntax

**G49** Axes Name where enable MILD MODE – None Axis, MILD MODE DISABLED ON ALL AXES

**G49.0** Suspends MILD MODE

**G49.1** Resumes MILD MODE on the Axes indicated in previous G49

#### Function type

Immediate – Disabled on PROGRAM STOP

#### Parameters

**Axes Name**                      **Name of Axes where enable Mild Mode: ex: G49 XYZ**  
**(QX,QY,QZ,QA,QB,QC,QU,QV,QW)**

#### Description

G49 manages ENABLE/DISABLE MILD MODE.

**G49** with **Axes Name** (ex. G49 XY) enabled MILD MODE on the Axes indicated.

**G49** Without parameters DISABLES MILD MODE on the ALL AXES.



**G49.0** Without parameters **SUSPENDS MILD MODE**


**G49.1** Without parameters **RESUMES MILD MODE** if it was activated by **G49**.

**Ex:**

```

G60
F15
G0 Z3
G49 XY // ENABLED MILD MODE ON XY
G0X63.7738 Y160.6052
F10
G01 Z0
X70.9693 Y140.2459 F15
X92.5556 Y139.694
X75.4163 Y126.5593
X81.5619 Y105.8589
X63.7738 Y118.1006
X45.9857 Y105.8589
X52.1313 Y126.5593
X34.992 Y139.694
X56.5783 Y140.2459
X63.7738 Y160.6052
G49 // DISABLED MILD MODE ON ALL AXES
G0 Z3
G0 X56.5783 Y140.2459

```



## 25.16 PARALLEL TASKS

IsoUs can execute two Gcode parallel Tasks besides the main Gcode

This allows to execute functions in asynchronous mode to increase the machine performances.

The parallel tasks **TASK1** and **TASK2** can't manage all main gcode functions (see single instructions)

### 25.16.1 USTASK-ENDUSTASK

These two instructions define the Gcode that is load in the TASK1 automatically from the compiler.

USTASK and ENDUSTASK MUST BE Write in the Main Gcode

#### USTASK

LOOP 1000

    \${O1}=1

    G4F1

    \${O1}=0

    G4F1

END\_LOOP

#### ENDUSTASK

**TASK.RUN 1** // FOM MAIN PROCESS RUN TASK1 CODE

LOOP 1000

    G1X100Y100F5

    G4F1

    X0Y0

    G4F1

END\_LOOP

The gcode enclosed in USTASK ENDUSTASK will be load in the TASK1 but it is not execute during the RUN the Main Gcode. For execute it must be used TASK.RUN.

The Gcode external to USTASK ENDUSTASK will be execute in the Main Process during the RUN

### 25.16.2 TASK.RUN

Starts the execution the code in TASK

#### Syntax

#### TASK.RUN Ntask

**Ntask** TASK number where:

**0** Task Main (not used)

**1** TASK1

**2** TASK2

One task can't run itself

### 25.16.3 TASK.STOP

Stop the execution the code in TASK

#### Syntax

#### TASK.STOP Ntask

**Ntask** TASK number where:

**0** Task Main (not used)

**1** TASK1

**2** TASK2

One task can't stop itself

**25.16.4 TASK.PAUSE**

Pause the execution the code in TASK

**Syntax****TASK.PAUSE Ntask**

**Ntask** TASK number where:  
**0** Task Main (not used)  
**1** TASK1  
**2** TASK2

One task can't pause itself

**25.16.5 TASK.READVAR**

Read a Variable by Address in the Task

**Syntax****TASK.READVAR Ntask AddrVar \$VarDest**

**Ntask** TASK number where:  
**0** Task Main  
**1** TASK1  
**2** TASK2  
**AddrVar** Variable Address to Read  
**\$VarDest** Destination Variable

Ex:

**TASK.READVAR 1 2000 \$VAR // READ THE VARIABLE 2000 FROM TASK 1 AND STOR IN VAR**

**25.16.6 TASK.WRITEVAR**

Write a Variable by Address in the Task

**Syntax****TASK.WRITEVAR Ntask AddrVar \$VarSource**

**Ntask** TASK number where:  
**0** Task Main  
**1** TASK1  
**2** TASK2  
**AddrVar** Variable Address to Write  
**\$VarSource** Source Variable

Ex:

**TASK.WRITE 1 2000 \$VAR // WRITE \$VAR IN THE VARIABLE 2000 OF TASK 1**

**25.16.7 TASK.STATUS**

Read the Task status

**Syntax****TASK.STATUS Ntask \$VAR**

**Ntask** TASK number where:  
**0** Task Main (not used)  
**1** TASK1  
**2** TASK2  
**\$VAR** Status Destination Variable  
 0 - Task Stop  
 1 - Task Run  
 2 - Task Pause

Ex:

**TASK.STATUS 1 \$VAR // READ TASK 1 STATUS IN \$VAR**

**25.16.8 TASK.LOADCMD**

Load a CMD FILE in the Task

The CMD file Must be created by PlugIn MHM

The CMD isn't executed but is necessary to use TASK.RUN

**Syntax****TASK.LOADCMD Ntask "CMDNAME"**

**Ntask** TASK number where:  
**0** Task Main (not used)  
**1** TASK1  
**2** TASK2

**"CMDNAME"** CMD Name (in quotes and without extension) to load in the TASK

**Ex:**

**TASK.LOADCMD 1 "TESTCMD" // LOAD TH CMD TESTCMD IN TASK1**

**25.16.9 TASK.PRIORITY**

Set Task Priority

**Syntax****TASK.PRIORITY Ntask Pval**

**Ntask** TASK number where:  
**0** Task Main  
**1** TASK1  
**2** TASK2

**Pval** Priority from 0 to 100  
**0** High Priority (default)

**Ex:**

**TASK. PRIORITY 1 2 // TASK 1 PRIORITY 2**

## 25.17 MAIN MACHINE PARAMETERS

In this chapter are explained the MAIN machine parameters to be set in Isous to configure the machine. MAIN MACHINE PARAMETERS are always present on any application, however it's possible that applications share more PARAMETERS. Indeed Isous allows to customize parameters to adapt just Isous for any type of machine.

### **NOTE TO CALCULATE ACCELERATION IN Mt/sec<sup>2</sup>**

In Isous acceleration is expressed in increase for CN sample, to obtain the value in Mt/sec<sup>2</sup> this is the calculation to do:

$$ACC = ACC\_xx / TAU^2$$

TAU = Sample time set on CN in msec

ACC\_xx = value of acceleration parameter

If for example we set an ACC\_xx=100 and a sample of TAU=5 msec, we obtain:

$$ACC=100/(5*5)=4 \text{ Mt/sec}^2$$

### 25.17.1 Generic parameters

#### 25.17.1.1 FEEDMAX

It defines the maximum **FEED** of the system. The unit of measure depends by system resolution (typically mm/min). If it's set a **F** at speed greater than this, it is limited at **FEEDMAX**.

[This parameter is affected by unit of measure set. Working with resolution of 0.0001 \(instead of typical 0.001\) this parameter must be expressed in tenth of mm/min.](#)

#### 25.17.1.2 FEEDMIN

It defines the minimum **FEED** of the system. The unit of measure depends by system resolution (typically mm/min). If it's set a **F** at speed less than this, it is limited at **FEEDMIN**.

[This parameter is affected by unit of measure set. Working with resolution of 0.0001 \(instead of typical 0.001\) this parameter must be expressed in tenth of mm/min.](#)

#### 25.17.1.3 FEEDDEF

It defines the default **FEED** set by the system at start-up. The unit of measure depends by system resolution (typically mm/min).

[This parameter is affected by unit of measure set. Working with resolution of 0.0001 \(instead of typical 0.001\) this parameter must be expressed in tenth of mm/min.](#)

#### 25.17.1.4 FEEDRES

It defines the resolution of the speed set by F.

<b>1</b>	<b>mm/min</b>	<b>ex: F1500 = 1,5 Mt/min</b>
<b>1000</b>	<b>mt/min</b>	<b>ex: F1.5 = 1.5 Mt/min</b>

#### 25.17.1.5 SPEEDMAX

It defines the maximum speed (**S**) of the system. The unit of measure depends by system resolution. If it's set a **S** at speed greater than this, it is limited at **SPEEDMAX**.

#### 25.17.1.6 SPEEDMIN

It defines the minimum speed (**S**) of the system. The unit of measure depends by system resolution. If it's set a **S** at speed less than this, it is limited at **SPEEDMIN**.

#### 25.17.1.7 SPEEDDEF

It defines the default speed (**S**) set by the system at start-up. The unit of measure depends by system resolution.

**25.17.1.8 VMAXGO**

It defines the maximum speed for the positioning with G0. It is in percent of the speed calculated by system based to maximum speed of each axis.

Value can be from 0 to 100 %.

[This parameter is affected by unit of measure set. Working with resolution of 0.0001 \(instead of typical 0.001\) this parameter must be expressed in tenth of mm/min.](#)

**25.17.1.9 ACC\_GO**

It defines the acceleration for positioning with G0. See the above note to detail for unit of measure.

**25.17.1.10 ACC\_GO.1\_**

It defines the private acceleration for positioning with G0.1

**25.17.1.11 ACC\_MAX\_**

It defines the max acceleration for single used in the function G66 X-100 for Adaptive Feed Control.

**25.17.1.12 ACC\_LAV**

It defines the acceleration for interpolation with G1, G2 and G3. See the above note to detail for unit of measure.

**25.17.1.13 ACC\_QSTOP**

It defines the acceleration for quick-stop when the position limit is reached. See the above note to detail for unit of measure.

**25.17.1.14 VEL\_GO\_LINE\_RETRACE**

It defines the speed for positioning "GO LINE" during **RETRACE** function. The unit of measure depends by system resolution (typically mm/min).

[This parameter is affected by unit of measure set. Working with resolution of 0.0001 \(instead of typical 0.001\) this parameter must be expressed in tenth of mm/min.](#)

**25.17.1.15 ACC\_RAGGIO\_MAX**

It defines the centrifuge acceleration to auto-reducing speed on circular interpolation. It must be set after machine test. Normally this parameter is set with values from 1 to 15  
Small values defines a greater feed reduction when the radius are small. If the minimum value 1 is not sufficient to reduction your desired feed, is necessary use the decimal part in the following mode  
Insert the parameter ACC\_RAGGIO\_MAX with value greater to 100 or 1000, the effective value is:

**$ACC\_RAGGIO\_MAX=(ACC\_RAGGIO\_MAX-100)/10$  (for values over 100)**

**$ACC\_RAGGIO\_MAX=(ACC\_RAGGIO\_MAX-1000)/100$  (for values over 1000)**

So:

109 = 0,9

1018 = 0,18

Etc.

**25.17.1.16 RED\_ACC\_RADIUS**

If it is >0 allows to have a further reduction of **ACC\_RAGGIO\_MAX** parameter. **RED\_ACC\_RADIUS** indicates the minimum radius in micron below this value **ACC\_RAGGIO\_MAX** is reduced in proportional mode

**$ACC\_RAGGIO\_MAX=(RADIUS/RED\_ACC\_RADIUS)*ACC\_RAGGIO\_MAX$**

Ex:

**$RED\_ACC\_RADIUS=3000$**

**$ACC\_RAGGIO\_MAX=5$**

**$Radius=2000 (<3000)$**

**$ACC\_RAGGIO\_MAX=(2000/3000)*5=3.33$**

**25.17.1.17 MIN\_ACC\_RADIUS**

Indicate the minimum value of reduction for **ACC\_RAGGIO\_MAX** by **RED\_ACC\_RADIUS**.  
 $RED\_ACC\_RADIUS = (RED\_ACC\_RADIUS - 100) / 10$  (for values over 100)  
 $RED\_ACC\_RADIUS = (RED\_ACC\_RADIUS - 1000) / 100$  (for values over 1000)  
 Value=0 disable

**25.17.1.18 VRIPOSO**

It defines the speed for re-positioning in start after PAUSE. The unit of measure depends by system resolution (typically mm/min). This speed acts only if axis are moved in PAUSE state and they aren't repositioned in the exact point when restarted.

**25.17.1.19 SGLP**

Threshold in tenth of degree (default 200 = 20 degree) to stop axis on edge when CN works in FAST INTERPOLATION. Threshold acts only on work plane axis. CN stop automatically the axis when on work plane it recognizes an angle greater than SGLP (edge found).

**25.17.1.20 SGLP\_RED**

Percentage of SGLP to begin the gradual slowdown in the proportion of the edge. If **SGLP\_RED = 0** parameter is disabled and is done only stop on the corner SGLP, otherwise the percentage set, the CNC starts slowing down (see examples below). When **SGLP\_RED** is set to a value greater than 0, it would be necessary to increase the value of SGLP.

**25.17.1.21 MAX\_RED**


Maximum percentage reduction in speed caused by the parameter **SGLP\_RED**. This is always limited to a value below 100% (to avoid that the speed goes to ZERO) (see examples below)

**Example Parameter SGLP\_RED and MAX\_RED**


If **SGLP\_RED** is disabled (value set to ZERO) work only parameter **SGLP** or **SGL3D** in the following mode:

Corner less to **SGLP** or **SGL3D** the CNC not commands the stop axes  
 Corner greater to **SGLP** or **SGL3D** the CNC decelerates and commands the STOP Axes

**Ex: SGLP=200 (20 degrees) , SGLP\_RED=0**



**Ex: SGLP=450 (45 degrees) , SGLP\_RED=10 ( 10% of 45 degrees – at 4,5 degrees start the slowdown) MAX\_RED=85**



**25.17.1.22 SGLR**

Threshold to signal an error for circular interpolation.

In circular interpolation CN computer radius in start point and in end point, if the difference is greater than SGLR program is stopped showing an error. That happens when arc is made by center positions I,J with value not accurate.

The unit of measure depends by system resolution (typically 0.001 mm, default 10 thousandths). Ex:

**Unit of measure 0.001 mm**

**10 = 10 thousandths of mm**

**Unit of measure 0.0001 mm**

**100 = 10 thousandths of mm**

**25.17.1.23 ACQ\_MODE**

It define the acquisition mode for searching of the **SENSOR** with **G102** function and for **StartAcqSens** method of Framework. Actually not in use, reserved for future expansion.

**25.17.1.24 ACQ\_VEL**

It defines the axis speed for acquisition sensor cycle.

Contrary to other speed parameters this is NOT affected by unit of measure and must be expressed always in mm/min

**25.17.1.25 RESQUOTE**

Resolution for axis position. It depends by DSOF-axis parameter.

It defines the minimum unit for axis position:

**10** → Tenth of mm

**100** → Hundredths of mm

**1000** → Thousandths of mm

**10000** → 0.1 Thousandths of mm

**100000** → 0.01 Thousandths of mm

**25.17.1.26 VISUAREAL**

Enable or disable showing of axis ACTUAL positions

**-1 = Disable reading of actual position**

**0 = Enable by INTERFACE**

**1 = Enable reading of ACTUAL positions**

**2 = Enable reading of ACTUAL FOLLOWING ERROR position**

**25.17.1.27 ENABLE\_OW\_GO**

Enable or disable override potentiometer on G0

**NO = Potentiometer disabled**

**YES = Potentiometer enabled**

**NO GO ACK = Potentiometer disabled with Acknowledged on CN**

**YES GO ACK = Potentiometer enabled with Acknowledged on CN**

**25.17.2 Axis parameters****25.17.2.1 VMAX\_**

It defines the maximum speed of the single axis for positioning with G0. The unit of measure depends by system resolution (typically mm/min).

This parameter is affected by unit of measure set. Working with resolution of 0.0001 (instead of typical 0.001) this parameter must be expressed in tenth of mm/min.



**25.17.2.2 VOVERLIMIT\_**

Defines the speed limit for a single Axis used in G66 X-100 during the check speed in RTCP Axes or tangential Axes. The unit is like to VMAX.

If one or more Axes exceed the value in VOVERLIMIT the FEED is decrease

**25.17.2.3 VMAX\_Pn**

It defines the maximum speed of the positioner number

**25.17.2.4 VJOG\_**

It defines the speed of the single axis manual positioning (jogging). The unit of measure depends by system resolution (typically mm/min).

**Contrary to other speed parameters this is NOT affected by unit of measure and must be expressed always in mm/min**

**25.17.2.5 ACC\_JOG\_**

Acceleration for JOGGING positioning. See the above note to detail for unit of measure.

**25.17.2.6 RZERO\_MODE**

This parameter defines the mode of homing procedure. These are the value accepted:

**RZERO\_MODE=0 – Backward (negative), sensor ACTIVATED**

- 1) Fast backward to zero-sensor with **F=RZERO\_VEL**
- 2) Slow forward to exit from zero-sensor with **F=RZERO\_VELF**
- 3) Slow backward to zero-sensor with **F=RZERO\_VELF**
- 4) Move axis to offset position (**RZERO\_OFFSET**) with **F=RZERO\_VEL**
- 5) Preset position at **RZERO\_PRESET**

**RZERO\_MODE=1 - Forward (positive), sensor ACTIVATED**

- 1) Fast forward to zero-sensor with **F=RZERO\_VEL**
- 2) Slow backward to exit from zero-sensor with **F=RZERO\_VELF**
- 3) Slow forward to zero-sensor with **F=RZERO\_VELF**
- 4) Move axis to offset position (**RZERO\_OFFSET**) with **F=RZERO\_VEL**
- 5) Preset position at **RZERO\_PRESET**

**RZERO\_MODE=2 - Backward (negative), sensor ACTIVATED with encoder INDEX**

- 1) Fast backward to zero-sensor with **F=RZERO\_VEL**
- 2) Slow forward to exit from zero-sensor with **F=RZERO\_VELF**
- 3) Slow backward to zero-sensor with **F=RZERO\_VELF**
- 4) Continue to first encoder INDEX always with **F=RZERO\_VELF**
- 5) Move axis to offset position (**RZERO\_OFFSET**) with **F=RZERO\_VEL**
- 6) Preset position at **RZERO\_PRESET**

**RZERO\_MODE=3 - Forward (positive), sensor ACTIVATED with encoder INDEX**

- 1) Fast forward to zero-sensor with **F=RZERO\_VEL**
- 2) Slow backward to exit from zero-sensor with **F=RZERO\_VELF**
- 3) Slow forward to zero-sensor with **F=RZERO\_VELF**
- 4) Continue to first encoder INDEX always with **F=RZERO\_VELF**
- 5) Move axis to offset position (**RZERO\_OFFSET**) with **F=RZERO\_VEL**
- 6) Preset position at **RZERO\_PRESET**

**RZERO\_MODE=4 - Backward (negative), sensor DISACTIVATED**

- 1) Fast backward to zero-sensor with **F=RZERO\_VEL**
- 2) Slow forward to exit from zero-sensor with **F=RZERO\_VELF**
- 3) Move axis to offset position (**RZERO\_OFFSET**) with **F=RZERO\_VEL**

- 4) Preset position at **RZERO\_PRESET**

**RZERO\_MODE=5 - Forward (positive), sensor DISACTIVATED**

- 1) Fast forward to zero-sensor with **F=RZERO\_VEL**
- 2) Slow backward to exit from zero-sensor with **F=RZERO\_VELF**
- 3) Move axis to offset position (**RZERO\_OFFSET**) with **F=RZERO\_VEL**
- 4) Preset position at **RZERO\_PRESET**

**RZERO\_MODE=6 - Backward (negative), sensor DISACTIVATED with encoder INDEX**

- 1) Fast backward to zero-sensor with **F=RZERO\_VEL**
- 2) Slow forward to exit from zero-sensor with **F=RZERO\_VELF**
- 3) Continue to first encoder INDEX always with **F=RZERO\_VELF**
- 4) Move axis to offset position (**RZERO\_OFFSET**) with **F=RZERO\_VEL**
- 5) Preset position at **RZERO\_PRESET**

**RZERO\_MODE=7 - Forward (positive), sensor DISACTIVATED with encoder INDEX**

- 1) Fast forward to zero-sensor with **F=RZERO\_VEL**
- 2) Slow backward to exit from zero-sensor with **F=RZERO\_VELF**
- 3) Continue to first encoder INDEX always with **F=RZERO\_VELF**
- 4) Move axis to offset position (**RZERO\_OFFSET**) with **F=RZERO\_VEL**
- 5) Preset position at **RZERO\_PRESET**

**RZERO\_MODE=8 – Backward to encoder INDEX (no sensor)**

- 1) Slow backward to first encoder INDEX with **F=RZERO\_VELF**
- 2) Move axis to offset position (**RZERO\_OFFSET**) with **F=RZERO\_VEL**
- 3) Preset position at **RZERO\_PRESET**

**RZERO\_MODE=9 – Forward to encoder INDEX (no sensor)**

- 1) Slow forward to first encoder INDEX with **F=RZERO\_VELF**
- 2) Move axis to offset position (**RZERO\_OFFSET**) with **F=RZERO\_VEL**
- 3) Preset position at **RZERO\_PRESET**

**RZERO\_MODE=32 – No searching, HOME position on ENABLE DRIVE**

**RZERO\_MODE=64 – No searching, position from ABSOLUTE ENCODER**

**RZERO\_MODE=128+HOME\_MODEx256 – CanOpen DS402 mode of HOMING procedure**

**25.17.2.7 LIMITE\_N\_**

Primary Negative limit of axis position **SOFTWARE-LIMIT**. The unit of measure depends by system resolution (typically 0.001 mm, for ex. -10000 = -10mm).

**25.17.2.8 LIMITE\_P\_**

Primary Positive limit of axis position **SOFTWARE-LIMIT**. The unit of measure depends by system resolution (typically 0.001 mm, for ex. 2000000 = 2000mm).

**25.17.2.9 2ND\_LIMITE\_N\_**

Secondary Negative limit of axis position **SOFTWARE-LIMIT**. The unit of measure depends by system resolution (typically 0.001 mm, for ex. -10000 = -10mm).

**25.17.2.10 2ND\_LIMITE\_P\_**

Secondary Positive limit of axis position **SOFTWARE-LIMIT**. The unit of measure depends by system resolution (typically 0.001 mm, for ex. 2000000 = 2000mm).

**25.17.2.11**     **LIMITE\_N\_Pn**  
Negative limit positioner

**25.17.2.12**     **LIMITE\_P\_Pn**  
Positive limit of positioner

- 25.17.2.13 DSOFV**  
 Software divider for the position of electronic manual hand-wheel. It reduces or increases its resolution. A negative value reverse the direction.  
 It is strictly related to VTB application, for ex:  
**Encoder Pulse** = 100 pulse/rev.  
**SCALA=1** (VTB application parameter)  
**FILTRO=10** (VTB application parameter)  
**DSOFV=10000** (pulse x filtro x **10 thousandths**)  
 Working with default resolution of 0.001mm we obtain a hundreds for each encoder pulse.
- 25.17.2.14 RZERO\_OFFSET**  
 Value of axis positioning after homing procedure (see RZERO\_MODE parameter for details).  
 The unit of measure depends by system resolution (typically um).
- 25.17.2.15 RZERO\_PRESET**  
 Value of preset position after homing procedure (see RZERO\_MODE parameter for details).  
 The unit of measure depends by system resolution (typically um).
- 25.17.2.16 RZERO\_VEL**  
 Fast speed for homing procedure (see RZERO\_MODE parameter for details).  
 The unit of measure depends by system resolution (typically mm/min).
- 25.17.2.17 RZERO\_VELF**  
 Slow speed for homing procedure (see RZERO\_MODE parameter for details).  
 The unit of measure depends by system resolution (typically mm/min).
- 25.17.2.18 RZERO\_ACC**  
 Acceleration for all movement of homing procedure. See the above note to detail for unit of measure.
- 25.17.2.19 MSOF\_**  
 It defines the number of pulse of one shaft revolution. If incremental encoder are connected to CN the pulse number must be multiplied for 4 to adjust hardware decoder. It works strictly related with DSOF, indeed the ratio MSOF/DSOF is used to transform unit from pulse to millimetres.
- 25.17.2.20 DSOF\_**  
 It defines the envelope one shaft revolution. It works strictly related with DSOF, indeed the ratio MSOF/DSOF is used to transform unit from pulse to millimetres.  
 This value determines the unit of measure of the system. Typically it's put a value in thousandths of mm. Accordingly it must set **RESQUOTE** parameter properly.
- 10** → *Tenth of mm*  
**100** → *Hundredths of mm*  
**1000** → *Thousandths of mm*  
**10000** → *0.1 Thousandths of mm*  
**100000** → *0.01 Thousandths of mm*

**25.17.2.21 GANTRY**

It defines the index to which axis get the position value. This function can be used to enable GANTRY function. This is the relationship from index and axis name:

0 → **AXIS X**  
 1 → **AXIS Y**  
 2 → **AXIS Z**  
 3 → **AXIS A**  
 4 → **AXIS B**  
 5 → **AXIS C**  
 6 → **AXIS U**  
 7 → **AXIS V**  
 8 → **AXIS W**

To enable GANTRY function:

**GANTRY\_X** → 0=disabled or index of axis master  
**GANTRY\_Y** → 1=disabled or index of axis master  
**GANTRY\_Z** → 2=disabled or index of axis master  
**GANTRY\_A** → 3=disabled or index of axis master  
**GANTRY\_B** → 4=disabled or index of axis master  
**GANTRY\_C** → 5=disabled or index of axis master  
**GANTRY\_U** → 6=disabled or index of axis master  
**GANTRY\_V** → 7=disabled or index of axis master  
**GANTRY\_W** → 8=disabled or index of axis master

**ATTENTION!!!**

To enable GANTRY function it must be supported by VTB application on CN.

**25.17.2.22 SGL3D**

It defines the threshold to detection of **EDGE** in 3D interpolations. This is used by **G65 G67** or by **AFC** filter **G66**. The value is approximatively expressed in tenth of degree. The proper value must be found from dynamics of the machine. In **G65** or **G67** interpolation when an axis overcomes this threshold axis are stopped.

*Reference value for SGL3D*

THRESHOLD in DEGREES	VALUE OF SGL3D (min-max)
5	60-90
10	125-175
20	250-350
30	300-500
45	400-700

**25.17.2.23 SGLAFC**

It defines the threshold for **AFC G66** to automatic reduction of the speed. This value determines the maximum speed change of each axis tolerates. When in the path are found values higher than SGLAFC speed is reduced. The value depends by dynamic of machine.

**25.17.2.24 MILD**

It Defines the MILD MODE value ([see G49 functions](#))

Estimated values from 200 to 20

**0 or 1000 DISABLED**

- 25.17.2.25 SGLP\_MILD**  
It Defines the threshold 2D **ABOVE THIS VALUE THE MILD MODE** Doesn't Works
- 25.17.2.26 SGL3D\_MILD\_**  
It Defines the threshold 3D **ABOVE THIS VALUE THE MILD MODE** Doesn't Works  
(see SGL3D for degrees references)
- 25.17.2.27 BACKLASH**  
Parameter for BACKLASH compensation. The unit of measure depends by system resolution (typically 0.001 mm, for ex. -10 = 0.01mm).
- 25.17.2.28 TBCK**  
It define a time to achieve the BACKLASH recovery. If  $Se\ TBCK \geq BACKLASH$  it is recovered in a single CN sample, else it is divided in more samples The number of samples will be: **BACKLASH / TBCK**  
With the result rounded-up.  
Ex:  

```

BACKLASH=100
TBCK=80
N.SAMPLES=1.25 → 2 samples

```

Sample is defined in the VTB application on CN (typically 2 msec).  
It's recommended to distribute the BACKLASH recovery in more sample when it is high (over 3-4 hundredths).
- 25.17.2.29 TSHF**  
It define a time to achieve the SetShiftAxis recovery.  
This value indicate the increment xTAU  
Ex:  

```

TAU=2 Ms
ValShift=100
TSHF_=10

```

The entire position is reached in 20 Ms
- 25.17.2.30 WR\_SPD9**  
It define automatic write SPEED "S" to variable USER GENERIC 10 to NC.  
**WR\_SPD=0** Automatic write disabled  
**WR\_SPD=1** Automatic write Enabled  
  
If WR\_SPD=1 when the S value of PartProgram is automatically writing to NC Variable User Generic 10
- 25.17.2.31 RFG**  
It define automatic limitation FEED in G1-G2-G3  
**RFG=0** Whitout limitation  
**RFG=1** If the velocity exceeds that of the single axis (VMAX\_), it is limited
- 25.17.2.32 JERK**  
It define the value of JERK for S Ramp.  
If the value is ZERO the S ramp is disabled (use trapezoidal ramp)  
Value > 0 enable S ramp.  
Max value 100

- 25.17.2.33 CR\_LIMIT**  
 Enables or disables the prior control of axis limits  
 If enabled, each START, PART PROGRAM is not performed if the axes exceed the limits set machine  
**CR\_LIMIT=0** Disable  
**CR\_LIMIT=1** Preventive control G0-G1 activated only on the final point of G2-G3  
**CR\_LIMIT=2** Preventive control activated G0-G1-G2-G3 (with explosion of ARCS)  
**CR\_LIMIT=3** Preventive control activated G0-G1-G2-G3 only in run time, before executed the block ( G2-G3 Only final point is controlled)
- 25.17.2.34 ARC\_REL**  
 Enables or disables the center of arc I,J in relative mode  
**ARC\_REL=0** The center I,J is in absolute mode (if set G90)  
**ARC\_REL=1** The center I,J is in relative mode (if set G90)
- 25.17.2.35 NO\_SHORT**  
 Enables or disables the CNC to remove the short segments  
**NO\_SHORT=0** Function disactivated  
**NO\_SHORT=1** short segment are removed by CNC. This facilitates the machining of complex contours  
**NO\_SHORT=2** Only Warning message is displayed if the short segment is worked
- 25.17.2.36 USE\_G60**  
 If the value is >0, enabled default mode G60 and not G61
- 25.17.2.37 TIME\_OUT\_CMD**  
 TimeOut Commands invoked on CNC. Value in Ms (default 5000)
- 25.17.2.38 TIME\_OUT\_M**  
 TimeOut M invoked on CNC.. Value in Ms (default 5000)
- 25.17.2.39 G62\_TO\_G40**  
 If it is set to 1 (YES) will be add a **G62** After **G40** (end tool offset).  
 This allows to empty the movements buffer
- 25.17.2.40 LIMIT\_G41G42**  
 If it is set to 1 (YES) the previous limits, or simulation limits will be check only in the **G41** or **G42** phase, and not in **G40** phase (center of tool).  
**WARNING**  
 In this case, could be that the center of tools is inside the machine limits, and the external of tools is outside of machine limits
- 25.17.2.41 INVERT\_G2G3**  
 If it is set to 1 (YES) the **G2** (CW circular interpolation) is inverted with **G3** (CCW circular interpolation) when is set the Work Plane **G18 XZ**
- 25.17.2.42 STANDARD\_IJ**  
 If it is set to 1 (YES) uses the standard convention for parameters I,J,K
- 25.17.2.43 ACC\_VMODE\_X,Y,Z,A,B,C,U,V,W**  
 Acceleration for the axis in SPEED MODE, G108.4 Function
- 25.17.2.44 ENABLE\_RFEED**  
 If ON (1) enables the events generation and display of Real Axes Feed  
 Available on **ComSynk** 3.0.0.500 or greater and **IsoVirtual** 2.5.0 or greater

- 25.17.2.45 NEW\_ORIGINS**  
 If ON (1) enables the Origins file management. The file “Zeri.val” will be renamed “Origins\_n.val” where **n** is the IsoUs process.  
 Now all Origins are separated for each process
- 25.17.2.46 USE\_G80\_CYCLES**  
 If ON (1) enables the migrations of codes:  
**G1080 → G80**  
**G1081 → G81**  
**G1082 → G82**  
**G1083 → G83**  
**G1084 → G84**  
**G1028 → G28**  
 And vice versa
- 25.17.2.47 G28\_HOME\_**  
 Defines the Home position for single Axis for the **G1028 (G28)** function  
 The unit of measure depends by system resolution (typically um).
- 25.17.2.48 DIVACC**  
 Defines the acceleration divisor for interpolator MSL.  
 Typical value 10, higher values define lower accelerations
- 25.17.2.49 AXES\_Z**  
 Defines **AXIS Z** index (depth) for canned cycles G81,82,83,84
- 25.17.2.50 AXES\_G84**  
 Defines **AXIS Tapping** index for canned cycle G84  
 Only for **INTERPOLATE MODE**
- 25.17.2.51 MODE\_G84**  
 G84 Mode  
**NORMAL (0)** for **NON INTERPOLATE AXIS** (normal Spindle)  
**INTERPOLATE (1)** for Interpolate Axis Spindle  
 The Tapping Step is calculated from **S** and **F** set
- 25.17.2.52 ROT\_G84**  
 Rotation direction for INTERPOLATE Tapping Axis  
**POSITIVE (0)**  
**NEGATIVE (1)**
- 25.17.2.53 MOLT\_G84**  
 Feed multiplier for tapping Axis G84
- 25.17.2.54 DELTA\_G83**  
 D parameter for function [G1083](#) (G83)
- 25.17.2.55 PRIORITY\_TASK1 – PRIORITY\_TASK2**  
 Set the priority for the TASK1 and TASK2. That indicate the interval time for execution task.  
 Value=0 (default) Max priority  
 Set value from 0 to 100
- 25.17.2.56 USE\_J\_M6**  
 If Yes (1) during M6 cycle is disabled PAUSE and STOP



**25.17.2.57 SH\_FILTER\_X,Y,Z,A,B,C,U,V,W**

Filter for Shift Axes

0 Disabled

Less value more filtering

From 0 to 200

## 25.18 PID PARAMETERS

The PID Parameters are used for the analogical Axes velocity control with Encoder Loop.

Usually, these Axes are controlled by +/- 10 Analog Outputs.

These Parameters are inserted by Isous configurator “Machine Parameters→Default Par PID”:



### 25.18.1.1 PID\_KP

Proportional Gain

### 25.18.1.2 PID\_KI

Integrative Gain

### 25.18.1.3 PID\_KV

Feed Forward Gain.

For a correct setting You have to use the following method:

- 1) Set to ZERO (0) the PID\_KP and PID\_KI
- 2) Insert a PID\_KV value
- 3) Move the axes and check if the real position is near to target (+/- 5 %)
- 4) Insert the PID\_KP and PID\_KI

#### **WARNING**

**This operation must be did with Axis disconnected from mechanical part**

### 25.18.1.4 PID\_I\_LIMIT

Integrative Limit

### 25.18.1.5 PID\_DIV

PID parameters Magnitude. Increase this parameter for Increase the PID parameter resolution:

Ex:     PID\_DIV=10     PID\_KP=1  
          It Is the same  
          PID\_DIV=100    PID\_KP=10

### 25.18.1.6 PID\_SERVO

Maximum following error (micron).

If the Axis exceeds this value, an alarm is invoked

(must be exceeds this value for a PID\_TIME\_SERVO time)

### 25.18.1.7 PID\_TIME\_SERVO

If the Axis exceeds the PID\_SERVO for a time lower of PID\_TIME\_SERVO (Millisecond)

The ERROR isn't invoked

### 25.18.1.8 PID\_DIR

Analog Outputs Direction (0 or 1)

Set this parameter for tuning the Axis direction with Analog Output

#### **WARNING**

**For change the Axis direction (ex: CW in CCW) is necessary Change this Parameter and also change the SIGN of MSOF parameter (ex: 5000 to -5000)**

### 25.18.1.9 PID\_OFFS\_ANA

Reset the analog output Offset.

With all PID parameters (KP,KI) set to ZERO, set this parameter until the axis is stationary (when it is enabled)

## 25.19 SPINDLE PARAMETERS

Parameters for SPINDLE

### 25.19.1.1 SPEEDMAXSPINDLE

Max rpm for SPINDLE when the analog output is 10V

### 25.19.1.2 ANALOG\_BIT\_RES

Analog resolution for the set Channel (see [Chap. 12.8](#))

### 25.19.1.3 SPEED\_ANALOG\_CH

Analog Channel for SPINDLE (see [Chap. 12.8](#))

### 25.19.1.4 ENABLE\_OE\_SPEED

Manage the override for spindle

<i>DISABLE</i>	No Override
<i>EXTERNAL</i>	External Override managed by VTB application
<i>INTERNAL VIRTUAL</i>	Enable the virtual override by Plugin <b>USSPINDEMANAGER (IsoUs)</b>

### 25.19.1.5 SPEED\_OW\_MIN

Minimum value in percentage for override refer to current SPEED set (0-100%)

### 25.19.1.6 SPEED\_OW\_MAX

Maximum value in percentage for override refer to current SPEED set (0-100%)

## 25.20 EGEAR PARAMETERS

### 25.20.1.1 EGEAR\_KEM

Multiplier for adapt feed **MASTER - SLAVE**

### 25.20.1.2 EGEAR\_KED

Divisor for adapt feed **MASTER – SLAVE**

### 25.20.1.3 EGEAR\_ACC

Acceleration of **LINK MASTER – SLAVE** (um/TAU)

#### Example

Axis **MASTER CONVEYOR** controlled by motor with **ENCODER 1000** p/r (the hardware will multiply the pulses x 4), axis **X SLAVE** brushless interpolated motor.

Space **MASTER** each encoder round = 100 mm.

Link **SLAVE** in 500 msec (0,5 sec)

**TAU**=2 Msec

**EGEAR\_KEM** =100000 um

**EGEAR\_KED** = 4000 i/g

**EGEAR\_ACC** = 100000/(500/TAU) = 100000/250=400

## 25.21 Peripheral speed parameters

### 25.21.1.1 CENTRE\_X\_R1

X axis position of rotation centre for first rotational axis [um]

### 25.21.1.2 CENTRE\_Y\_R1

Y axis position of rotation centre for first rotational axis [um]

### 25.21.1.3 CENTRE\_Z\_R1

Z axis position of rotation centre for first rotational axis [um]

### 25.21.1.4 CENTRE\_X\_R2

X axis position of rotation centre for second rotational axis [um]

### 25.21.1.5 CENTRE\_Z\_R2

Y axis position of rotation centre for second rotational axis [um]

### 25.21.1.6 CENTRE\_Z\_R2

Z axis position of rotation centre for second rotational axis [um]

For any rotational axis, only two positions are mandatory to define the rotation centre.

Referring to the example in the G108.12 instructions (see [Cap.25.7.5](#)) considering that we have Y as rotation axis, only X and Z positions are needed to define it.

## Index

2.1	BLOCK .....	3
2.2	LINE NUMBER OR BLOCK NUMBER .....	3
2.3	PROGRAM RUNNING .....	3
2.4	AXIS NAME .....	3
2.5	HOMING .....	3
2.6	WORK ORIGIN .....	3
2.7	WORK OFFSET .....	4
2.8	HEADS.....	4
2.9	MODAL FUNCTIONS .....	4
2.10	RECOGNIZED CODES.....	4
2.11	NUMERIC VALUES SETTING .....	4
2.12	PROGRAM REMARKS .....	4
3.1	RECOGNIZED G CODES .....	5
4	OTHERS RECOGNIZED CODES .....	8
4.1	PROGRAM FLOW INSTRUCTIONS .....	10
4.2	MULTI TASK INSTRUCTIONS .....	10
4.3	GENERIC INSTRUCTIONS .....	11
4.4	MATH AND LOGICAL OPERATORS .....	12
4.5	MATH FUNCTIONS.....	13
4.6	VARIABLES AND CONSTANTS.....	14
4.7	PREDEFINED VARIABLES.....	14
4.8	USFORMS INSTRUCTIONS .....	15
4.9	EXTENDED INSTRUCTIONS EXD .....	16
4.10	COMPILATOR SWITCH AND DIRECTIVE .....	17
4.11	INSTRUCTIONS FOR REMOTE CONTROLS.....	18
4.12	INSTRUCTIONS FOR MULTI PROCESS CONTROL .....	19
5.1	IF-ELSE-END_IF .....	20
5.2	LOOP - END_LOOP.....	20
	FOR – NEXT – BREAK - CONTINUE .....	21
	WHILE – END_WHILE – BREAK - CONTINUE.....	22
5.3	GOTO .....	23
5.4	GOSUB – RETURN.....	23
5.5	LABEL.....	24
5.6	END_PROGRAM .....	24
5.7	WAIT_INPUT .....	24

5.8	TWAIT_INPUT .....	25
5.9	ERROR.....	26
5.10	RESUME_T .....	26
5.11	SAVE_T.....	26
5.12	SET_TABPAR .....	26
5.13	SELECT – CASE - END_SELECT.....	27
5.14	IF RUN.....	28
5.15	IF NOTRUN .....	28
5.16	USEFORM.....	28
6.1	SDO_DL.....	29
6.2	SDO_UL.....	29
6.3	GET .....	29
6.4	READ_PARMAC .....	30
6.5	WRITE_PARMAC .....	30
6.6	OPT .....	30
6.7	PAUSE_MODE .....	31
6.8	FILTER_MODE.....	31
6.9	IMPORT.....	31
6.10	END_IMPORT .....	32
6.11	STOP_MODE .....	33
6.12	DEBUG_INFO.....	33
7.1	LIB.HMESSAGE .....	34
8.1	EXD.STL_LOAD .....	35
8.2	EXD.READ_TOOLPAR .....	39
8.3	EXD.READ_HEADPAR.....	39
8.4	EXD.WRITE_TOOLPAR .....	39
8.5	EXD.WRITE_HEADPAR .....	40
8.6	EXD.LOAD_LAST .....	40
8.7	EXD.SAVE_LAST .....	40
8.8	EXD.RESET_LAST .....	40
8.9	EXD.SET_OUT .....	41
8.10	EXD.READ_OUT.....	41
8.11	EXD.READ_INP .....	41
8.12	EXD.WRITE_USER.....	41
8.13	EXD.READ_USER .....	42
8.14	EXD.READ_DEMAND .....	42
8.15	EXD.READ_REAL.....	42

8.16	EXD.MASK.....	43
8.17	EXD.WRITE_BIT .....	43
8.18	EXD.READ_BIT.....	43
8.19	EXD.PXV_ALL_DETECTORS .....	44
8.20	EXD.PXV_SINGLE_DETECTOR.....	44
8.21	EXD.PXV_READ_PROBE.....	45
8.22	EXD.PXV_RESET_PROBE .....	45
	EXD.PXV_SET_DETECTOR.....	45
8.23	EXD.PXV_SAVE_IMAGE .....	46
8.24	EXD.PXV_GET_IMAGE .....	46
8.25	EXD.PXV_SET_JOB.....	46
8.26	EXD.RUN_SCRIPT.....	47
1)	EXD.OPEN_DLL.....	50
2)	EXD.CALL_DLL .....	52
3)	EXD.CLOSE_DLL.....	52
4)	EXD.SYNK_DLL .....	52
5)	EXD.STL_SETVIS .....	53
6)	EXD.STL_READVIS .....	53
7)	EXD.STL_SETVISIDX.....	53
8)	EXD.STL_READVISIDX.....	54
9.1	LIB.MESSAGE.....	69
9.2	LIB.SHOWFORM .....	70
9.3	LIB.CLOSEFORM .....	70
9.4	LIB.FORMPROP .....	70
9.5	LIB.FORMTEXT .....	73
9.6	LIB.ADDLABEL .....	73
9.7	LIB.LABELPROP.....	73
9.8	LIB.LABELTEXT.....	74
9.9	LIB.LABELPRINT.....	75
9.10	LIB.LABELF .....	75
9.11	LIB.ADDBUTTON .....	75
9.12	LIB.BUTTONPROP.....	76
9.13	LIB.BUTTONTEXT.....	78
9.14	LIB.BUTTONPRINT .....	78
9.15	LIB.BUTTONF.....	79
9.16	LIB.ADDINPUT.....	79
9.17	LIB.INPUTPROP .....	79



9.18	LIB.INPUTSETVALUE .....	80
9.19	LIB.ADDITEXT .....	81
9.20	LIB.ITEXTPROP .....	81
9.21	LIB.ITEXTSETVALUE .....	82
9.22	LIB.ADDCHECK .....	82
9.23	LIB.CHECKPROP .....	82
9.24	LIB.CHECKSETVALUE .....	83
9.25	LIB.CHECKTEXT .....	83
9.26	LIB.ADDCOMBO .....	84
9.27	LIB.COMBOPROP .....	84
9.28	LIB.COMBOSETVALUE .....	85
9.29	LIB.COMBOITEM .....	85
9.30	LIB.ADDSLIDER .....	86
9.31	LIB.SLIDERPROP .....	86
9.32	LIB.SLIDERSETVALUE .....	87
9.33	LIB.GETVAR .....	88
9.34	LIB.SETVAR .....	88
9.35	LIB.DEBUG .....	88
9.36	COLOR TABLE .....	89
10.1	IFDEF .....	91
10.2	ELSEDEF .....	91
10.3	ENDIFDEF .....	91
10.4	NOAXESREADY .....	92
10.5	ONERROR .....	92
10.6	ONSTOP .....	92
10.7	ENDON .....	92
10.8	USET .....	92
10.9	USEH .....	92
11.1	SIN .....	93
11.2	COS .....	93
11.3	LOG .....	93
11.4	EXP .....	93
11.5	INT .....	93
11.6	FIX .....	94
11.7	ABS .....	94
11.8	DRG .....	94
11.9	RAD .....	94

11.10	SQR .....	94
11.11	TAN.....	94
11.12	ATAN.....	95
11.13	ASIN .....	95
11.14	ACOS .....	95
I.	ISTRUZIONI PER IL CONTROLLO MULTIPROCESSO .....	96
12.1	CNC.LOAD .....	97
12.2	CNC.RUN .....	97
12.3	CNC.PREVIEW .....	97
12.4	CNC.STOP .....	98
12.5	CNC.PAUSE .....	98
12.6	CNC.STATUS .....	98
12.7	CNC.STATUSBIT .....	99
12.8	CNC.INFO .....	99
12.9	CNC.AXIS.....	99
12.10	CNC.GROUP .....	100
12.11	CNC.READVARADDR .....	100
12.12	CNC.READVARNAME .....	101
12.13	CNC.WRITEVARADDR.....	101
12.14	CNC.WRITEVARNAME .....	101
12.15	CNC.READPARMAC .....	101
12.16	CNC.WRITEPARMAC .....	101
12.17	CNC.ENABLEAXIS .....	102
12.18	CNC.HOMEAXIS .....	102
12.19	CNC.READGENERIC .....	102
12.20	CNC.WRITEGENERIC.....	102
13.1	REMOTE.LOAD .....	104
13.2	REMOTE.RUN .....	104
13.3	REMOTE.STOP .....	104
13.4	REMOTE.PAUSE .....	105
13.5	REMOTE.STATUS .....	105
13.6	REMOTE.MOVE .....	105
13.7	REMOTE.INFO .....	106
13.8	REMOTE.AXIS.....	106
13.9	REMOTE.GROUP .....	107
13.10	REMOTE.READISOVAR .....	107
13.11	REMOTE.READVARNAME .....	107

13.12	REMOTE.WRITEISOVAR .....	108
13.13	REMOTE.WRITENAMEVAR .....	108
13.14	REMOTE.READCNVAR .....	108
13.15	REMOTE.WRITECNVAR .....	109
13.16	REMOTE.READINPUT .....	109
13.17	REMOTE.READOUTPUT .....	109
13.18	REMOTE.WRITEOUTPUT .....	110
15.1	ROUND BRACKETS ( ) .....	113
15.2	ISO EXPRESSIONS AND SQUARE BRACKETS [ ] .....	113
15.3	VARIABLE TEST .....	113
15.4	BIT CONTROL .....	114
16.1	NUMERIC CONSTANTS .....	114
16.2	GENERIC VARIABLES "\$" .....	114
16.3	VARIABLES FOR ADDRESS .....	115
16.4	VARIABLES FOR POINTER .....	115
16.5	DATA STRUCTURES .....	115
16.6	AXIS POSITION VARIABLES .....	116
16.7	DIGITAL INPUT/OUTPUT VARIABLES .....	116
16.8	TIMER VARIABLES .....	117
16.9	TOOL TABLE VARIABLES .....	118
16.10	HEAD TABLE VARIABLES .....	119
16.11	AXIS COUNTER VARIABLES .....	119
17	LIMIT AXIS VARIABLES .....	120
18	PREVIEW PARAMETERS .....	121
18.1	GLOBAL VARIABLE .....	126
18.2	M FUNCTION VARIABLES (FOR CN) .....	126
18.3	SPECIAL PARAMETERS VARIABLES .....	126
18.4	WORK ORIGIN AND OFFSET VARIABLES .....	129
18.5	USER GENERIC VARIABLES .....	129
18.6	ARRAY VARIABLES - DIM .....	129
18.7	MARKER VARIABLES .....	130
18.8	VARIABLE FOR ANALOG SPINDLE OUTPUT .....	131
18.9	MACRO AND GCODE PARAMETERS MANAGEMENT .....	132
20	PA-PD(N,PAR)ESPR SET ABSOLUTE POSITION .....	133
21	PF(N)ESPR SET POSITIONER FEED .....	133
22	PS(N) STOP POSITIONER .....	133
23	_PM(N,PAR) READ STATUS POSITIONER .....	133

<b>24.1</b>	<b>DEFINITION OF AXIS POSITIONS</b> .....	<b>135</b>
24.1.1	<i>Axis definition for Channel Address</i> .....	135
24.1.2	<i>G90 – PROGRAMMING WITH ABSOLUTE POSITIONS</i> .....	136
24.1.3	<i>G91 - PROGRAMMING WITH INCREMENTAL POSITIONS</i> .....	136
24.1.4	<i>Definition of absolute and incremental positions</i> .....	137
<b>24.2</b>	<b>WORK ORIGIN</b> .....	<b>137</b>
24.2.1	<i>Work origin By INDEX</i> .....	137
24.2.2	<i>G94 – Work origin at position defined with parameter</i> .....	139
24.2.3	<i>G94.n – Save work orgini at Index</i> .....	140
24.2.4	<i>G54, G55, G56, G57, G58, G59 - Work origin from memory file</i> .....	140
24.2.5	<i>G92 – Work origin in current axis position</i> .....	142
24.2.6	<i>G82 – Work origin in current axis position with sensor offset</i> .....	142
24.2.7	<i>G98 – G53 - Suspend work origin</i> .....	142
24.2.8	<i>G99 – Restore work origin</i> .....	142
24.2.9	<i>G940 MOVE axes excluding WORK ORIGIN only in the actual block</i> .....	144
24.2.10	<i>USER_ZERO – Index of WORK ORIGIN LIST</i> .....	144
<b>24.3</b>	<b>WORK OFFSET</b> .....	<b>145</b>
24.3.1	<i>G93 - Work offset at position defined with parameter</i> .....	145
24.3.2	<i>G95 - Work offset in current axis position</i> .....	145
24.3.3	<i>G85 - Work offset in current axis position with sensor offset</i> .....	145
24.3.4	<i>G86 - Hardware preset axis on module 360 degrees</i> .....	146
24.3.5	<i>G96 - Suspend work offset</i> .....	146
24.3.6	<i>G97 - Restore work origin</i> .....	146
24.3.7	<i>USER_OFFSET - Index of WORK OFFSET LIST</i> .....	146
<b>24.4</b>	<b>WORK HEAD SELECTION – H FUNCTION</b> .....	<b>148</b>
24.4.1	<i>Hn – Select head</i> .....	148
24.4.2	<i>G87 – Suspend head offset</i> .....	148
24.4.3	<i>G88 – Restore head offset</i> .....	148
<b>24.5</b>	<b>ROTATIVE AXIS</b> .....	<b>149</b>
24.5.1	<i>G36 – Rotative axis definition</i> .....	149
<b>24.6</b>	<b>HARDWARE PRESET OF AXIS</b> .....	<b>150</b>
24.6.1	<i>G89 – Hardware preset of axis position</i> .....	150
<b>24.7</b>	<b>HARDWARE PRESET OF AXIS</b> .....	<b>150</b>
24.7.1	<i>G84 – Preset Axes counters</i> .....	150
24.7.2	<i>G83 – Preset CPU 1 counters</i> .....	150
<b>24.8</b>	<b>CANNED CYCLES</b> .....	<b>151</b>
24.8.1	<i>G1080 – Disabled Canned Cycles</i> .....	151
24.8.2	<i>G1081 – Drilling Cycle</i> .....	151
24.8.3	<i>G1082 – Drilling Cycle</i> .....	152
24.8.4	<i>G1083 – Drilling Cycle</i> .....	153
24.8.5	<i>G1084 – Tapping Cycle</i> .....	154
<b>24.9</b>	<b>SELECT WORK PLANE</b> .....	<b>155</b>
24.9.1	<i>G17 – Select work plane on X-Y</i> .....	155
24.9.2	<i>G18 - Select work plane on X-Z</i> .....	155
24.9.3	<i>G18.1 - Select work plane on X-Z but not in PREVIEW</i> .....	155
24.9.4	<i>G19 - Select work plane on Y-Z</i> .....	155

24.9.5	<i>G19.1 - Select work plane on Y-Z but not in PREVIEW</i> .....	155
24.9.6	<i>G70 - Select work plane on axis by parameters</i> .....	156
<b>24.10</b>	<b>START SEARCH OF HOME POSITION</b> .....	<b>157</b>
24.10.1	<i>G71 – Start Homing cycle</i> .....	157
24.10.2	<i>G71.1 Enable Axis</i> .....	157
24.10.3	<i>G71.2 Disable Axis</i> .....	157
<b>24.11</b>	<b>AXIS MOVEMENT FUNCTIONS</b> .....	<b>158</b>
24.11.1	<i>G0 – Rapid positioning</i> .....	158
24.11.2	<i>G0.1 – Rapid positioning with private Acceleration</i> .....	158
24.11.3	<i>G0.2 – Rapid positioning for “Transported Axes”</i> .....	159
24.11.4	<i>G1 – Linear interpolation a programmed F speed</i> .....	160
24.11.5	<i>G1.1 – G1-G2-G3 Suspension and Set G0</i> .....	160
24.11.6	<i>G1.2 – Resume Gx saved with G1.1</i> .....	160
24.11.7	<i>G2/G3 - Circular interpolation a programmed F speed</i> .....	161
24.11.8	<i>G30 - Enable automatic insert of fillet on edges</i> .....	162
G31 – SUSPEND OF AUTOMATIC INSERT OF FILLET .....		163
24.11.9	<i>G32 - Restore of automatic insert of fillet</i> .....	163
24.11.10	<i>G33 - Enable automatic insert of bevel on edges</i> .....	164
24.11.11	<i>G34 - Suspend of automatic insert of bevel</i> .....	165
24.11.12	<i>G35- Restore of automatic insert of bevel</i> .....	165
24.11.13	<i>G102 – Start searching sensor position</i> .....	166
24.11.14	<i>G102.1 – Acquisition from PxVision System</i> .....	167
<b>24.12</b>	<b>PROGRAMMING AXIS INTERPOLATION SPEED</b> .....	<b>173</b>
24.12.1	<i>F – Speed of axis interpolation</i> .....	173
24.12.2	<i>ARC speed auto-reduction</i> .....	173
<b>24.13</b>	<b>WORK PLANE TRANSFORMATION</b> .....	<b>174</b>
24.13.1	<i>G120 – Vertical mirror</i> .....	174
24.13.2	<i>G121 – Disable vertical mirror</i> .....	174
24.13.3	<i>G24 – Horizontal mirror</i> .....	175
24.13.4	<i>G25 – Disable horizontal mirror</i> .....	175
24.13.5	<i>G22 – Echange axis of work plane</i> .....	175
24.13.6	<i>G23 – Restore axis of work plane</i> .....	176
24.13.7	<i>G26 – Exchange axis by parameter</i> .....	176
24.13.8	<i>G27 – Suspend G26</i> .....	176
24.13.9	<i>G28 – Restore G26</i> .....	176
24.13.10	<i>G1028 – Return to Home</i> .....	177
24.13.11	<i>G51 – Suspend work plane rotation</i> .....	177
24.13.12	<i>G52 – Restore work plane rotation</i> .....	177
24.13.13	<i>G50 - Work plane rotation</i> .....	178
24.13.14	<i>G1050 – Disable Scaling</i> .....	179
24.13.15	<i>G1051 – Enable Scaling</i> .....	179
24.13.16	<i>G103 – Set RTCP parameters</i> .....	181
24.13.17	<i>G104 – Enable/restore RTCP</i> .....	181
24.13.18	<i>G104.1 – Enable/restore RTCP</i> .....	181
24.13.19	<i>G105 – Disable RTCP</i> .....	181
<b>25</b>	<b>TOOL RADIUS COMPENSATION</b> .....	<b>182</b>
25.1.1	<i>G41/G42 – Enable left/right radius tool compensation</i> .....	182
25.1.2	<i>G40 – Disable radius tool compensation</i> .....	182
25.1.3	<i>D – Tool diameter</i> .....	183
25.1.4	<i>G47 – Set tool entry mode</i> .....	184

<b>25.2</b>	<b>TOOL LENGHT COMPENSATION .....</b>	<b>185</b>
25.2.1	<i>G43 – Enable tool length compensation from parameter .....</i>	185
25.2.2	<i>G44 – Disable tool length compensation G43 .....</i>	186
25.2.3	<i>G44.1 (2) – Suspend/Resume G43 .....</i>	186
25.2.4	<i>G45 – Enable tool length compensation from tool table T .....</i>	186
25.2.5	<i>G46 – – Disable tool length compensation G45 .....</i>	187
<b>25.3</b>	<b>INTERPOLATION MODES .....</b>	<b>188</b>
25.3.1	<i>G60 – Enable FAST interpolation without stop on segments .....</i>	188
25.3.2	<i>G61 – Enable interpolation with stop on segments .....</i>	188
25.3.3	<i>G62 – Wait for stop axis .....</i>	188
25.3.4	<i>G63 – Interpolation outside work plane (PX_MOVETO) .....</i>	189
25.3.5	<i>G64 – Interpolation on work plane (default) .....</i>	189
25.3.6	<i>G65 – Enable 3D interpolation PX_MOVETO with calculated stop on edge by parameters .....</i>	190
25.3.7	<i>G75 – Enable G64 for movement inside the work plane , G65 for movement outside the work plane 190</i>	
25.3.8	<i>G66 – AFC – Adaptive Feed Control .....</i>	191
25.3.9	<i>G66 X-100 – NEW AFC – Adaptive Feed Control .....</i>	192
25.3.10	<i>G67 – Px_Moveto for movement outside plane and Px_Lineto for inside one .....</i>	196
25.3.11	<i>G68 – Always using of PX_LINETO in G1 “TRANSPORTED AXIS” (with possibility to combine with PX_MOVETO .....</i>	196
25.3.12	<i>G69 – LHK – Buffer look ahead depth .....</i>	197
<b>25.4</b>	<b>ISOUS FILTERS .....</b>	<b>198</b>
25.4.1	<i>G72 – N.U.R.B.S (Non Uniform Rational Bspline) (2D 3D) .....</i>	199
25.4.2	<i>G73 – NOISE (2D-3D) .....</i>	202
25.4.3	<i>G74 – RLS Remove Len Segment (2D 3D) .....</i>	204
25.4.4	<i>G106 – Smoothing (2D 3D) .....</i>	205
<b>25.5</b>	<b>INTERRUPT MACRO .....</b>	<b>208</b>
25.5.1	<i>G107 – Management Interrupt Macro .....</i>	208
<b>25.6</b>	<b>EMERGENCY MACRO M60000 IN STOP MODE .....</b>	<b>211</b>
<b>25.7</b>	<b>G108 MANAGEMENT SPECIAL AXES .....</b>	<b>212</b>
25.7.1	<i>G108.0 G108.1 G108.2 G108.3 - Master Slaves Axes .....</i>	212
25.7.2	<i>G108.4 G108.5 G108.6 SPEED MODE AXIS .....</i>	213
25.7.3	<i>G108.7 G108.8 G108.9 Physical exchange Axes .....</i>	213
25.7.4	<i>G108.10 G108.11 eGear Axes Management .....</i>	214
25.7.5	<i>G108.12 G108.13 - Peripheral speed management .....</i>	215
<b>25.8</b>	<b>VIRTUAL AXIS .....</b>	<b>216</b>
25.8.1	<i>G100 – Comando sincrono per asse virtuale .....</i>	216
<b>25.9</b>	<b>OTHER GENERIC G FUNCTIONS .....</b>	<b>217</b>
25.9.1	<i>G4 – Timed pause .....</i>	217
25.9.2	<i>G4.1 – Time Add on Calc Time .....</i>	217
25.9.3	<i>G10 – Enable external OVERRIDE potentiometer .....</i>	217
25.9.4	<i>G11 – Disable external OVERRIDE potentiometer .....</i>	217
25.9.5	<i>G101 – Axis Stop command .....</i>	219
25.9.6	<i>G80 – Forced pause by code .....</i>	219
25.9.7	<i>G81 – Management secondary axes LIMITS .....</i>	220
25.9.8	<i>G20 – Axes Values in Inch .....</i>	220
25.9.9	<i>G21 – Axes Values in Millimeters .....</i>	220

<b>25.10</b>	<b>VARIABLE MANAGEMENT FUNCTIONS .....</b>	<b>221</b>
25.10.1	<i>LOAD_VAR – load a variables file in current list .....</i>	221
25.10.2	<i>GET_VAR – Read a value from the loaded list and store it in a variable .....</i>	221
25.10.3	<i>WRITE_VAR – Write a value in the loaded list getting it from a variable .....</i>	222
25.10.4	<i>SAVE_VAR – save a variables file with current list.....</i>	222
25.10.5	<i>FILE_EXISTS – test if a file exists .....</i>	222
25.10.6	<i>ADD_VAR – Add a value to current list .....</i>	223
25.10.7	<i>REMOVE_VAR – Remove a value from current list .....</i>	223
25.10.8	<i>CLEAR_VAR – Remove all values from the current list.....</i>	223
25.10.9	<i>DIM_VAR – Size current list to a specific number of elements .....</i>	224
25.10.10	<i>COUNT_VAR – Get the number of elements in the current list.....</i>	224
<b>25.11</b>	<b>HM FUNCTIONS .....</b>	<b>225</b>
25.11.1	<i>Call of HM functions.....</i>	225
25.11.2	<i>Building of a HM function .....</i>	226
<b>25.12</b>	<b>M FUNCTIONS .....</b>	<b>227</b>
25.12.1	<i>M functions inside CN.....</i>	227
25.12.2	<i>M function inside PC.....</i>	228
<b>25.13</b>	<b>ESSENTIAL M FUNCTIONS .....</b>	<b>229</b>
25.13.1	<i>START M .....</i>	229
25.13.2	<i>END M .....</i>	229
25.13.3	<i>STOP M.....</i>	229
25.13.4	<i>PAUSE M.....</i>	229
25.13.5	<i>RESUME PAUSE M .....</i>	230
25.13.6	<i>GO BLOCK M.....</i>	230
25.13.7	<i>GO RETRACE M.....</i>	230
<b>25.14</b>	<b>DEFINING DEPTH AXIS .....</b>	<b>231</b>
25.14.1	<i>G48 Define Depth axis.....</i>	231
<b>25.15</b>	<b>MILD MODE – EDGE SMOOTHING .....</b>	<b>232</b>
25.15.1	<i>G49 MILD MODE Managing.....</i>	232
<b>25.16</b>	<b>PARALLEL TASKS .....</b>	<b>234</b>
25.16.1	<i>USTASK-ENDUSTASK .....</i>	234
25.16.2	<i>TASK.RUN .....</i>	234
25.16.3	<i>TASK.STOP .....</i>	234
25.16.4	<i>TASK.PAUSE .....</i>	235
25.16.5	<i>TASK.READVAR .....</i>	235
25.16.6	<i>TASK.WRITEVAR.....</i>	235
25.16.7	<i>TASK.STATUS .....</i>	235
25.16.8	<i>TASK.LOADCMD.....</i>	236
25.16.9	<i>TASK.PRIORITY.....</i>	236
<b>25.17</b>	<b>MAIN MACHINE PARAMETERS.....</b>	<b>237</b>
25.17.1	<i>Generic parameters.....</i>	237
25.17.2	<i>Axis parameters.....</i>	240
<b>25.18</b>	<b>PID PARAMETERS .....</b>	<b>250</b>
<b>25.19</b>	<b>SPINDLE PARAMETERS.....</b>	<b>251</b>
<b>25.20</b>	<b>EGEAR PARAMETERS .....</b>	<b>252</b>

**25.21 PERIPHERAL SPEED PARAMETERS .....253**