

**IsoUs – Ultimate Step  
Framework for .NET**

[www.promax.it](http://www.promax.it)



**PROMAX**

**Motion  
&  
Control**

The contained information in this handbook are only informative and they can being change without warning and they must not being understandings with some engagement from Promax srl. Promax srl does not assume responsibility or obligates for errors or inaccuracies that can be found in this handbook. Except how much granted from the license, no part of this publication can be reproduced, saved in a recording system or transmitted in whatever form or with any means, electronic, mechanical or recording system or otherwise without Promax srl authorization.

Any reference to names of society or products have only demonstrative scope and it does not allude to some real organization.

Rev. 1.3.0 © Promax srl

## 1 PREFAZIONE

This manual, describes the IsoUs Framework for .NET application.  
The framework is contained in the **UsWork.dll**.

### 1.1 Before Start

The use of UsWork.DLL provides that there is the configuration file "**IsoUs.cfg**" already installed in the same folder.  
The configuration file contains all the informations necessary to component for the proper functioning and adaptation to the CNC in use.

In the same folder UsWork.DLL must be the following DLL:

**Compiler.DLL**

**ComSynk.DLL**

These are directly allocated by the component itself and therefore only require their presence.

The component is loaded in the development environment like all other components of the framework running the standard usage.

**First you must assign the address of the property SetIsoUsCnC CN (usually 0)**

```
UsWork.IsoUs MyUsIso = new UsWork.IsoUs();
```

```
// Run Application
private void StartIsoUs()
{
    SetIsoUsCnC(CnCIndex, StartupPath, "IsoUs.cfg");
}
```

## 2 Events

### 2.1 *AbsRelChanged*

Event occurs to change the state of NC by absolute or relative. Generated as a result of an instruction manual functions G90 or G91.

**False** indicate Absolute Motion

**True** indicate Relative Motion

Example c#:

```
private void AbsRelChanged(object sender, UsWork.BoolArgs e)
{
    if (e.Value == false)
        ... Absolute
    else
        ... Relative
}
```

### 2.2 *AcquisitionExecuteChanged*

Event occurs to change the bit of a statusword “**probe acquisition**”.

Boolean value that indicates the status of acquisition

**True** acquisition terminated

**False** acquisition in RUN

Example c#:

```
private void AcqExecute(object sender, Boolean e)
{
    if(e.Value==True) // Acq Terminated
    else // Acq Run
}
```

### 2.3 *AllAxesReadyChanged*

Event occurs to change the Axes Status (homing or Enable)

Boolean value that indicates the axes status

**True** All Axes Ready (Homing e Enable)

**False** One or more Axis not ready (Homing e Enable)

### 2.4 *AxesDemandValueChanged*

Event occurs to change the demand position of Axes

**FormatRealValue** contains an array of string formatted values of the absolute reference positions axes to machine zero

**FormatSpaceErr** contains an array of string formatted values of the axes of space errors (difference between the theoretical position and current position)

**Format** Contains an array of string formatted values of the axes positions These are referred to the axis and Zero Offset

**RealValue** contains an array of Int32 values of the coordinates axes to machine zero absolute reference

**Value** contains an array of Int32 values of the positions These are referred to the axis and Zero Offset

**Mask** Int32 Bit mapped that indicates which axis has changed positions Bit 0 Axis X - Bit 1 Axis Y etc. ..

The bit is not enabled, the event did not generate

Example c#:

```
private void AxesDemandValueChanged(object sender, UsWork.AxesValueArg e)
{
    Int32 P = 1;
    for (int n = 0; n < e.FormatValue.Length; n++)
    {
        if ((Mask & P) == P) // value changed
        {
            MyQuoteAbs[n].Text = FormatRealValue[n];
            MyQuoteRel[n].Text = FormatValue[n];
        }
        P <<= 1;
    }
}
```

## 2.5 AxesMoveChanged

Event occurs to change the Axes movement

**True** Axis movement

**False** Axis stop

Example c#:

```
private void MoveChanged(object sender, NsWork.BoolArgs e)
{
    if (e.Value == false)
        axis stop
    else
        axis movement
}
```

## 2.6 AxesOffsetValueChanged

Event occurs to change the offset axes following a G93 statement

**Format** containing a value formatted string

**Index** index of the axis

**Value** containing the integer value of the offset axis

Example c#:

```
private void AxesOffsetValueChanged(object sender, UsWork.OffsetArgs e)
{
    labelval.Text = e.Format;
    Int32 Value = e.Value;
    Double ValZero = e.Value;
    ValZero /= MyUsIso.UsAxesValue.AxesResolution;
}
```

## 2.7 AxesOriginChanged

Event occurs to change the axis zeros following a G94 statement

**Format** String position formatted value

**Index** Axis index

**Value** Int32 offset axis

Example c#:

```
private void AxesOriginChanged (object sender, UsWork.OffsetArgs e)
{
    labelval.Text = e.Format;
    Int32 Value = e.Value;
    Double ValZero = e.Value;
    ValZero /= MyUsIso.UsAxesValue.AxesResolution;
}
```

## 2.8 *AxesDemandValueChanged*

Event occurs to change the real position of Axes

<b>FormatRealValue</b>	contains an array of string formatted values of the absolute reference positions axes to machine zero
<b>FormatSpaceErr</b>	contains an array of string formatted values of the axes of space errors (difference between the theoretical position and current position)
<b>Format</b>	Contains an array of string formatted values of the axes positions These are referred to the axis and Zero Offset
<b>RealValue</b>	contains an array of Int32 values of the coordinates axes to machine zero absolute reference
<b>Value</b>	contains an array of Int32 values of the positions These are referred to the axis and Zero Offset
<b>Mask</b>	Int32 Bit mapped that indicates which axis has changed positions Bit 0 Axis X - Bit 1 Axis Y etc. .. The bit is not enabled, the event did not generate

## 2.9 *AxisEnabledChanged*

Event occurs to change the enabled status of the driver of an axis

Value contains the status

**True** Axis enabled

**False** Axis disabled

**IndexAxis** contains the index of axis (0-1-2) eg X, Y, Z

Example c#:

```
private void AxisEnabledChanged (object sender, UsWork.HomingEnableArgs e)
{
    if (e.Value == false)
        e.IndexAxis... //Disable
    else
        e.IndexAxis... // Enable
}
```

## 2.10 *AxisHomeChanged*

Event that occurs when an axis has finished homing function

Value contains the status of Home

**True** Axis homing OK

**False** Axis not homing

**IndexAxis** contains the index of the axis (0-1-2) eg X, Y, Z

Example c#:

```
private void AxisHomeChanged (object sender, UsWork.HomingEnableArgs e)
{
    if (e.Value == false)
        e.IndexAxis... // no homing
    else
        e.IndexAxis... // homing
}
```

### 2.11 PositDemandValueChanged

Event occurs to change the real position of POSITIONER Axes

**Value** contains an array of Int32 values of the positions

**Mask** Int32 Bit mapped that indicates which axis has changed positions  
Bit 0 Axis X - Bit 1 Axis Y etc. ..

The bit is not enabled, the event did not generate

Example c#:

```
private void PositDemandValueChanged(object sender, UsWork.PositiValueArg e)
{
    Int32 P = 1;
    for (int n = 0; n < e.Value.Length; n++)
    {
        if ((Mask & P) == P) // Changed
        {
            MyQuoteAbs[n].Text = Value[n];
        }
        P <<= 1;
    }
}
```

### 2.12 PosHomeChanged

Event that occurs when an POSITIONER has finished homing function

Value contains the status of Home

**True** Axis homing OK

**False** Axis not homing

**PosIndex** contains the index of the POSITIONER (0-1-2)

Example c#:

```
private void PosHomeChanged (object sender, UsWork. PosBoolArgs e)
{
    if (e.Value == false)
        e.PosIndex... // no homing
    else
        e. PosIndex... // homing
}
```

### 2.13 PosEnabledChanged

Event occurs to change the enabled status of the driver of an POSITIONER

Value contains the status

**True** Axis enabled

**False** Axis disabled

**PosIndex** contains the index of POSITIONER (0-1-2)

Esempio c#:

```
private void PosEnabledChanged (object sender, UsWork. PosHomingEnableArgs e)
{
    if (e.Value == false)
        e.PosIndex... // disabled
    else
        e. PosIndex... // enabled
}
```

### 2.14 PosMoveChanged

Event occurs to change the POSITIONER movement

**True** movement

**False** stop

Example c#:

```
private void PosMoveChanged(object sender, UsWork.PosBoolArgs e)
{
    if (e.Value == false)
        e.PosIndex // Stop
    else
        e.PosIndex // Move
}
```

### 2.15 PosAlarmChanged

Event occurs during ALLARMA POSITIONER

**Value true** ALLARM

Example c#:

```
private void PosAlarmChanged(object sender, UsWork.PosBoolArgs e)
{
    if (e.Value == false)
        e.PosIndex // Restored Alarm
    else
        e.PosIndex // Alarm
}
```



## 2.16 DigitalInputChanged

Event occurs to change the status of a digital input.

The digital inputs enabled the generation of events must first be configured in the file `IsoUs.cfg` in the following mode:

```
<EventsData UserGeneric="" DigitalInputs=" inputn,inputn1,inputn2 etc " />
```

Where Inputn1,Inputn2 ecc. are the NC real digital inputs

Ex:

```
<EventsData UserGeneric="" DigitalInputs=" 1,5,32 " />
```

Example c#:

```
private void DigitalInputChanged(object sender, UsWork.DigitalInputArgs e)
{
    for(int n=0;n<e.DigitalInput.Length;n++)
    {
        // e.DigitalInput is a integer vector that contains the digital inputs changed
        // ex: e.DigitalInput[0]=digital input 1 changed
        // e.DigitalStato is a boolean vector that contains the state of relative input
        // e:x e.DigitalStato[0]=false Input 1 false
        // test input 1
        if(e.DigitalInput[n]==1)
        {
            if(e.DigitalStato[n]==true)
            {
                if(IsoNs.IsStatusRun==true) // if run
                    IsoNs.ProgramRun.PauseProg();
            }
        }
    }
}
```

## 2.17 EnableExtOverrideChanged

Event occurs to change the enabled status of the external potentiometer override

**True** external override enabled

**False** external override disabled

Example c#:

```
private void EnableExtOverrideChanged (object sender, UsWork.BoolArgs e)
{
    if (e.Value == false)
        ....Disable
    else
        .... Enable
}
```

## 2.18 EndImportChanged

Event occurs when the last IMPORT file is terminated

**e.FileName** NULL

**e.FileImportPath** Path file that has terminated the execution

### 2.19 ExtPauseRequestChanged

Event that occurs at the change of external input **PAUSE** program  
 The input is defined in the CN application VTB  
 True request from external **PAUSE**

Example c#:

```
private void ExtPauseRequestChanged (object sender, UsWork.BoolArgs e)
{
    if (e.Value == true)
        MyUsIso.UsGcodeRun.PauseGcode();
}
```

### 2.20 ExtRunRequestChanged

Event that occurs at the change of external input **RUN** program  
 The input is defined in the CN application VTB  
 True request from external **RUN**

Example c#:

```
private void ExtRunRequestChanged(object sender, UsWork.BoolArgs e)
{
    if (e.Value == true)
        MyUsIso.UsGcodeRun.ExecuteGcode(LineStart); // Run Prog
}
```

### 2.21 ExtStopRequestChanged

Event that occurs at the change of external input **STOP** program  
 The input is defined in the CN application VTB  
 True request from external **STOP**

Example c#:

```
private void ExtStopRequestChanged(object sender, UsWork.BoolArgs e)
{
    if (e.Value == true)
        MyUsIso.UsGcodeRun.StopGcode();
}
```

### 2.22 FeedAxesChanged

Event occurs to change the set F  
 The event is generated by F instructions or manual functions  
 Contains an integer value of F  
 Format contains a string formatted to units of measurement set

Example c#:

```
private void FeedAxesChanged(object sender, UsWork.FeedArgs e)
{
    LedFeed.Level = e.Value;
    LblFeed.Text = e.Format;
}
```

### 2.23 RealFeedAxesChanged

Event occurs to change the Real Axes Feed calculato in the CNC  
**Must be enabled the parameter ENABLE\_RFEED**  
 Contains an integer value of F  
 Format contains a string formatted to units of measurement set

Esempio c#:

```
private void RealFeedAxesChanged(object sender, UsWork.FeedArgs e)
{
    LedFeed.Level = e.Value;
    LblFeed.Text = e.Format;
}
```

### 2.24 HeadOffsetValueChanged

Event occurs to change the offset head following a **Hn** command

**Format** containing a value formatted string

**Index** index of the axis

**Value** containing the integer value of the offset axis

Example c#:

```
private void HeadOffsetValueChanged (object sender, UsWork.OffsetArgs e)
{
    labelval.Text = e.Format;
    Int32 Value = e.Value;
    Double ValZero = e.Value;
    ValZero /= MyUsIso.UsAxesValue.AxesResolution;;
}
```

### 2.25 MachineParametersUpdate

Event occurs when one or more machine parameters are changed by browser.

### 2.26 MulHandWheelChanged

Event occurs to change the multiplier value software for electronic handwheel. This event is generated even if the multiplier varies from application through VTB switch.

**Value** Int32 Contains the multiplier value

Example c#:

```
private void MulHandWheelChanged (object sender, UsWork.GenArgs e)
{
    Label1.Text=e.Value.ToString();
}
```

### 2.27 M\_CnC\_ExecuteChanged

Event that occurs at the end of a **M** function internal to the NC

**True** M in RUN

**False** M terminated

Example c#:

```
private void M_CnC_ExecuteChanged (object sender, UsWork.BoolArgs e)
{
    if(e.Value==true)
        // M START
    else
        // M terminated
}
```

### 2.28 OnCloseComRequest

Event occurs to end communication to NC

### 2.29 OverrideValueChanged

Event occurs to change the value of the Override Percentage FEED velocity axis.

**Value** Int32 analog input value (0-1023)

**PercValue** Percentage

Example c#:

```
private void OverrideValueChanged (object sender, UsWork.OverrideArgs e)
{
    LedOverride.Level = e.Value;
    LblOw.Text = e.PercValue + " %";
}
```

### 2.30 *PauseChanged*

Event occurs to change the pause state of NC  
**True** NC in pause  
**False** resume from pause

Example c#:

```
private void PauseChanged(object sender, UsWork.PauseArgs e)
{
    if (e.Value == false)
        // Resume
    else
        // PAUSE
}
```

### 2.31 *RemoveMarkLineChanged*

Event application required by simulation that enables an application to remove the marker line ISO. This event has a specific use is enabled only if the simulation with the file **Simulation.dll**. This file may take to the main interface to remove the marker line after an event **RequestMarkLineChanged**

### 2.32 *RequestMarkLineChanged*

Event application required by simulation that enables an application to mark a line in the Gcode ISO This event has a specific use is enabled only if the simulation with the file **Simulation.dll**. This file may take to mark a main interface ISO line to highlight it

### 2.33 *RunStopChanged*

Event that occurs at the change of state of the NC STOP RUN  
**True** NC in RUN  
**False** NC in STOP

Example c#:

```
private void RunStopChanged(object sender, UsWork.BoolArgs e)
{
    ProgInRun = e.Value;
    if (e.Value == false)
        // from RUN to STOP
    else
        // from STOP to RUN
}
```

### 2.34 *RunStopChangedWithType*

Event that occurs at the change of state of the NC STOP RUN with RUN type  
**True** NC in RUN  
**False** NC in STOP

Example c#:

```
private void RunStopChangedWithType (object sender, UsWork.TypeRunArgs e)
{
    // TypeRun=0 Normal Run
    // TypeRun=1 Preview Run
    // TypeRun=2 Resume from Block Run
    // TypeRun=3 Retrace Run
    // TypeRun=4 Execution Time Calc Run
}
```

### 2.35 ScriptChanged

Event that occurs at the RUN / STOP ISONS script code that is invoked when the method IsoNs.ProgramRun.ExecuteScript

**True** Script RUN

**False** Script terminated

Example c#:

```
private void ScriptChanged(object sender, UsWork.BoolArgs e)
{
    if (e.Value == false)
        .. Terminated
    else
        .. in esecuzione
}
```

### 2.36 SelectAxisJogChanged

Event occurs to change the value of the selected axis to jog.

**e.value** axis selected

0 → Axis X      1 → Axis Y      2 → Axis Z

3 → Axis A      4 → Axis B      5 → Axis C

6 → Axis U      7 → Axis V      8 → Axis W

Example c#:

```
private void SelectAxisJogChanged (object sender, UsWork.GenArgs e)
{
    Label1.Text=e.Value.ToString();
}
```

### 2.37 SpeedSpindleChanged

Event occurs to change the spindle speed in response to an instruction S from Gcode

**Value** Int32 S value

**Format** String formatted value

**PercValue** Double percentage of maxvalue ( maxvaluesetted in isous.cfg)

Example c#:

```
private void SpeedSpindleChanged(object sender, UsWork.FeedArgs e)
{
    LedSpeed.Level = e.Value;
    LblSpeed.Text = e.Format;
    LblPerc.Text=e.PercValue.ToString();
}
```

### 2.38 StartImportChanged

Event occurs when IMPORT instruction is executed

**e.FileName** Text of imported file.

**e.FileImportPath** File of imported file

### 2.39 StepModeChanged

Event occurs to change the state of NC by way of execution STEP by STEP (line by line) to the continuous play mode.

**True** Step Mode

**False** Normal mode

Example c#:

```
private void StepModeChanged(object sender, UsWork.BoolArgs e)
{
    if (e.Value == false)
        BtnStepMode.ImageIndex = 0;
    else
        BtnStepMode.ImageIndex = 1;
}
```

### 2.40 TabUtChanged

Event occurs to change the selected value of the tool table.

ISO function **Tn**

Value Int32 T number selected

Example c#:

```
private void TabUtChanged(object sender, UsWork.GenArgs e)
{
    Label1.Text=e.Value.ToString();
}
```

### 2.41 ToolDiameterChanged

Event occurs to change the settings of the tool diameter.

Created in response to an instruction of the **D** Gcode. The value is contained in an integer and represents the thousandths of a millimeter in diameter tool.

Example c#:

```
private void ToolDiameterChanged (object sender, UsWork.GenArgs e)
{
    m_ActDiam = e.Value;
}
```

### 2.42 ToolLengthChanged

Event occurs to change the tool length set by the Gcode

**Value** contains the value in thousandths of a millimeter of the tool length

Example c#:

```
private void ToolLengthChanged (object sender, UsWork.GenArgs e)
{
    m_ActLenUt=e.Value;
}
```

### 2.43 UsFatalError

If this event is allocated, IsoUs does'not manages the fatal Errors by notify the external application can get the events from Fatal Errors

```
void MyUsIso_UsFatalError(object sender, UsWork.UsFatalErr e)
{
    MessageBox.Show("ERROR CN : " + e.UsCnNumber.ToString() + "\n" + e.UsErrorMessage);
}
```

## 2.44 UsNotifyChanged

System Notify

Type:

**CNC ALARM** Alarm on CNC

**CNC WARNING** Warning on CN

**DEFINE ERROR** Defined Error by user (ERROR Gcode Function)

**GCODE ERROR** Error in Gcode

**INFORMAZIONI** Info

Example c#:

```
private void MyUsIso_UsNotifyChanged(object sender, UsWork.UsNotify e)
{
    switch(e.NotifyType)
    {
        case UsWork.IsoUs.UsNotifyType.UsCncAlarm:
            // CNC in Alarm
            MessageBox.Show("CNC ALARM : " + e.NotifyDescription);
            break;
        case UsWork.IsoUs.UsNotifyType.UsCncWarning:
            // CNC in Warning
            MessageBox.Show("CNC WARNING : " + e.NotifyDescription);
            break;
        case UsWork.IsoUs.UsNotifyType.UsGcodeDefineError:
            // Error define by User
            MessageBox.Show("CNC ERROR DEFINE BY USER : " + e.NotifyDescription);
            break;
        case UsWork.IsoUs.UsNotifyType.UsGcodeError:
            // Error in Gcode
            MessageBox.Show("ERROR IN GCODE : " + e.NotifyDescription);
            break;
        case UsWork.IsoUs.UsNotifyType.UsInfo:
            // Information
            MessageBox.Show("INFO : " + e.NotifyDescription);
            break;
    }
}
```

### 2.45 VariableUserChanged

Event that occurs at the change of a variable USER GENERIC IsoUs.cfg configured. GENERIC USER variables can be used for data exchange between NC and PC (since these are manageable by applying the CN VTB )

**Value** Int32 Array that contains the value of USER changed

**Mask** Bit mapped indicate which USER is changed

Bit 0 User configured 1

Bit 1 User configured 2 etc.

Only those with bit 1 are changed

Example c#:

```
private void VariableUserChanged(object sender, UsWork.UserGeneric e)
{
    Int32 P=1;
    for(int n=0;n<e.Value.Length;n++) // check variable changed
    {
        if((e.Mask & P)==P) // variable changed
            LblUser.Text = e.Value[n].ToString();
        P <<= 1; // shift bit
    }
}
```

### 2.46 WorkLineDemandChanged

Event occurs to change the number of demand lines running

**Value** contains an integer number of demand line running

Example c#:

```
private void WorkLineDemandChanged (object sender, UsWork.GenArgs e)
{
    Label1.Text=e.Value.ToString();
}
```

### 2.47 WorkLineRealChanged

Event occurs to change line number REAL running on CN

This line number may differ from the demand.

**Value** contains an integer number of CURRENT line running

Example c#:

```
private void WorkLineRealChanged (object sender, NsWork.GenArgs e)
{
    Label1.Text=e.Value.ToString();
}
```

### 2.48 WorkPlaneSetChanged

Event occurs to change the work plan as a result of the NC **G17 G18 G19 G70** instructions

**WorkPlaneSet** contains an array of string with the names of the two axes

Example c#:

```
private void PianoChanged(object sender, UsWork.WorkPlaneArgs e)
{
    LblPiano1.Text = e.WorkPlaneSet0;
    LblPiano2.Text = e.WorkPlaneSet0[1];
}
```



**2.49 *UsCompiler.CodeLoaded***

Event occurs when the compiled code is loaded in the IsoUs memory  
Now is ready to work

**2.50 *G43Changed***

Event occurs when the G43 changes its state

**Value**   **True** G43 Enabled  
          **False** G43 Disabled

**2.51 *Us2ndLimitsChanged***

Event occurs when the 2nd limits are changed

**Value**  
**True** 2nd Limits Activated  
**False** 2nd Limits Deactivated

**2.52 *UsDebuInfo***

Event occurs when is used by Gcode:

**DEBUG\_INFO "TEXT\$" \$VAR** with Last char of Text \$

### 3 Methods and Properties of UsWork

#### 3.1 *Double AxisValueToDoubleUs (Int32 AxisIntValue)*

Return a double value of an Integer Axis Value.  
The return value considers the Axes Resolution

#### 3.2 *Void PutNotify(String NotifyText, bool PutInPanel=false)*

Sends a notify to Notify Manager.  
Follows an event UsNotifyChanged if PutInPanel=True  
The notify is also put in the IsoUs\_x.log file

#### 3.3 *Void PutNotify(UsNotifyType NotifyType, String NotifyText, bool PutInPanel=false)*

Sends a notify to Notify Manager.  
NotifyType defines the Type:  
*UsCncAlarm*  
*UsCncWarning*  
*UsGcodeError*  
*UsGcodeDefineError*  
*UsInfo*  
Follows an event UsNotifyChanged if PutInPanel=True  
The notify is also put in the IsoUs\_x.log file

#### 3.4 *Void EndSession()*

Close all communications

#### 3.5 *Void ForceEventAxesValue()*

Force the Events  
AxesDemandValueChanged  
AxesRealValueChanged  
AxesOriginsChanged  
AxesOffsetChanged

#### 3.6 *Void SetIsoUsCnC (Int32 IndexCn, String CfgName)*

Init the CnC session  
**IndexCn** Index of CNC from 0 to 7 (multiprocess)  
**CfgName** Name of configuration file (normally "IsoUs.cfg")  
Before to call **SetIsoUsCnC** the keys that indicate the location and configuration to be loaded must be registered  
The CNC can't be connected to PC. This means the the IsoUs is in DEMO MODE.  
Read **IsoUsModeRun**. If **False** the CNC is in DEMO MODE

#### 3.7 *Bool IsoUsModeRun*

Property Read  
**True** CNC in NORMAL MODE  
**False** CNC in DEMO MODE

#### 3.8 *Int32[] GetIndexCnC*

Property Read  
Get the CnC Index setted by **SetIsoUsCnC**

### 3.9 Int32[] *WorkPlaneSet*

Property Read Write

Work plane setted

Array of Int32[2]:

Int32[0] Index of the first Axis of Work Plane

Int32[1] Index of the second Axis of Work Plane

```
Int32[] _Plane = new Int32[2];  
_Plane[0] = 0; //X  
_Plane[1] = 2; //Z  
MyUsIso.WorkPlaneSet = _Plane;
```

### 3.10 String *GetNameConfigIsoUs*

Property Read

Return the name of configuration file

### 3.11 String *GetPathIsoUs*

Property Read

Return the Path of configuration file

## 4 Classi di UsWork

### 4.1 *MyMaster*

*Do not use*

## 4.2 UsAxesHomingEnable

It contains all the methods that manage the Property **HOMING** and **ENABLE** of the axes

### 4.2.1 *bool* AllAxesRedy

Property Read

**True** All Axes Reday – Homing and Enable performed

**False** All Axes not ready

### 4.2.2 *bool* NoCheckAllAxesRedy

Property Read/Write

**True** **AllAxesRedy** return always True

### 4.2.3 *Int32[]* GetAxesHomingSequence

Property Read

Returns the axes sequence homing configured

Ex:

**AXES CONFIGURED X,Y,Z**

**Sequence configured 2,1 (0 not homing)**

**Return GetSeqHoming Int32 arrayi:**

**Int32[0]=2**

**Int32[1]=1**

**Int32[0]=0**

The first axis is Z

The second axis is Y

The third axis is X

### 4.2.4 *Void* EnableAxis(*Int32* AxisIndex, *bool* State)

Enable/Disable Axis

**AxisIndex** Index of axis

**State** **True** Enable

**False** Disable

The number of axis refers to the index of axes configured (0=X – 1=Y 2=Z etc.)

At this stage you can manage the parameter **TIMEOUTENABLE**

### 4.2.5 *Void* PresetAbsoluteEncoder(*Int32* AxisIndex)

Method that executes the preset ZERO for multi-turn absolute encoder type.

This method sets the current position of the CN as ZERO. The method should be used when you want to fix the ABSOLUTE ZERO for the first time.

**AxisIndex** Index of axis

### 4.2.6 *Int32* ReadEncoderIndexShift(*Int32* AxisIndex)

Method that reads the phase shift in the pulse encoder zero mark in relation to micro-homing.

The value is updated after searching the zero axis.

This method is valid only for boards that are connected encoder with zero mark on the CN

**AxisIndex** Index of axis

### 4.2.7 *bool* ResetAxesHoming(*bool[]* Axes)

Reset the Homing

**Axes** Array of bool. The position with **True** indicate, the reset bit of axis

**4.2.8 Void StartHomingAxis(Int32 AxisIndex)**

Run start axis homing procedure

The number of axis refers to the index of axes configured (0=X – 1=Y 2=Z etc.)

At this stage you can manage the parameter TIMEOUTHOME

**AxisIndex**          Index of Axis

**4.2.9 Void StopHomingAxis()**

Stop homing sequence. The axis that is making the homing is stopped.

### 4.3 *UsAxesManualJog*

Manual movimentation Axes

#### 4.3.1 **Bool AbsoluteRelativeJog**

Property Read Write

Get or Set absolute/relative movimentation

**False** Absolute

**True** Relative

#### 4.3.2 **Bool ExternalJogActivated**

Property Read Write

**False** External Axes selector Disabled

**True** External Axes selector Enabled

#### 4.3.3 **Int HandWheelMultiplier**

Property Read Write

Handwheel multiplier read or set x1 x10 x100 x1000

#### 4.3.4 **Int SelectAxisForJog**

Property Read Write

Read or set the axis for **MoveSelectAxisJog()**

#### 4.3.5 **Void MoveAxisJog(int AxisIndex, bool Direction)**

JOG Axis to direction. The axis is selected by **AxisIndex**.

**AxisIndex** Index of Axis

**Direction** **True/False** Direction

**WARNING!!!**

Use **StopMove()** for stop movimentation

Example c#:

```
// Button down
private void button1_MouseDown(object sender, MouseEventArgs e)
{
    IsoNs.JogAxis.Jog(0,true);
}
// Button Up
private void button1_MouseUp(object sender, MouseEventArgs e)
{
    IsoNs.JogAxis.StopMove();
}
```

**4.3.6 Void MoveAxisToTarget(double Target, Int32 AxisIndex)**

Method that moves the axis to the position shown in Axis Target passed as doubles.

The unit of measurement of target position is set in the configuration.

If the CNC is in RELATIVE MOTION **AbsoluteRealtiveJog = True** target position is considered as the distance traveled from the point where it is the axis.

If the CNC is in ABSOLUTE MOTION **AbsoluteRealtiveJog = False** Target position is considered by the machine zero set for the axis movement

**Target** Axis target position

**AxisIndex** Index of Axis to be moved

**WARNING!!!**

Use **StopMove()** for stop movimentation

**4.3.7 Void MoveSelectAxisJog(bool Direction)**

JOG Axis to direction. The axis is selected **SelectAxisForJog**

**Direction** True/False Direction

**WARNING!!!**

Use **StopMove()** for stop movimentation

**4.3.8 Int32 ReadHandWheelMultiplier()**

Return the Handwheel mulplier selected

**4.3.9 Void SelectAxisHandMult(Int32 AxisIndex,Int32 HandWheelMultValue)**

Select the HandWheel multiplier

**AxisIndex** Index of Axis

**HandWheelMultValue** Mulpilier value

The multiplier must have the following values

<b>1</b>	→	<b>x1</b>
<b>10</b>	→	<b>x1</b>
<b>100</b>	→	<b>x100</b>
<b>1000</b>	→	<b>x1000</b>

**WARNING!!!**

If you are using an electronic hand wheel with gearbox software, you should always use this method instead of the Property **SelectAxisForJog**.

**4.3.10 Void SetPositionAxisShift(Int32 AxisIndex,double ShiftValue)**

This method, moves the axis in Shift mode. The value **ShiftValue** is added at actual axis position (also if the axis is in moving). The entire position is reached during a time depending by parameter **TSHF\_...**This value indicate the increment xTAU

**AxisIndex** Index of Axis

**ShiftValue** Value of Shift

Ex:

**TAU=2 Ms**

**ShiftValue=100**

**TSHF\_ =10**

The entire position is reached in 20 Ms

**4.3.11 Void StopAllMove()**

Stop all manual movements

**4.3.12 EnumsMoveAxes AxisIsMove ()**

Return the Axes movment status

**NoMove** No Axes Move

**Move** Axes Move

**CncInRun** Cn In Run Request not available



**4.3.13 EnumMoveAxes MoveInterpolationAxes(StructMoveAxes AxesPar )**

Motion Axes in interpolation

**StructMoveAxes**

```

public double Feed; Feed Assi
public bool Absolute; True Absolute motion
public double[] AxesValues; Array Axes
public int HeadNumber; Head -1 disable
public bool UseCurrentWorkOrigins; True uses the current origins
public bool UseCurrentOffset; True uses the current offet

```

Return:

<b>CncInRun</b>	Cn In Run Request not available
<b>CncAlreadyInMovement</b>	Axes already in movment
<b>AllAxesNotReady</b>	One ore more Axes are not ready (homing,enable)
<b>NoAxesNumber</b>	The AxesValues dimension is not equale to axes number
<b>NoInsertBuffer</b>	Movment not insert (wait axes move)
<b>MoveAxesOk</b>	Ok

#### 4.4 *UsAxesValue*

Axes value

##### 4.4.1 **Int32 AxesResolution**

Property Read

Axes value resolution setted in IsoUs.cfg

##### 4.4.2 **double CncTaskTime**

Property Read

CNC sample time setting (millisecond)

##### 4.4.3 **Int32 FeedResolution**

Property Read

Feed value resolution setted in IsoUs.cfg

##### 4.4.4 **double ReadDemandPosition(Int32 AxisIndex)**

Reads the Demand position

**AxisIndex**      Index of Axis

##### 4.4.5 **double[] ReadAllDemandPosition()**

Reads All Demand position of Axes

##### 4.4.6 **double ReadRealPosition(Int32 AxisIndex)**

Reads the Real position

**AxisIndex**      Index of Axis

##### 4.4.7 **double[] ReadAllRealPosition()**

Reads All Real position of Axes

##### 4.4.8 **double ReadRelativeDemandPosition(Int32 AxisIndex)**

Reads the Relative (without offset) Demand position

**AxisIndex**      Index of Axis

##### 4.4.9 **double[] ReadAllRelativeDemandPosition()**

Reads All Relative (without offset) Axes Demand position

##### 4.4.10 **double ReadRelativeRealPosition(Int32 AxisIndex)**

Reads the Relative (without offset) Real position

**AxisIndex**      Index of Axis

##### 4.4.11 **double[] ReadAllRelativeRealPosition()**

Reads All Relative (without offset) Axes Real position

## 4.5 *UsBreakPoints*

It contains all the methods and properties to insert breakpoints. Breakpoints allow you to terminate the program at a desired point.

Once the program execution reaches the breakpoint that stops going to PAUSE.

### 4.5.1 **Int32[] GetAllBreakPoint()**

Return Array of Int32 containing all line number of breakpoints inserted

### 4.5.2 **Int32 InsertBreakPoint(Int32 LineNumber)**

Insert a break point

**LineNumber** Gcode Line Number

Return:

**0** Break Point Ok

**1** Break Point All ready inserted

**2** Debug not activated

### 4.5.3 **Bool IsBreakPoint(Int32 LineNumber)**

Check if there is a Break point

**LineNumber** Gcode Line Number

Return:

**True** There is a BreakPoint

**False** There is not a BreakPoint

### 4.5.4 **Void RemoveAllBreakPoints()**

Remove all break Points

### 4.5.5 **Void RemoveBreakPoint(Int32 LineNumber)**

**LineNumber** Gcode Line Number

Return:

**0** Break Point not inserted at line number

**1** Break Point removed ok

**2** Debug not activated

## 4.6 *UsCalcTime*

Manages all function for Gcode execution time calculation

### 4.6.1 **TimeSpan** **GetTotalTime**

Property Read

Returns the time in second for Gcode execution

### 4.6.2 **bool** **ExecuteCalcTime()**

Start the cala time funtion

It is finished with event RunStop

Ritorna:

**True** Start Ok

**False** CNC not ready

**GetTotalTime** contains the timespan

## 4.7 *UsCnErrors*

It contains all the methods and properties to handle errors at the NC following an event **NotifyChanged**

### 4.7.1 **bool GetErrors(out String[] CnErrors,out String[] UsErrors)**

Return:

**False** no errors

**True** Errors

**CnErrors** array string of CNC errors(null none CNC errors)

**UsErrors** array string of IsoUs Errors (null none IsoUs errors)

### 4.7.2 **void ResetCnCAlarms()**

Reste the CNC alarms

## 4.8 *UsCncMemory*

Cnc Memory management.

### 4.8.1 **Byte[] ReadArrayByteMemory(Int32 MemoryAddress, Int32 Length)**

Reads an array of Bytes from CNC

**MemoryAddress** Start memory Address on CNC

**Length** Number of bytes to read

Return:

Array of bytes

### 4.8.2 **Int16[] ReadArrayInt16Memory(Int32 MemoryAddress, Int32 Length)**

Reads an array of Ont16 from CNC

**MemoryAddress** Start memory Address on CNC

**Length** Number of Int16 to read

Return:

Array of Int16

### 4.8.3 **Int32[] ReadArrayInt32Memory(Int32 MemoryAddress, Int32 Length)**

Reads an array of Int32 from CNC

**MemoryAddress** Start memory Address on CNC

**Length** Number of Int32 to read

Return:

Array of Int32

### 4.8.4 **void WriteArrayByteMemory(Int32 MemoryAddress, Byte[] DataValues)**

Wrtite an array of Bytes in CNC memory

**MemoryAddress** Start memory Address on CNC

**DataValues** Array of bytes to write

### 4.8.5 **void WriteArrayInt16Memory(Int32 MemoryAddress, Int16[] DataValues)**

Wrtite an array of Int16 in CNC memory

**MemoryAddress** Start memory Address on CNC

**DataValues** Array of Int16 to write

### 4.8.6 **void WriteArrayInt32Memory(Int32 MemoryAddress, Int32[] DataValues)**

Wrtite an array of In32 in CNC memory

**MemoryAddress** Start memory Address on CNC

**DataValues** Array of Int32 to write

## 4.9 UsCncMFunctions

It contains all the methods to execute the M in the CNC

### 4.9.1 Void Break\_M\_Function()

Break all M in execution on the CNC  
 The VTB Application must stop all M in execution  
 This method sets only the flag  
**ISOV1\_STATUS\_M\_STOP**

### 4.9.2 bool Execute\_M\_Cnc(Int32 Code\_M\_Function, Int32[] ParametersValue)

Run M On NC.  
**Code\_M\_Function** M code  
**ParametersValue** Int32 Array M paramaters (max number for parameters is defined IsoUs.cfg – default 10)  
 Return:  
**True** M Run  
**False** M not configured

Example c#:

```
private void GoM()
{
    Int32[] Param=new Int32[3]; // 3 parameters
    // assign the parameters values
    Param[0]=10;
    Param[1]=20;
    Param[2]=30;
    // Start M100
    if(MyIsoUs.UsCncMFunctions.Execute_M_Cnc(100, Param)==false)
        // error
}
```

### 4.9.3 Int32 ReadCnC\_M\_Parameters(Int32 ParameterNumber)

Read the M parameter on NC .This feature allows a complete interaction between the NC and the functions M PC application. If a function M activated the CN values must communicate to the PC is possible via this function  
**ParameterNumber** Parameter number on NC (0 to 10)  
 Return  
 Parameter value

### 4.9.4 bool WriteCnC\_M\_Parameters(Int32 ParameterNumber,Int32 ParameterValue)

Write a M par on NC  
**ParameterNumber** Parameter number  
**ParameterValue** Value  
 Return  
**True** ok  
**False** error  
 This method can also be used to write the variables defined by the compiler ... \$\_PARAM1

## 4.10 *UsCnCStatusWord*

Questa classe contiene tutte le Property relative allo stato del CN.

### 4.10.1 **bool** *IsAbsoluteRealtiveMotion*

Property Read  
 Absolute/relative motion  
**True** Relative Motion  
**False** Absolute motion (refrence to ZERO MACHINE)

### 4.10.2 **bool** *IsStatusAxesMove*

Property Read  
 Indicates the axes status movements  
**True** Axes Moviment  
**False** Axes stop

### 4.10.3 **bool[]** *IsStatusEnableAxes*

Property Read  
 Axes enable status.  
 Return a boolean array to length axes number  
 The relative array index contains the status enabled axis  
**True** Axis enabled  
**False** Axis disabled

### 4.10.4 **bool** *IsStatusError*

Property Read  
 Status NC error  
**True** NC in error  
**False** NC OK

### 4.10.5 **bool** *IsStatusExternalOverride*

Property Read  
 Indicates the exetrnal override status  
**True** External Override Enabled  
**False** External Override Disabled

### 4.10.6 **bool[]** *IsStatuHomingAxes*

Property Read  
 Axes homing status  
 Return a boolean array to length axes number  
 The relative array index contains the status homing axis  
**True** Axis homing OK  
**False** Axis homing NOT OK

### 4.10.7 **bool** *IsStatusPause*

Property Read  
 Indicates NC Stautus PAUSE  
**True** PAUSA NC  
**False** PAUSA terminated

### 4.10.8 **bool** *IsStatusProbe*

Property Read  
 Indicates the acquisition state (test after StartAcq())  
**True** Acquisition terminated  
**False** Acquisition in RUN



**4.10.9 bool IsStatusRun Property di tipo Boolean- Read Only**

Property Read

Indicates the NC statusRUN STOP

**True** NC in RUN or PAUSE (check **IsStatusPause**)

**False** NC in STOP

**4.10.10 bool IsStatusStepMode**

Property Read

Indicates the NC mode execution Gcode STEP MODE or NORMAL MODE

**True** STEP MODE

**False** NORMAL MODE

**4.10.11 bool IsStatus\_M\_Execution**

Property Read

Indicates if M to NC is in RUN

**True** M in RUN

**False** M Terminated

## 4.11 *UsCompiler*

Manages the Gcode Compilation

### 4.11.1 `List<Compiler.MarkerCs> GetMarker`

Property Read

Returns the LIST of marker defined in Gcode

### 4.11.2 `List<Compiler.DimaArray> GetUsArray`

Property Read

Returns the LIST of array defined in Gcode

### 4.11.3 `List<string[]> GetUsDefine`

Property Read

Returns the LIST of “define” defined in Gcode

### 4.11.4 `List<string> GetUsFixedVariables`

Reserved

### 4.11.5 `List<string> GetUsVariables`

Property Read

Returns the LIST of \$ Variables defined in Gcode

### 4.11.6 `string LastFileCompiled`

Property Read

Returns the path of last file compiled

### 4.11.7 `Int32 LastTotalCodeLoaded`

Property Read

Returns the number of bytes loaded last time

### 4.11.8 `Int32 TotalLinesCompiled`

Property Read

Returns the number of lines compiled

### 4.11.9 `UsWork.IsoUs.UsErrorCompiler[] CompileGcode(string Gcode, bool CanLoadCode, out Int32 TotalLines)`

Compile Gcode from Text

**Gcode** Text of Gcode (must be UPPERCASE)

**CanLoadCode** True automatic load in memory

**TotalLines** Returns the number of lines compiled

Return:

**Array** UsErrorCmpiler, or **null** if none errors

### 4.11.10 `UsWork.IsoUs.UsErrorCompiler[] CompileGcodeFromBlock(string GcodePathFile, bool CanLoadCode, out Int32 TotalLines)`

Compile Gcode from Block Execution

**GcodePathFile** Path Gcode

**CanLoadCode** True automatic load in memory

**TotalLines** Returns the number of lines compiled

Return:

**Array** UsErrorCmpiler, or **null** if none errors

#### 4.11.11 `UsWork.IsoUs.UsErrorCompiler[] CompileGcodeFromFile(string GcodePathFile, bool CanLoadCode, out Int32 TotalLines)`

Compile Gcode from file

**GcodePathFile** Gcode Path

**CanLoadCode** True automatic load in memory

**TotalLines** Returns the number of lines compiled

Return:

**Array** `UsErrorCmpiler`, or **null** if none errors

**WARNING This Function is Deprectaed Use** `CompileGcodeFromPathFile`

#### 4.11.12 `UsWork.IsoUs.UsErrorCompiler[] CompileGcodeFromPathFile(string GcodePathFile, bool CanLoadCode, out Int32 TotalLines)`

Compile Gcode from file

**GcodePathFile** Gcode Path

**CanLoadCode** True automatic load in memory

**TotalLines** Returns the number of lines compiled or **-1 if file not found**

Return:

**Array** `UsErrorCmpiler`, or **null** if none errors

#### 4.11.13 `bool LoadCode()`

Load in the memory the Gcode compiled

Return:

**True** Ok

**False** Error

#### **4.12 *UsConfig***

It contains all the methods and properties that manage the configuration of the NC. The configuration is read from the file IsoUs.cfg.

## 4.13 UsGcodeRun

This class manages the execution of the ISO program

### 4.13.1 double Feed

Property Read Write  
Reads or Set the Gcode **FEED**  
Normally the **FEED** is setted by Gcode **F** function

### 4.13.2 bool SelectStepMode

Property Read Write  
Get/Set the run STEP MODE Gcode  
**True** Step Mode enabled  
**False** Normal run

### 4.13.3 bool BackupCode()

BackUp the last code compiled.  
This can be recovered by **RestoreGcode()**  
BackUp avoids to recompile a Gcode file  
Return:  
**True** Ok  
**False** BackUp non effettuato

### 4.13.4 bool ExecuteGcode(Int32 NlineStart)

Executes the Gcode loaded  
**NlineStart** Number of Line of Start  
if **NlineStart >0**, it means RESUME FROM BLOCK and the **MGOBLOCK** is performed  
Return:  
**True** Ok  
**False** Error

### 4.13.5 Void ExecuteGcodeFromMarker(Int32[] AddressMarker,Double[] ValuesMarker)

Executes the Gcode when the conditions of the indicated marker.

**MARKER**

*Markers are placed in the part of the normal variables.*

*IsoNs Gcode can resume when these variables have reached a certain value.*

*In advanced programming with the use of VARIABLES and LOOP CYCLE, the recovery from the number of lines is not sufficient, since the positions axes can be increased from the value of variables that are detreminate a loop LOOP. Using markers, you can resume the Gcode by the value of one of these and not by line number, so it is possible to discriminate the resumption of cycles inside LOOP.**AddressMarker** Array di Int32 che contiene l' indirizzo fisico in memoria delle variabili MARKER recuperabile con la Property GetMarker, la quale ritorna un Lista di tipo Compiler.MarkerCs*

**AddressMarker** Array of Int32 that contains the memory address of Markers get by Compiler.MarkerCs

**ValuesMarker** Value must have each marker so that the restart condition is satisfied

**Ex:**

In the following example defines a variable Marker named **\$INC**.

**MARKER** \$INC NUMBER OF LOOP

\$VAR=0

\$INC=0

```

F5
G1X0Y0
LOOP 10
    $INC=$INC+1
    G1X200
    $VAR=$VAR+50
    GOX0Y[$VAR]
END_LOOP

```

You can then enable the resumption of the Gcode when the variable \$ INC (the MARKER) assumes a certain value.

```

private void GoMarker()
{
    List<Compiler.MarkerCs> MyMarker = MyUsIso.UsCompiler.GetMarker; // Read Markers
    Int32[] AddrMarker = new Int32[MyMarker.Count];
    for (int n = 0; n < MyMarker.Count; n++) // Copy address
        AddrMarker[n] = MyMarker[n].AddrVar;
    Int32[] ValMarker = new Int32[1]; // insert the marker value ($INC)
    ValMarker[0] = 5; // recovery after 5 cycles
    MyUsIso.UsGocodeRun.ExecuteGcodeFromMarker(AddrMarker, ValMarker); // Start
}

```

#### 4.13.6 Void ExecuteGcodeFromMarkerAndLine(Int32[] AddressMarker,Double[] ValuesMarker,Int32 LineNumber)

Equal to **ExecuteGcodeFromMarker** but the **LineNumber** condition must be satisfied  
**LineNumber** Number of line

#### 4.13.7 bool ExecuteGcodeScript(String GcodeScript, out UsWork.IsoUs.UsErrorCompiler[] Errors)

Execute Script code

*A script behaves differently from a normal Gcode, as this does not handle a full movement of the axes but only GO and G1 and can also be run at when the CN is in a state of PAUSE*

**GcodeScript** Text of IsoUs Gcode Script  
**Errors** UsWork.IsoUs.UsErrorCompiler[] Errors

Return:

**True** Ok

**False** Error

#### Example C#

```

private void Script()
{
    UsWork.IsoUs.UsErrorCompiler[] _Errors;
    if(!MyUsIso.UsGocodeRun.ExecuteGcodeScript("F5G1X100Y100,Z100\nG4F2\nX0Y0Z0", out _Errors))
    {
        if(Errors!=null)
        {
            for (int n = 0; n < Errors.Length; n++) // check errors
                Label1.Text += "E:" + Errors [n].Nline + " " + Errors [n].ErrorType;
        }
        else
            // execution Error
    }
    // Ok
}

```

#### 4.13.8 Void PauseGcode()

Pause Gcode

Is performed **MPAUSE** configured

From a state of PAUSE you can share the exact point where it stopped working by invoking the method **ExecuteGcode(0)**.

Is performed **MGOPAUSE** configured

#### 4.13.9 bool RestoreGcode()

Recovery the code saved with **BackUpGcode()**

This is loaded in memory redy to work

Return:

**True** Ok

**False** Restore Error

#### 4.13.10 Void StopGcode()

Force STOP Gcode

Is performed **MSTOP**configured

#### 4.13.11 Int32 WorkLineReal()

Read Real line in esecution. Can also use event **WorkLineRealChanged**

It can be used when the CN is in STOP after an alarm to get the precise line of interruption of the Gcode.

#### 4.14 UsGcodeVariables

This class provides access to the read and write variables ISONS Gcode.

Variables accessible are those of general type \$.

It is necessary that the Gcode has been compiled.

The following variables are always at a fixed address

Name	Address	Name	Address
\$_PARAM_1	0	\$_PARAM_6	5
\$_PARAM_2	1	\$_PARAM_7	6
\$_PARAM_3	2	\$_PARAM_8	7
\$_PARAM_4	3	\$_PARAM_9	8
\$_PARAM_5	4	\$_PARAM_10	9

The above variables can be read and written also before the Gcode compilation

The possibility of writing the variables of the Gcode allows you to configure the processing cycle in a parametric mode.

##### 4.14.1 List<string> GetAllVariablesName

Property Read

Get all Variable configured

Return:

The list of string with Variables Name without \$

##### 4.14.2 Int32 GetVariableAddress(String VariableName)

Get variable Address

**VariableName** Variable name without \$

Return:

**>=0** Variable Address

**-1** Variable not found

##### 4.14.3 String GetVariableName(Int32 VariableAddress)

Get variable Name

**VariableAddress** Variable Address

Return:

**Name** Variable name without \$

**""** Variable not found

##### 4.14.4 double ReadVariableByAddress(Int32 VariableAddress)

Read Variable by Address

**VariableAddress** Variable Address

Return:

**Value double**

**Exception variable not found**

##### 4.14.5 double ReadVariableByName(string VariableName)

Read Variable by Name

**VariableName** Variable name without \$

Retrun:

**Value double**

**Exception variable not found**



**4.14.6 bool WriteVariableByAddress(Int32 VariableAddress, double VariableValue)**

Write Variable by Address

**VariableAddress** Variable Address

**VariableValue** Value

Return:

**True** Ok

**False** Variable not found

**4.14.7 bool WriteVariableByName(string VariableName, double VariableValue)**

Write Variable by Name

**VariableName** Variable name without \$

**VariableValue** Value

Return:

**True** Ok

**False** Variable not found

## 4.15 UsInputOutput

It contains all the methods and properties to manage all the resources of the NC Input Output. The management of these resources depends on the type of CN used and the hardware configuration.

### 4.15.1 bool ReadDigitalInput(Int32 InputNumber)

Read Digital Input

**InputNumber** Digital Input from 0 to 255

Return:

**True** ON

**False** OFF

### 4.15.2 bool ReadDigitalOutput(Int32 OutputNumber)

Read Digital Output

**OutputNumber** Digital Output from 0 to 255

Return:

**True** ON

**False** OFF

### 4.15.3 Int32 ReadGroupDigitalInputs(Int32 Group)

Read a Group of Digital Inputs

**Group** Group from 0 to 7 (0 first 32 digital inputs)

Return:

32 bit Digital Inputs

**Bit Set** ON

**Bit Reset** OFF

Example c#:

```
private void TestInput()
{
    // Read first group
    Int32 Group = MyUsIso.UsInputOutput.ReadGroupDigitalInputs(0);
    // Test input1 and 5
    if((Group & 1)==1 && (Group & 16)==16)
        // ON
}
```

### 4.15.4 Int32 ReadGroupDigitalOutputs(Int32 Group)

Read a Group of Digital Outputs

**Group** Group from 0 to 7 (0 first 32 digital outputs)

Return:

32 bit Digital Outputs

**Bit Set** ON

**Bit Reset** OFF

### 4.15.5 void WriteDigitalOutputs(Int32 OutputNumber,bool OutputState)

Write a Digital Outputs

**OutputNumber** Digital Output from 0 to 255

**OutputState** State 1 ON 0 OFF

## 4.16 *UsLogFile*

Log file management

### 4.16.1 `string PathUsLog`

Property Read Write

Set or Get the Path of Log file

#### 4.17 UsMachineParameters

This class manages all parameters of CN.

All machine parameters are stored in the file and must be IsoUs.cfg

##### 4.17.1 UsWork.UsMachineParametersCs.AxesVisType AxesValueMode

Property Read Write

Get or Set the type of read axes values:

**DEMAND\_POSITION** Demand Position

**DEVIATION\_POSITION** Following error

**DISABLE** only DEMAND\_POSITION

**REAL\_POSITION** Real Position

##### 4.17.2 List<ComSynk.ParametriMacchina> MyParameterList

Property Read

Return the List of machine parameters

##### 4.17.3 Int32 NumberOfParameters

Property Read

Return the number of machine parameters

##### 4.17.4 String[] ParametersGroups

Property Read

Return the GROUP configured (ex: General,Axis X etc.)

##### 4.17.5 String PathUsCfg

Property Read

Return the IsoUs.cfg Path

##### 4.17.6 Void DownloadParamaters()

Reads all the configuration parameters IsoUs.cfg and saves them in preparing an internal list to read the other of these methods.

**This should be in every case the first method to be invoked before the management parameters.**

##### 4.17.7 bool GetParameterDataByIndex(Int32 ParameterIndex, out String ParameterName,out String ParameterDescr,out String ParameterGroup,out Int32 ParameterValue,out Int32 ParameterAddress)

Get a parameter from Index

**ParameterIndex** Index of parameter in the internal List

**ParameterName** Return Parameter Name

**ParameterDescr** Return Parameter Description

**ParameterGroup** Return Parameter Group

**ParameterValue** Return Parameter Value

**ParameterAddress** Return Parameter Address on CNC

Return:

**True** Ok

**False** Paramater not found or **DownloadPara()** not performed

#### 4.17.8 **bool** GetParameterDataByName (String ParameterName, out Int32 ParameterIndex, out String ParameterDescr, out String ParameterGroup, out Int32 ParameterValue, out Int32 ParameterAddress)

Get a parameter from Name

<b>ParameterName</b>	Parameter Name (CASE Sensitive)
<b>ParameterIndex</b>	Return Parameter Index
<b>ParameterDescr</b>	Return Parameter Description
<b>ParameterGroup</b>	Return Parameter Group
<b>ParameterValue</b>	Return Parameter Value
<b>ParameterAddress</b>	Return Parameter Address on CNC

Return:

**True** Ok

**False** Paramater not found or **DownloadPara()** not performed

#### 4.17.9 **bool** GetParameterExtendedData(Int32 ParameterIndex, out Int32 Transform, out Int32 MinValue, out Int32 MaxValue, out Int32 PassWordLevel, out Int32 Familiy, out Int32 AxisIndex, out List<ComSynk.EnumCs> Enums)

Get a parameter extend data from Index

<b>ParameterIndex</b>	Index of parameter in the internal List
<b>Transform</b>	Return Parameter Transform
<b>MinValue</b>	Return Parameter Minimum Value
<b>MaxValue</b>	Return Parameter Maximum Value
<b>PassWordLevel</b>	Return Parameter Password Level
<b>Family</b>	Return Parameter Familiy
<b>AxisIndex</b>	Return Parameter Axis Index (-1 none Axis)
<b>Enums</b>	Return Parameter ENUMERATIVE DESCRIPTION (if present)

Return:

**True** Ok

**False** Paramater not found or **DownloadPara()** not performed

#### 4.17.10 **bool** GetParameterValueByIndex(Int32 ParameterIndex, out Int32 ParameterValue)

Get a parameter from Index

<b>ParameterIndex</b>	Index of parameter in the internal List
<b>ParameterValue</b>	Return Parameter Value

Return:

**True** Ok

**False** Paramater not found or **DownloadPara()** not performed

#### 4.17.11 **bool** GetParameterValueByName (String ParameterName, out Int32 ParameterValue)

Get a parameter from Name

<b>ParameterName</b>	Parameter Name (CASE Sensitive)
<b>ParameterValue</b>	Return Parameter Value

Return:

**True** Ok

**False** Paramater not found or **DownloadPara()** not performed

**4.17.12 bool RestoreUsCfgBackUp()**

Restore thye BackUp copy

Return:

**True** Restore Ok

**False** Error

**4.17.13 Void SaveUsCfg()**

Save in the **IsoUs.cfg** the parameter internal list

Before, a copy of backup is made (use **RestoreUsCfgBackUp()**)

**4.17.14 Void SendAllParameters()**

Send all Parameters to CNC

Some parameters are available only after **UpdateParameters()**

**4.17.15 Void UpdateParameters()**

Update the parameters

Call it after **SendAllParameters()**

**4.17.16 bool WriteParametersByIndex(Int32 ParameterIndex, Int32 ParameterValue, bool WriteInCnC)**

Write a parameter by Index

**ParameterIndex** Index of parameter in the internal List

**ParameterValue** Parameter Value

**WriteInCnC** if **True** the Parameter is send to CNC (the **UpdateParameters()** is not called)

Return:

**True** Ok

**False** Error

**4.17.17 bool WriteParametersByName(string ParameterName, Int32 ParameterValue, bool WriteInCnC)**

Write a parameter by Name

**ParameterName** Parameter Name

**ParameterValue** Parameter Value

**WriteInCnC** if **True** the Parameter is send to CNC (the **UpdateParameters()** is not called)

Return:

**True** Ok

**False** Error

## 4.18 UsMHMfunctions

It contains all the methods that handle the compilation and Property of M and HM, which are run at a PC (not inside the CN)

These can then be retrieved by the method ExecuteMtoCn.GoMtoCn (....)

**4.18.1 bool GenerateHMFunction (Int32 HMFunctionNumebr, String GCode,out UsWork.IsoUs.UsErrorCompiler[] Errors)**

**4.18.2 bool GenerateMFunction (Int32 MFunctionNumebr, String GCode,out UsWork.IsoUs.UsErrorCompiler[] Errors)**

This method allows you to fill out a HM or M function and save it automatically in the configuration folder.

**..FunctionNumber** M or HM number

**GCode** String Code ISO

**Errors** Array Error compiler

Return:

**True** M/HM Ok

**False** Error

## 4.19 *UsOffsetAndOrigins*

This class manages the capabilities of the MANUAL WORK ORIGIN.  
 IsoUs manipulate an array of 256 different positions for WORK ORIGIN. The positions are indexed by GCODE instruction **USER\_ZERO Index Value**.  
 This function is the same of GCODE G94

### 4.19.1 `List<ComSynk.FileZeri> GetAllOriginsByFile`

Property Read  
 Get all origins setted in the default file  
 Return:  
 List of 9 string position that contains the values of origin for single Axis  
**The List position is the Index of Origin**

### 4.19.2 `bool HeadOffsetSuspend`

Property Read Write  
 Suspend or Resume the Heads Offset selected by **Hn**  
**False** Suspend (As G87)  
**True** Resume (As G88)

### 4.19.3 `Int32 IndexOffset`

Property Read Write  
 Get or Set the Index OFFSET  
 Value from 0 to 255

### 4.19.4 `Int32 IndexOrigin`

Property Read Write  
 Get or Set the Index ORIGINS  
 Value from 0 to 255

### 4.19.5 `bool IsOffset`

Property Read  
 Read if the OFFSET is activated  
**False** Disabled  
**True** Enabled

### 4.19.6 `bool IsOrigins`

Property Read  
 Read if the ORIGINS are activated  
**False** Disabled  
**True** Enabled

### 4.19.7 `bool OffsetSuspend`

Property Read Write  
 Suspend or Resume the Offset selected by **G93**  
**False** Suspend (As G96)  
**True** Resume (As G97)

### 4.19.8 `bool OriginsSuspend`

Property Read Write  
 Suspend or Resume the Origins selected by **G94**  
**False** Suspend (As G98)  
**True** Resume (As G99)



**4.19.9 Int32[] SingleAxisIndexOrigins**

Property Read Write

Get or Set the index origin fo the single Axis

**Array Int32 that contains the Index Origins for Axis****4.19.10 Void ActivateOriginFile()**

Activates the Origins by file ZERI.VAL (default File)

**4.19.11 Int32 AxesOffsetDisable(Int32 Index)**

Disable the Offset at Index

**Index** Offset Index

Return:

**1** Error**0** Ok**4.19.12 Int32 AxesOriginDisable(Int32 Index)**

Disable the Origin at Index

**Index** Origin Index

Return:

**1** Error**0** Ok**4.19.13 double[] GetCurrentOffset(Int32 Index)**

Get the Current offset at Index

**Index** Offset Index

Return:

Array of Axes Offset position

**4.19.14 double[] GetCurrentOffsetSetted()**

Get the Offset at current Index

Return:

Array of Axes Offset position

**4.19.15 double[] GetCurrentOrigins(Int32 Index)**

Get the Current Origin at Index

**Index** Origin Index

Return:

Array of Axes Origin position

**4.19.16 double[] GetCurrentOriginsSetted()**

Get the Origin at current Index

Return:

Array of Axes Origin position

**4.19.17 double[] GetOriginsFromUsFile(Int32 Index)**

Get the Origins at Index from default file ZERI.VAL

**Index** Origin Index

Return:

Array of Axes Origin position

**4.19.18 Int32 SetAxesOffsetToCurrentPosition(Int32 OffsetIndex)**

Set the OFFSET at Index to current axes position

**OffsetIndex** Offset Index**The OFFSET is automatically enabled**

Return:

**1** Error**0** Ok**4.19.19 Int32 SetAxesOffsetToPosition(double[] OffsetValue, Int32 OffsetIndex)**

Set the OFFSET at Index by values

**OffsetValue** array of Offset Values for Axis**OffsetIndex** Offset Index**The OFFSET is automatically enabled**

Return:

**1** Error**0** Ok**4.19.20 Int32 SetAxesOriginsToCurrentPosition(Int32 OriginIndex)**

Set the ORIGIN at Index to current axes position

**OriginIndex** Origin Index**The ORIGIN is automatically enabled**

Return:

**1** Error**0** Ok**4.19.21 Int32 SetAxesOriginsToPosition(double[] OriginsValue, Int32 OriginIndex)**

Set the ORIGIN at Index by values

**OriginsValue** array of Origin Values for Axis**OriginIndex** Origin Index**The ORIGIN is automatically enabled**

Return:

**1** Errore**0** Ok**4.19.22 Int32 SetAxisOffsetToCurrentPosition(Int32 OffsetIndex, Int32 AxisIndex)**

Set the OFFSET at Index by current position for single Axis

**OffsetIndex** Offset Index**AxisIndex** Axis Index**The OFFSET is automatically enabled**

Return:

**1** Error**0** Ok**4.19.23 Int32 SetAxisOffsetToPosition(double OffsetValue, Int32 OffsetIndex, Int32 AxisIndex)**

Set the OFFSET at Index by value for single Axis

**OffsetValue** Offset Value**OffsetIndex** Offset Index**AxisIndex** Axis Index**The OFFSET is automatically enabled**

Return:

**1** Error**0** Ok

**4.19.24 Int32 SetAxisOriginToCurrentPosition(Int32 OriginIndex, Int32 AxisIndex)**

Set the ORIGIN at Index by current position for single Axis

**OriginIndex**      Origin Index

**AxisIndex**        Axis Index

**The ORIGIN is automatically enabled**

Return:

**1**            Error

**0**            Ok

**4.19.25 Int32 SetAxisOriginToPosition(double OriginValue,Int32 OriginIndex, Int32 AxisIndex)**

Set the ORIGIN at Index by value for single Axis

**OriginValue**      Origin Value

**OriginIndex**      Origin Index

**AxisIndex**        Axis Index

**The ORIGIN is automatically enabled**

Return:

**1**            Error

**0**            Ok

**0**            Ok

**4.19.26 bool IsoG43FromTable(Int32 Kmode,Int32 Axis, bool Direction)**

Enable G43 from Tool Table

**Kmode**            See the K parameter G43 function

**Axis**              Axis Index

**Direction**        Correction direction (**false** Negative – **true** Positive)

Return:

**True**      Ok

**False**     Error (CNC in Run or Axis not configured)

**4.19.27 bool IsoG43FromLen(Double ToolLen,Int32 Kmode,Int32 Axis, bool Direction)**

Enable G43 from Tool Len

**ToolLen**          Tool Len

**Kmode**            See the K parameter G43 function

**Axis**              Axis Index

**Direction**        Correction direction (**false** Negative – **true** Positive)

Return:

**True**      Ok

**False**     Error (CNC in Run or Axis not configured)

**4.19.28 bool IsoG44(Int32 G44Ext)**

Disable G43

**G44Ext**            See command **G43.0 G43.1**

Return:

**True**      Ok

**False**     Error (CNC in Run or Axis not configured)

**4.19.29 bool IsoG43State()**

Read the G43 state

Return:

**True**      G43 Enabled

**False**     G43 Disabled

## 4.20 *UsOverrideFeed*

This class manages the OVERRIDE FEED

.

### 4.20.1 **bool ExternalOverrideFeed**

Property Read Write

Enable/Disable External Override

**True** Enabled

**False** Disabled

### 4.20.2 **Int32 OverrideFeedAxes**

Property Read Write

Get or Set the internal override value

**Value from 0 to 100 %**

## 4.21 *UsPasswordManagement*

IsoUs Password management

### 4.21.1 **bool** ResetUsPassword(**Int32** PasswordLevel)

Reset the current Password to default value

**PasswordLevel** Password level to Reset from 0 to 2

Default value:

**Level 0** → 684618

**Level 1** → 684619

**Level 2** → 684620

Return:

**True** Ok

**False** Error

### 4.21.2 **bool** SetUsNewPassword(**String** NewPassword,**Int32** PasswordLevel)

Set the new Password at level

**NewPassword** New Password

**PasswordLevel** Password level to Set from 0 to 2

Return:

**True** Ok

**False** Error

### 4.21.3 **bool** TestUsLevelPasswordBlock(**Int32** PasswordLevel)

Check the Password level if locked or Unlocked

**PasswordLevel** Password level to check from 0 to 2

Return:

**True** Unlocked

**False** Locked

### 4.21.4 **bool** TestUsPassword(**String** Password,**Int32** PasswordLevel)

Check the Password at level

**Password** Password to check

**PasswordLevel** Password level to Check from 0 to 2

Return:

**True** Password Ok

**False** Password Error

## 4.22 UsPositioners

Positioners class manager  
The positioners must be enabled in VTB application

### 4.22.1 bool AllAxesPositionerReady

Property Read  
Return the state of all positioners (Homing and Enable)  
**True** Ready  
**False** Not Ready

### 4.22.2 Int32 NumberOfPositioners

Property Read  
Return the number of positioners declared in VTB application

### 4.22.3 bool EnablePositioner(Int32 PositionerIndex, bool EnableState)

Enable/Disable Positioner  
**PositionerIndex** Positioner Index  
**EnableState** **True** Enable **False** Disable  
Return:  
**True** Ok  
**False** Positioner Error

### 4.22.4 bool IsAlarm(Int32 PositionerIndex, out bool Status)

Reads the Alarm status  
**PositionerIndex** Positioner Index  
**Status** **True** Alarm **False** Ok  
Return:  
**True** Ok  
**False** Positioner Error

### 4.22.5 bool IsEnabled(Int32 PositionerIndex, out bool Status)

Reads the Enable status  
**PositionerIndex** Positioner Index  
**Status** **True** Enabled **False** Disabled  
Return:  
**True** Ok  
**False** Positioner Error

### 4.22.6 bool IsHoming(Int32 PositionerIndex, out bool Status)

Reads the Homing status  
**PositionerIndex** Positioner Index  
**Status** **True** Homing Ok **False** Homing not made  
Return:  
**True** Ok  
**False** Positioner Error

### 4.22.7 bool IsMoving(Int32 PositionerIndex, out bool Status)

Reads the Movement status  
**PositionerIndex** Positioner Index  
**Status** **True** Movement **False** Stop  
Return:  
**True** Ok  
**False** Positioner Error

**4.22.8 bool Preset(Int32 PositionerIndex, Int32 PresetValue, out bool Status)**

Preset Axis value

**PositionerIndex** Positioner Index**PresetValue** Preset Value**Status True** Preset Ok **False** Preset Error

Return:

**True** Ok**False** Positioner Error**4.22.9 bool ReadDemandPosition(Int32 PositionerIndex, out Int32 PositionValue)**

Reads Demand Position

**PositionerIndex** Positioner Index**PositionValue** Demand Position value

Return:

**True** Ok**False** Positioner Error**4.22.10 bool ReadRealPosition(Int32 PositionerIndex, out Int32 PositionValue)**

Reads Real Position

**PositionerIndex** Positioner Index**PositionValue** Real Position value

Return:

**True** Ok**False** Positioner Error**4.22.11 bool SetOffsetValue(Int32 PositionerIndex, Int32 OffsetValue)**

Set OFFSET position

**PositionerIndex** Positioner Index**OffsetValue** OFFSET value

Return:

**True** Ok**False** Positioner Error**4.22.12 bool SetVelocity(Int32 PositionerIndex, Int32 VelocityValue)**

Set FEED

**PositionerIndex** Positioner Index**VelocityValue** FEED value

Return:

**True** Ok**False** Positioner Error**4.22.13 bool StartHoming(Int32 PositionerIndex)**

Start homing

Read StatusWord for check end Homing

**PositionerIndex** Positioner Index

Return:

**True** Ok**False** Positioner Error

**4.22.14 bool StartPositionTarget(Int32 PositionerIndex, Int32 PositionValue, bool AbsoluteValue)**

Start positioner at Target

**PositionerIndex** Positioner Index**PositionValue** Target Value**AbsoluteValue** **True** Target Absolute Value **False** Target Relative Value

Return:

**True** Ok**False** Positioner Error**4.22.15 bool StatusWord(Int32 PositionerIndex, Out Int32 Status)**

Reads StatusWord

**PositionerIndex** Positioner Index**Status** StatusWord bit mapped (bit 1 setted):**Bit 0** → **Enable****Bit 1** → **Homing****Bit 2** → **Move****Bit 3** → **Allarm**

Return:

**True** Ok**False** Positioner Error**4.22.16 bool Stop(Int32 PositionerIndex)**

Stop the Positioner

**PositionerIndex** Positioner Index

Return:

**True** Ok**False** Positioner Error



## 4.23 UsRetrace

This class handles all the logic functionality of IsoNs Retrace.

The retrace and a mode useful for some types of machines. In practice, it scrolls the tool path on the piece with a kind of simulation, but with axes in motion. The path of the sliding mode occurs in both forward and reverse JOG. This allows you to choose how to RESTART POINT OF VIEW of any section even though this is not a starting point or end of an element. you can make a fresh start from any point of an arc or a straight line. With axes in motion, can have a real vision on the machine POINT OF RESTART.

Is performed **MGORETRACE** configured

**Before using the functions of retrace, you must call the method InitRetrace()**

### 4.23.1 Int32 GetLineRetrace

Property Read

Return the Gcode Line currently in execution in retrace mode.

### 4.23.2 Void ExecuteProg()

Start the Gcode from the current point where the axes are on the profile.

This method is invoked when the operator decided the point of restart of the profile.

Is performed **MGORETRACE** configured

### 4.23.3 bool GetPosAxisAtLine(out Int32 PosX, out Int32 Posy, Int32 Nline)

Reads the axes position at line number

**PosX** Axis X Position

**Posy** Axis Y Position

**NLine** Gcode Line number

Return:

**True** Ok

**False** Line not found

### 4.23.4 Void GoLine(Int32 Nline)

Move axes to block the line indicated.

Need to skip parts of the tool path.

**Nline** Gcode Line number to jump

### 4.23.5 Void InitRetrace()

Enable the feature RETRACE. This method must be called before using any of the Property and the other class methods retraced.

In practice prepares a list of all the Gcode simulation.

### 4.23.6 Void JogDown()

Move axis in the negative direction on the path PIECE.

The jog speed is set in the Gcode

For STOP Axes use **StopJog ()**

### 4.23.7 Void JogUp()

Move axis in the positive direction on the path PIECE.

The jog speed is set in the Gcode

For STOP Axes use **StopJog ()**

### 4.23.8 Void StopJog()

Stp Axes **JogUp()** or **JogDown()**

## **4.24 UsSimulation**

Simulation Gcode

### **4.24.1 Void ExecuteSimulation()**

The current Gcode loaded, will be simulated in the preview window

## 4.25 *UsSpindleManager*

This Class allows to manage all functions for Analog 0-10V Spindle Output.  
The Spindle Output is configured in IsoUs by Machine Parameters Spindle Table  
(See [IsoUs Documentation](#))

### 4.25.1 Void WriteSpindleSpeed(Int32 \_Val)

Write the value **\_Val** in the Analog Output configured for Spindle  
**\_Val** is in **BIT**, therefore for an output of **10V** on the Channels **0-15** the value must be **2047**,  
for the Channel **NGMEVO PWM 255** (max)

### 4.25.2 Int32 ReadSpindleSpeed()

Read the last value write with **WriteSpindleSpeed()**  
Return 0-2047 for the channels 0-15  
0-255 for the channel NGMEVO PWM

### 4.25.3 Void WriteSpindleOw(Int32 \_Val)

Write the Override value for the Analog Output configured for Spindle  
The value is between **0** (0%) and **1024** (100%).

#### **WARNING**

For this function, must be enabled the parameter **ENABLE\_OW\_SPEED** on **INTERNAL VIRTUAL**

The Minimum and Maximum value is restrained by parameter:

**SPEED\_OW\_MIN** Minimum Value of Override

**SPEED\_OW\_MAX** Maximum Value of Override

### 4.25.4 Int32 ReadSpindleOw()

Read the Override value set  
Return 0-1024

### 4.25.5 Int32 SpindleOwState

Property Read

Return the mode set of Spindle Override

- 0**      **Disable**
- 1**      **Managed by VTB**
- 2**      **Managed by WriteSpindleOw()**

### 4.25.6 Int32 SpindleAnalogBitRes

Property Read

Return the BIT resolution set for the Spindle Analog Output

**2048**      **Channels 0-15**

**255 (max)**      **Channel NGMEVO PWM**

## 4.26 *UsStaticVariables*

This class handles files of variables saved in permanent memory. IsoNs allows you to save the contents of variables in a file so that it can be reloaded later. These files are also manageable Gcode.Le PERMANENT are all variables of type DOUBLE, and are included in a list. `Ilist<Double>`.

**The file are saved in internal path of**

### 4.26.1 **String** `GetPathStaticFile`

Property Read  
Return the path of permanents variables.

### 4.26.2 **List<double>** `GetStaticVariables`

Property Read  
Get the values of static variables.  
Necessary use `LoadStaticFile` before

### 4.26.3 **bool** `LoadStaticFile(String StaticFileName)`

Load in memory the static file  
**StaticFileName** File name (Use `GetPathStaticFile` for get the Path)  
Return:  
**True** Ok  
**False** File not found

### 4.26.4 **Void** `SaveFile(String StaticFileName)`

Save in the file the curren LIST get from `GetStaticVariables`.  
**StaticFileName** File Name (only name)

## 4.27 *UsToolInfo*

Tool informations

### 4.27.1 **Int32** **GetIndexAxisLengthEnabled**

Property Read

Get the Index Axis where is enabled the Length correction

**-1** No Axis

### 4.27.2 **double** **GetToolDiameterSet**

Property Read

Get the current Tool Diameter setted

### 4.27.3 **bool** **GetToolDirection**

Property Read

Get the Tool Length correction direction

**True** Positive

**False** Negative

### 4.27.4 **double** **GetToolLengthSet**

Property Read

Get the Length correction value

### 4.27.5 **bool** **IsToolLengthActivated**

Property Read

Get if enabled Tool Length correction

**True** Enabled

**False** Disabled

## 4.28 *UsToolsHeadsTable*

It contains all the methods and properties related to the management of the tool **HEADS** and the parameters of the **TOOLS** table.

### 4.28.1 **Int32** *GetNumberOfHeads*

Property Read  
Get the number of Heads configured

### 4.28.2 **Int32** *GetNumberOfToolsTable*

Property Read  
Get the number of Tools configured

### 4.28.3 **Int32** *SelectHEad*

Property Read Write  
Get or Set an **HEAD**.  
The value of SET must be between 0 and the maximum number of HEAD included in the configuration. An exception is generated if the value is not within this range.  
Returns -1 if no **HEAD** is selected  
This function is equal to **Hn** in Gcode

### 4.28.4 **Int32** *SelectTollTable*

Property Read Write  
Get or Set a **TOOL TABLE**.  
The value of SET must be between 0 and the maximum number of TABLES included in the configuration tool. An exception is generated if the value is not within this range.  
Returns -1 if no TABLE is selected  
This function is equal to **Tn** in Gcode

### 4.28.5 **double** *GetHeadParameter(Int32 ParameterIndex)*

Reads the parameter specified in **ParameterIndex** from the **HEAD** table selected.  
**ParameterIndex** Index of parameter to selected head  
Return:  
Parameter Value

### 4.28.6 **double** *GetToolParamater(Int32 ParameterIndex)*

Reads the parameter specified in **ParameterIndex** from the **TOOL** table selected.  
**ParameterIndex** Index of parameter to selected Tool  
Return:  
Parameter Value

### 4.28.7 **Void** *SaveToolTabelParameters()*

Save the parameters of the tool table in memory (written with WriteParTab) in the configuration on disk permanently

### 4.28.8 **Void** *WriteHeadParameter(double Value, Int32 HeadIndex, Int32 ParameterIndex)*

Write a parameter to Head  
**Value** Parameter value  
**HeadIndex** Head Index  
**ParameterIndex** Parameter index

### 4.28.9 **Void** *WriteToolParameter(double Value, Int32 TableIndex, Int32 ParameterIndex)*

Write a parameter to Tool  
**Value** Parameter value  
**TabellIndex** Tool Index  
**ParameterIndex** Parameter index

## 4.29 *UsGenericVariables*

This class handles variables UserGeneric for data exchange with the NC.

These variables are of type Int32, and can be used to read / write values of using them for general data exchange between PC applicazione CN VTB.

The number of variables is 30

### 4.29.1 **Int32** ReadUserCnCVariable(**Int32** UserAddress)

Reads a User Generic Variable from CNC

**UserAddress**      User Address from 0 to 29

Return:

User Value

### 4.29.2 **Void** WriteUserCnCVariable(**Int32** UserAddress,**Int32** UserValue)

Writes a User Generic Variable in the CNC

**UserAddress**      User Address from 0 to 29

**UserValue**        User Value

### 4.30 *Us2ndLimitsManager*

Racchiude tutti i metodi e proprietà che gestiscono i secondi limiti assi

#### 4.30.1 **bool** *Is2ndLimits*

Property Read

Return:

**True** 2nd Limits activated

**False** Primary Limits activated

#### 4.30.2 **bool** *Activated2ndLimits()*

Activate the **2nd** Software Limits

Return:

**True** – Ok

**False** – CnC in Run

#### 4.30.3 **bool** *Reset2ndLimits()*

Deactivates the **2nd** Limits and activates the **PRIMARY** software Limits

Ritorna:

**True** – Ok


**False** – CnC in Run



### 4.31 UsProbe

This class manages the capabilities of Acquisitions sensor boards. Acquisitions by The sensor requires that the axes are moved to a position up and be detected by this sensor.

The axes can be moved at one time, however, can move only one axis in the direction of the probe Acquisition .



#### 4.31.1 Double[] GetAxesValue

Property Read

Read acquisition positions axes

After acquisition executed you can use this property for read all positions axes

Return:

**Double[]** Array axes positions at sensor

#### 4.31.2 bool StartProbeAcquisition(double[] AxesValue)

Start Acquisition at position

When the sensor detected the piece, the **AcquisitionExecuteChanged** event is performed.

Otherwise **NotifyChanged** event is performed if axes reach the position target.

Is possible test StatusCn **IsStatusProbe**.

**AxesValue** Array for Target positions.

Return:

**True** Acquisition Started

**False** Error Axes position array

#### WARNING

Before run **StartProbeAcquisition** you must set the RUN NC by following instructions

**MyMaster.GetCommand.RunProg();**

At end (normal end or error) **StartProbeAcquisition** you must set the STOP NC by following instructions

**MyMaster.GetCommand.StopProg();**

### 4.32 *UsMultiProcess*

This class manages the MultiProcess capability of IsoUs.  
All CN manage of PC are visible by this class

#### 4.32.1 **MProcessResult GcodeLoadFromFile(Int ProcessNumber, string GcodePat, Int LoadInEditor)**

Load a Gcode from file

**ProcessNumber** Process Number 0 to 7

**GcodePath** Gcode Path

**LoadInEditor** if **True** the will be load in Editor

**Return:**

**MProcessResult.MprocessOk**

Operation OK

**MProcessResult.MprocessNumberError**

Process Number not found

**MProcessResult.MprocessFileNotFound**

Gcode not found

**MProcessResult.MprocessCNCinRun**

Error CNC in run

**MProcessResult. MprocessGcodeCompileError**

Gcode Compile Error

**MProcessResult. MprocessUsEditorNotFound**

**LoadInEditor** Error.

#### 4.32.2 **List<IsoUs> ActiveProcess**

This List contains all UsWork components for all CN active in the current configuration

By it is possible to access all UsWork

**ActiveProcess[0]** Process 0

**ActiveProcess[1]** Process 1

Etc.

### 4.33 UsCmdManager

This class allows to manage the **CMD** of IsoUs.

The **CMD** are the Binary file saved in the local folder **\_CmdBinary** with extension **.USB**

These are the Gcode Files generally compiled with **Plugin MHM**.

The **CMD** can be executed when the **CN** is in **STOP** or in **PAUSE** (as **SCRIPT**).

The **CMDs** are functions that can customize the machine.

Can be passed up to **10 Parameters** (Double) that can be read in the Gcode file by:

**\$(X18...X27)**

#### 4.33.1 CmdResult RunCmd(string CmdName, int Cpu, double[] Parameters, bool CheckAxesReady)

Executes a **CMD**

**CmdName** CMD name (Without extension)

**Cpu** CPU Number

**0** Normal Run (Only CNC in STOP)

**1** Run as **SCRIPT** (CNC in STOP or PAUSE)

**Parameters** Array of double read in the Gcode by:

(The variable **\$(X17)=1** indicate that a **CMD** is in execution)

**\$(X18) Parameters[0]**

**\$(X19) Parameters[1]**

**\$(X20) Parameters[2]**

**\$(X21) Parameters[3]**

**\$(X22) Parameters[4]**

**\$(X23) Parameters[5]**

**\$(X24) Parameters[6]**

**\$(X25) Parameters[7]**

**\$(X26) Parameters[8]**

**\$(X27) Parameters[9]**

**CheckAxesReady False** The Axes Ready are not checked (HOME and ENABLE performed for all Axes)

Return:

**CmdResult.CmdRunOk**

CMD Executed

**CmdResult.ErrorCmdNotFound**

CMD file not found

**CmdResult.ErrorCmdCpuInRun**

CN in RUN

**CmdResult.ErrorCmdParameters**

More than 10 Parameters are passed

**CmdResult.ErrprAxesNotReady**

Axes not Ready (CheckAxesReady=True)

#### 4.33.2 bool SaveCmdCode(string Cmd, bool CheckFile)

Allows to generate a **CMD** by the Gcode current compiled

The **CMD** is saved in **\_CmdBinary**

**Cmd** CMD name (without extension)

**CheckFile True** is checked if the **CMD** already exists (a Dialog Box will be showed)

Return:

**True** CMD Generate OK

**False** Error

#### 4.33.3 string CurrentCmdInRun

Property Read

Return the **CMD** name in execution

#### 4.33.4 bool IsRunCmd

Property Read

**True** **CMD** in RUN

### 4.34 UsTask

This class manage the **PARALLEL TASKS** of IsoUs.

There are Two Parallel Tasks TASK0 e TASK1 that can execute the Gcode concurrently to main process.

TASK 0 is referred to TASK 1 in Gcode Instructions

TASK 1 is referred to TASK 2 in Gcode Instructions

```
public enum UsTaskError
{
    NoError,
    NoTask,
    AlreadyInRun,
    AlreadyInPause,
    NoTaskInRun,
    NoAddrVarValid,
    CmdPathNotFound,
    PriorityOutOfRange,
    CmdAutoLoadNotSet,
    NoTypeRun,
}
```

#### 4.34.1 IsoUs.ErrorCompiler[] LoadGcode(string Gcode, int UsTask, out UsTaskError Error)

Load the Gcode in the Task

**Gcode** Gcode String  
**UsTask** Task Number (0 or 1)  
**Out Error** UsTaskError  
**Return** IsoUs.ErrorCompiler[]

#### 4.34.2 UsTaskError TaskRun(int UsTask)

Run Gcode in the Task

**UsTask** Task Number (0 or 1)  
**Return** UsTaskError

#### 4.34.3 UsTaskError TaskStop(int UsTask)

Stop Gcode in the Task

**UsTask** Task Number (0 or 1)  
**Return** UsTaskError

#### 4.34.4 UsTaskError TaskPause(int UsTask)

Pause Gcode in the Task

**UsTask** Task Number (0 or 1)  
**Return** UsTaskError

#### 4.34.5 UsTaskError TaskReadVar(int UsTask, int AddrVar, out double ValVar)

Read Variable in the Task

**UsTask** Task Number (0 or 1)  
**AddrVar** Source Variable Address  
**Out ValVar** Variable value  
**Return** UsTaskError

#### 4.34.6 UsTaskError TaskWriteVar(int UsTask, int AddrVar, double ValVar)

Write a variable in the Task

**UsTask** Task Number (0 or 1)  
**AddrVar** Destination variable Address  
**ValVar** Source variable value  
**Return** UsTaskError

**4.34.7 UsTaskError TaskStatus(int UsTask, out UsTaskStatus Status)**

Read Task Status

**UsTask** Task Number (0 or 1)**Out Status** Status**Return** UsTaskError

```
public enum UsTaskStatus
{
    Stop,
    Run,
    Pause,
}
```

**4.34.8 UsTaskError TaskLoadCmd(int UsTask, String CmdName)**

Load CMD in the TASK

**UsTask** Task Number (0 or 1)**CmdName** CMD name without extension**Return** UsTaskError**4.34.9 UsTaskError TestTaskCmdAutoLoad(int UsTask)**

Test if a CMD should be loaded automatically after a RUN gcode in the TASK

The Autoload CMD is defined in the IsoUs Environment file via SetTaskCmdAutoload

In the positive case, the CMD file is loaded and executed

**UsTask** Task Number (0 or 1)**Return** UsTaskError**4.34.10 UsTaskError SetTaskCmdAutoLoad(int UsTask, String CmdName, bool IsAutoRun)**

Set the CMD as Autoload in the IsoUs Environment file.

This is always executed / loaded on the Gcode Run

**UsTask** Task Number (0 or 1)**CmdName** CMD name without extension**IsAutoRun** If True, the CMD is Executed automatically to RUN gcode, else only loaded**Return** UsTaskError**4.34.11 UsTaskError TaskSetPriority(int UsTask, int Priority)**

Set priority Task

Lower values higher priority Default 0 (max)

**UsTask** Task Number (0 or 1)**Priority** priority Task from 0 to 100**Return** UsTaskError

## Index

1	PREFAZIONE .....	3
1.1	Before Start.....	3
2	Events.....	4
2.1	AbsRelChanged.....	4
2.2	AcquisitionExecuteChanged .....	4
2.3	AllAxesReadyChanged .....	4
2.4	AxesDemandValueChanged .....	4
2.5	AxesMoveChanged .....	5
2.6	AxesOffsetValueChanged .....	5
2.7	AxesOriginChanged .....	5
2.8	AxesDemandValueChanged.....	6
2.9	AxisEnabledChanged .....	6
2.10	AxisHomeChanged.....	6
2.11	DigitalInputChanged .....	9
2.12	EnableExtOverrideChanged .....	9
2.13	EndImportChanged.....	9
2.14	ExtPauseRequestChanged .....	10
2.15	ExtRunRequestChanged .....	10
2.16	ExtStopRequestChanged .....	10
2.17	FeedAxesChanged .....	10
2.18	RealFeedAxesChanged.....	10
2.19	HeadOffsetValueChanged.....	11
2.20	MachineParametersUpdate .....	11
2.21	MulHandWheelChanged .....	11
2.22	M_CnC_ExecuteChanged .....	11
2.23	OnCloseComRequest.....	11
2.24	OverrideValueChanged.....	11
2.25	PauseChanged .....	12
2.26	RemoveMarkLineChanged.....	12
2.27	RequestMarkLineChanged .....	12
2.28	RunStopChanged .....	12
2.29	RunStopChangedWithType .....	12
2.30	ScriptChanged.....	13
2.31	SelectAxisJogChanged .....	13
2.32	SpeedSpindleChanged .....	13

2.33	StartImportChanged.....	13
2.34	StepModeChanged.....	14
2.35	TabUtChanged .....	14
2.36	ToolDiameterChanged .....	14
2.37	ToolLengthChanged .....	14
2.38	UsFatalError .....	14
2.39	UsNotifyChanged .....	15
2.40	VariableUserChanged .....	16
2.41	WorkLineDemandChanged .....	16
2.42	WorkLineRealChanged.....	16
2.43	WorkPlaneSetChanged .....	16
2.44	UsCompiler.CodeLoaded.....	17
2.45	G43Changed .....	17
2.46	Us2ndLimitsChanged .....	17
2.47	UsDebuInfo.....	17
3	Methods and Properties of UsWork .....	18
3.1	Double AxisValueToDoubleUs (Int32 AxisIntValue) .....	18
3.2	Void PutNotify(String NotifyText, bool PutInPanel=false) .....	18
3.3	Void PutNotify(UsNotifyType NotifyType, String NotifyText, bool PutInPanel=false)...	18
3.4	Void EndSession() .....	18
3.5	Void ForceEventAxesValue() .....	18
3.6	Void SetIsoUsCnC (Int32 IndexCn, String CfgName) .....	18
3.7	Bool IsoUsModeRun.....	18
3.8	Int32[] GetIndexCnC.....	18
3.9	Int32[] WorkPlaneSet .....	19
3.10	String GetNameConfigIsoUs.....	19
3.11	String GetPathIsoUs .....	19
4	Classi di UsWork.....	20
4.1	MyMaster .....	20
4.2	UsAxesHomingEnable .....	21
4.2.1	<i>bool</i> AllAxesRedy .....	21
4.2.2	<i>bool</i> NoCheckAllAxesRedy.....	21
4.2.3	Int32[] GetAxesHomingSequence .....	21
4.2.4	Void EnableAxis(Int32 AxisIndex, bool State).....	21
4.2.5	Void PresetAbsoluteEncoder(Int32 AxisIndex) .....	21
4.2.6	Int32 ReadEncoderIndexShift(Int32 AxisIndex) .....	21
4.2.7	<i>bool</i> ResetAxesHoming( <i>bool</i> [] Axes).....	21

4.2.8	Void StartHomingAxis(Int32 AxisIndex) .....	22
4.2.9	Void StopHomingAxis() .....	22
4.3	UsAxesManualJog.....	23
4.3.1	Bool AbsoluteRelativeJog.....	23
4.3.2	Bool ExternalJogActivated .....	23
4.3.3	Int HandWheelMultiplier .....	23
4.3.4	Int SelectAxisForJog.....	23
4.3.5	Void MoveAxisJog(int AxisIndex,bool Direction) .....	23
4.3.6	Void MoveAxisToTarget(double Target, Int32 AxisIndex).....	24
4.3.7	Void MoveSelectAxisJog(bool Direction) .....	24
4.3.8	Int32 ReadHandWheelMultiplier() .....	24
4.3.9	Void SelectAxisHandMult(Int32 AxisIndex,Int32 HandWheelMultValue) .....	24
4.3.10	Void SetPositionAxisShift(Int32 AxisIndex,double ShiftValue) .....	24
4.3.11	Void StopAllMove().....	24
4.3.12	EnumIsMoveAxes AxesIsMove ().....	24
4.3.13	EnumMoveAxes MoveInterpolationAxes(StructMoveAxes AxesPar ) .....	25
4.4	UsAxesValue .....	26
4.4.1	Int32 AxesResolution .....	26
4.4.2	double CncTaskTime.....	26
4.4.3	Int32 FeedResolution .....	26
4.4.4	double ReadDemandPosition(Int32 AxisIndex) .....	26
4.4.5	double[] ReadAllDemandPosition() .....	26
4.4.6	double ReadRealPosition(Int32 AxisIndex).....	26
4.4.7	double[] ReadAllRealPosition().....	26
4.4.8	double ReadRelativeDemandPosition(Int32 AxisIndex).....	26
4.4.9	double[] ReadAllRelativeDemandPosition() .....	26
4.4.10	double ReadRelativeRealPosition(Int32 AxisIndex) .....	26
4.4.11	double[] ReadAllRelativeRealPosition() .....	26
4.5	UsBreakPoints .....	27
4.5.1	Int32[] GetAllBreakPoint() .....	27
4.5.2	Int32 InsertBreakPoint(Int32 LineNumber).....	27
4.5.3	Bool IsBreakPoint(Int32 LineNumber) .....	27
4.5.4	Void RemoveAllBreakPoints() .....	27
4.5.5	Void RemoveBreakPoint(Int32 LineNumber) .....	27
4.6	UsCalcTime .....	28
4.6.1	TimeSpan GetTotalTime .....	28
4.6.2	bool ExecuteCalcTime() .....	28



4.7	UsCnErrors.....	29
4.7.1	bool GetErrors(out String[] CnErrors,out String[] UsErrors).....	29
4.7.2	void ResetCnCAlarms().....	29
4.8	UsCnCMemory .....	30
4.8.1	Byte[] ReadArrayByteMemory(Int32 MemoryAddress,Int32 Length).....	30
4.8.2	Int16[] ReadArrayInt16Memory(Int32 MemoryAddress,Int32 Length).....	30
4.8.3	Int32[] ReadArrayInt32Memory(Int32 MemoryAddress,Int32 Length).....	30
4.8.4	void WriteArrayByteMemory(Int32 MemoryAddress, Byte[] DataValues).....	30
4.8.5	void WriteArrayInt16Memory(Int32 MemoryAddress, Int16[] DataValues).....	30
4.8.6	void WriteArrayInt32Memory(Int32 MemoryAddress, Int32[] DataValues).....	30
4.9	UsCnCFunctions.....	31
4.9.1	Void Break_M_Function().....	31
4.9.2	bool Execute_M_Cnc(Int32 Code_M_Function, Int32[] ParametersValue).....	31
4.9.3	Int32 ReadCnC_M_Parameters(Int32 ParameterNumber).....	31
4.9.4	bool WriteCnC_M_Parameters(Int32 ParameterNumber,Int32 ParameterValue).....	31
4.10	UsCnCStatusWord.....	32
4.10.1	bool IsAbsoluteRealtiveMotion.....	32
4.10.2	bool IsStatusAxesMove.....	32
4.10.3	bool[] IsStatusEnableAxes.....	32
4.10.4	bool IsStatusError.....	32
4.10.5	bool IsStatusExternalOverride.....	32
4.10.6	bool[] IsStatuHomingAxes.....	32
4.10.7	bool IsStatusPause.....	32
4.10.8	bool IsStatusProbe.....	32
4.10.9	bool IsStatusRun Property di tipo Boolean- Read Only.....	33
4.10.10	bool IsStatusStepMode.....	33
4.10.11	bool IsStatus_M_Execution.....	33
4.11	UsCompiler.....	34
4.11.1	List<Compiler.MarkerCs> GetMarker.....	34
4.11.2	List<Compiler.DimaArray> GetUsArray.....	34
4.11.3	List<string[]> GetUsDefine.....	34
4.11.4	List<string> GetUsFixedVariables.....	34
4.11.5	List<string> GetUsVariables.....	34
4.11.6	string LastFileCompiled.....	34
4.11.7	Int32 LastTotalCodeLoaded.....	34
4.11.8	Int32 TotalLinesCompiled.....	34
4.11.9	UsWork.IsoUs.UsErrorCompiler[] CompileGcode(string Gcode,bool CanLoadCode,	

out Int32 TotalLines).....	34
4.11.10 UsWork.IsoUs.UsErrorCompiler[] CompileGcodeFromBlock(string GcodePathFile,bool CanLoadCode, out Int32 TotalLines).....	34
4.11.11 UsWork.IsoUs.UsErrorCompiler[] CompileGcodeFromFile(string GcodePathFile,bool CanLoadCode, out Int32 TotalLines).....	35
4.11.12 UsWork.IsoUs.UsErrorCompiler[] CompileGcodeFromPathFile(string GcodePathFile,bool CanLoadCode, out Int32 TotalLines).....	35
4.11.13 bool LoadCode() .....	35
4.12 UsConfig.....	36
4.13 UsGcodeRun.....	37
4.13.1 double Feed .....	37
4.13.2 bool SelectStepMode .....	37
4.13.3 bool BackupCode() .....	37
4.13.4 bool ExecuteGcode(Int32 NlineStart).....	37
4.13.5 Void ExecuteGcodeFromMarker(Int32[] AddressMarker,Double[] ValuesMarker) ..	37
4.13.6 Void ExecuteGcodeFromMarkerAndLine(Int32[] AddressMarker,Double[] ValuesMarker,Int32 LineNumber) .....	38
4.13.7 bool ExecuteGcodeScript(String GcodeScript, out UsWork.IsoUs.UsErrorCompiler[] Errors) 38	
4.13.8 Void PauseGcode().....	39
4.13.9 bool RestoreGcode() .....	39
4.13.10 Void StopGcode() .....	39
4.13.11 Int32 WorkLineReal() .....	39
4.14 UsGcodeVariables.....	40
4.14.1 List<string> GetAllVariablesName .....	40
4.14.2 Int32 GetVariableAddress(String VariableName).....	40
4.14.3 String GetVariableName(Int32 VariableAddress).....	40
4.14.4 double ReadVariableByAddress(Int32 VariableAddress) .....	40
4.14.5 double ReadVariableByName(string VariableName) .....	40
4.14.6 bool WriteVariableByAddress(Int32 VariableAddress,double VariableValue).....	41
4.14.7 bool WriteVariableByName(string VariableName,double VariableValue) .....	41
4.15 UsInputOutput .....	42
4.15.1 bool ReadDigitalInput(Int32 InputNumber) .....	42
4.15.2 bool ReadDigitalOutput(Int32 OutputNumber).....	42
4.15.3 Int32 ReadGroupDigitalInputs(Int32 Group) .....	42
4.15.4 Int32 ReadGroupDigitalOutputs(Int32 Group).....	42
4.15.5 void WriteDigitalOutputs(Int32 OutputNumber,bool OutputState) .....	42
4.16 UsLogFile .....	43

4.16.1	string PathUsLog.....	43
4.17	UsMachineParameters .....	44
4.17.1	UsWork.UsMachineParametersCs.AxesVisType AxesValueMode.....	44
4.17.2	List<ComSynk.ParametriMacchina> MyParameterList .....	44
4.17.3	Int32 NumberOfParameters .....	44
4.17.4	String[] ParametersGroups.....	44
4.17.5	String PathUsCfg .....	44
4.17.6	Void DownLoadParamaters().....	44
4.17.7	bool GetParameterDataByIndex(Int32 ParameterIndex, out String ParameterName,out String ParameterDescr,out String ParameterGroup,out Int32 ParameterValue,out Int32 ParameterAddress) .....	44
4.17.8	bool GetParameterDataByName (String ParameterName, out Int32 ParameterIndex,out String ParameterDescr,out String ParameterGroup,out Int32 ParameterValue,out Int32 ParameterAddress) .....	45
4.17.9	bool GetParameterExtendedData(Int32 ParameterIndex, out Int32 Transform,out Int32 MinValue,out Int32 MaxValue,out Int32 PassWordLevel,out Int32 Familiy, out Int32 AxisIndex, out List<ComSynk.EnumCs> Enums).....	45
4.17.10	bool GetParameterValueByIndex(Int32 ParameterIndex,out Int32 ParameterValue) 45	
4.17.11	bool GetParameterValueByName (String ParameterName,out Int32 ParameterValue).....	45
4.17.12	bool RestoreUsCfgBackUp() .....	46
4.17.13	Void SaveUsCfg().....	46
4.17.14	Void SendAllParameters().....	46
4.17.15	Void UpdateParameters().....	46
4.17.16	bool WriteParametersByIndex(Int32 ParameterIndex, Int32 ParameterValue, bool WriteInCnC).....	46
4.17.17	bool WriteParametersByName(string ParameterName, Int32 ParameterValue, bool WriteInCnC).....	46
4.18	UsMHMfunctions .....	47
4.18.1	bool GenerateHMFunction (Int32 HMFunctionNumebr, String GCode,out UsWork.IsoUs.UsErrorCompiler[] Errors) .....	47
4.18.2	bool GenerateMFunction (Int32 MFunctionNumebr, String GCode,out UsWork.IsoUs.UsErrorCompiler[] Errors).....	47
4.19	UsOffsetAndOrigins .....	48
4.19.1	List<ComSynk.FileZeri> GetAllOriginsByFile .....	48
4.19.2	bool HeadOffsetSuspend.....	48
4.19.3	Int32 IndexOffset .....	48
4.19.4	Int32 IndexOrigin.....	48
4.19.5	bool IsOffset.....	48

4.19.6	bool IsOrigins.....	48
4.19.7	bool OffsetSuspend.....	48
4.19.8	bool OriginsSuspend.....	48
4.19.9	Int32[] SingleAxisIndexOrigins.....	49
4.19.10	Void ActivateOriginFile().....	49
4.19.11	Int32 AxesOffsetDisable(Int32 Index).....	49
4.19.12	Int32 AxesOriginDisable(Int32 Index).....	49
4.19.13	double[] GetCurrentOffset(Int32 Index).....	49
4.19.14	double[] GetCurrentOffsetSetted().....	49
4.19.15	double[] GetCurrentOrigins(Int32 Index).....	49
4.19.16	double[] GetCurrentOriginsSetted().....	49
4.19.17	double[] GetOriginsFromUsFile(Int32 Index).....	49
4.19.18	Int32 SetAxesOffsetToCurrentPosition(Int32 OffsetIndex).....	50
4.19.19	Int32 SetAxesOffsetToPosition(double[] OffsetValue, Int32 OffsetIndex).....	50
4.19.20	Int32 SetAxesOriginsToCurrentPosition(Int32 OriginIndex).....	50
4.19.21	Int32 SetAxesOriginsToPosition(double[] OriginsValue, Int32 OringinIndex).....	50
4.19.22	Int32 SetAxisOffsetToCurrentPosition(Int32 OffsetIndex, Int32 AxisIndex).....	50
4.19.23	Int32 SetAxisOffsetToPosition(double OffsetValue,Int32 OffsetIndex, Int32 AxisIndex).....	50
4.19.24	Int32 SetAxisOriginToCurrentPosition(Int32 OriginIndex, Int32 AxisIndex).....	51
4.19.25	Int32 SetAxisOriginToPosition(double OriginValue,Int32 OriginIndex, Int32 AxisIndex).....	51
4.19.26	bool IsoG43FromTable(Int32 Kmode,Int32 Axis, bool Direction).....	51
4.19.27	bool IsoG43FromLen(Double ToolLen,Int32 Kmode,Int32 Axis, bool Direction).....	51
4.19.28	bool IsoG44(Int32 G44Ext).....	51
4.19.29	bool IsoG43State().....	51
4.20	UsOverrideFeed.....	52
4.20.1	bool ExternalOverrideFeed.....	52
4.20.2	Int32 OverrideFeedAxes.....	52
4.21	UsPassWordManagement.....	53
4.21.1	bool ResetUsPassWord(Int32 PassWordLevel).....	53
4.21.2	bool SetUsNewPassWord(String NewPassWord,Int32 PassWordLevel).....	53
4.21.3	bool TestUsLevelPassWordBlock(Int32 PassWordLevel).....	53
4.21.4	bool TestUsPassWord(String PassWord,Int32 PassWordLevel).....	53
4.22	UsPositioners.....	54
4.22.1	bool AllAxesPositionerReady.....	54
4.22.2	Int32 NumberOfPositioners.....	54

4.22.3	bool EnablePositioner(Int32 PositionerIndex, bool EnableState).....	54
4.22.4	bool IsAlarm(Int32 PositionerIndex, out bool Status) .....	54
4.22.5	bool IsEnabled(Int32 PositionerIndex, out bool Status) .....	54
4.22.6	bool IsHoming(Int32 PositionerIndex, out bool Status) .....	54
4.22.7	bool IsMoving(Int32 PositionerIndex, out bool Status).....	54
4.22.8	bool Preset(Int32 PositionerIndex, Int32 PresetValue, out bool Status).....	55
4.22.9	bool ReadDemandPosition(Int32 PositionerIndex, out Int32 PositionValue) .....	55
4.22.10	bool ReadRealPosition(Int32 PositionerIndex, out Int32 PositionValue).....	55
4.22.11	bool SetOffsetValue(Int32 PositionerIndex, Int32 OffsetValue).....	55
4.22.12	bool SetVelocity(Int32 PositionerIndex, Int32 VelocityValue) .....	55
4.22.13	bool StartHoming(Int32 PositionerIndex).....	55
4.22.14	bool StartPositionTarget(Int32 PositionerIndex, Int32 PositionValue, bool AbsoluteValue).....	56
4.22.15	bool StatusWord(Int32 PositionerIndex, Out Int32 Status).....	56
4.22.16	bool Stop(Int32 PositionerIndex) .....	56
4.23	UsRetrace.....	57
4.23.1	Int32 GetLineRetrace .....	57
4.23.2	Void ExecuteProg() .....	57
4.23.3	bool GetPosAxisAtLine(out Int32 PosX, out Int32 Posy, Int32 Nline).....	57
4.23.4	Void GoLine(Int32 Nline) .....	57
4.23.5	Void InitRetrace().....	57
4.23.6	Void JogDown() .....	57
4.23.7	Void JogUp() .....	57
4.23.8	Void StopJog().....	57
4.24	UsSimulation .....	58
4.24.1	Void ExecuteSimulation() .....	58
4.25	UsSpindleManager .....	59
4.25.1	Void WriteSpindleSpeed(Int32 _Val).....	59
4.25.2	Int32 ReadSpindleSpeed() .....	59
4.25.3	Void WriteSpindleOw(Int32 _Val).....	59
4.25.4	Int32 ReadSpindleOw() .....	59
4.25.5	Int32 SpindleOwState .....	59
4.25.6	Int32 SpindleAnalogBitRes .....	59
4.26	UsStaticVariables .....	60
4.26.1	String GetPathStaticFile.....	60
4.26.2	List<double> GetStaticVariables .....	60
4.26.3	bool LoadStaticFile(String StaticFileName).....	60

4.26.4	Void SaveFile(String StaticFileName).....	60
4.27	UsToolInfo .....	61
4.27.1	Int32 GetIndexAxisLengthEnabled .....	61
4.27.2	double GetToolDiameterSet.....	61
4.27.3	bool GetToolDirection .....	61
4.27.4	double GetToolLengthSet .....	61
4.27.5	bool IsToolLengthActivated .....	61
4.28	UsToolsHeadsTable .....	62
4.28.1	Int32 GetNumberOfHeads .....	62
4.28.2	Int32 GetNumberOfToolsTable .....	62
4.28.3	Int32 SelectHEad .....	62
4.28.4	Int32 SelectTollTable .....	62
4.28.5	double GetHeadParameter(Int32 ParameterIndex).....	62
4.28.6	double GetToolParamater(Int32 ParameterIndex) .....	62
4.28.7	Void SaveToolTabelParameters().....	62
4.28.8	Void WriteHeadParameter(double Value,Int32 HeadIndex, Int32 ParameterIndex) ...	62
4.28.9	Void WriteToolParameter(double Value,Int32 TableIndex, Int32 ParameterIndex) ....	62
4.29	UsGenericVariables .....	63
4.29.1	Int32 ReadUserCnCVariable(Int32 UserAddress).....	63
4.29.2	Void WriteUserCnCVariable(Int32 UserAddress,Int32 UserValue) .....	63
4.30	Us2ndLimitsManager .....	64
4.30.1	bool Is2ndLimits .....	64
4.30.2	bool Activated2ndLimits() .....	64
4.30.3	bool Reset2ndLimits().....	64
4.31	UsProbe.....	65
4.31.1	Double[] GetAxesValue .....	65
4.31.2	bool StartProbeAcquisition(double[] AxesValue).....	65
4.32	UsMultiProcess.....	66
4.32.1	MProcessResult GcodeLoadFromFile(Int ProcessNumber, string GcodePat, Int LoadInEditor).....	66
4.32.2	List<IsoUs> ActiveProcess .....	66
4.33	UsCmdManager .....	67
4.33.1	CmdResult RunCmd(string CmdName, int Cpu, double[] Parameters, bool CheckAxesReady).....	67
4.33.2	bool SaveCmdCode(string Cmd, bool CheckFile) .....	67
4.33.3	string CurrentCmdInRun.....	67
4.33.4	bool IsRunCmd .....	67

4.34	UsTask .....	68
4.34.1	IsoUs.ErrorCompiler[] LoadGcode(string Gcode, int UsTask, out UsTaskError Error) 68	
4.34.2	UsTaskError TaskRun(int UsTask) .....	68
4.34.3	UsTaskError TaskStop(int UsTask).....	68
4.34.4	UsTaskError TaskPause(int UsTask).....	68
4.34.5	UsTaskError TaskReadVar(int UsTask, int AddrVar, out double ValVar).....	68
4.34.6	UsTaskError TaskWriteVar(int UsTask, int AddrVar, double ValVar) .....	68
4.34.7	UsTaskError TaskStatus(int UsTask, out UsTaskStatus Status).....	69
4.34.8	UsTaskError TaskLoadCmd(int UsTask, String CmdName) .....	69
4.34.9	UsTaskError TestTaskCmdAutoLoad(int UsTask) .....	69
4.34.10	UsTaskError SetTaskCmdAutoLoad(int UsTask, String CmdName, bool IsAutoRun).....	69
4.34.11	UsTaskError TaskSetPriority(int UsTask, int Priority).....	69